

## Industrial Automation Headquarters

**Delta Electronics, Inc.**  
Taoyuan Technology Center  
No.18, Xinglong Rd., Taoyuan District,  
Taoyuan City 33068, Taiwan  
TEL: 886-3-362-6301 / FAX: 886-3-371-6301

## Asia

**Delta Electronics (Shanghai) Co., Ltd.**  
No.182 Minyu Rd., Pudong Shanghai, P.R.C.  
Post code : 201209  
TEL: 86-21-6872-3988 / FAX: 86-21-6872-3996  
Customer Service: 400-820-9595

## Delta Electronics (Japan), Inc.

Tokyo Office  
Industrial Automation Sales Department  
2-1-14 Shibadaimon, Minato-ku  
Tokyo, Japan 105-0012  
TEL: 81-3-5733-1155 / FAX: 81-3-5733-1255

## Delta Electronics (Korea), Inc.

Seoul Office  
1511, 219, Gasan Digital 1-Ro., Geumcheon-gu,  
Seoul, 08501 South Korea  
TEL: 82-2-515-5305 / FAX: 82-2-515-5302

## Delta Energy Systems (Singapore) Pte Ltd.

4 Kaki Bukit Avenue 1, #05-04, Singapore 417939  
TEL: 65-6747-5155 / FAX: 65-6744-9228

## Delta Electronics (India) Pvt. Ltd.

Plot No.43, Sector 35, HSIDC Gurgaon,  
PIN 122001, Haryana, India  
TEL: 91-124-4874900 / FAX : 91-124-4874945

## Delta Electronics (Thailand) PCL.

909 Soi 9, Moo 4, Bangpoo Industrial Estate (E.P.Z),  
Pattana 1 Rd., T.Phraksa, A.Muang,  
Samutprakarn 10280, Thailand  
TEL: 66-2709-2800 / FAX : 662-709-2827

## Delta Energy Systems (Australia) Pty Ltd.

Unit 20-21/45 Normanby Rd., Notting Hill Vic 3168, Australia  
TEL: 61-3-9543-3720

## Americas

### Delta Electronics (Americas) Ltd.

Raleigh Office  
P.O. Box 12173, 5101 Davis Drive,  
Research Triangle Park, NC 27709, U.S.A.  
TEL: 1-919-767-3813 / FAX: 1-919-767-3969

### Delta Greentech (Brasil) S/A

São Paulo Office  
Rua Itapeva, 26 – 3º Andar - Bela Vista  
CEP: 01332-000 – São Paulo – SP - Brasil  
TEL: 55-11-3530-8642 / 55-11-3530-8640

### Delta Electronics International Mexico S.A. de C.V.

Mexico Office  
Vía Dr. Gustavo Baz No. 2160, Colonia La Loma,  
54060 TlalnepanTla Estado de Mexico  
TEL: 52-55-2628-3015 #3050/3052

## EMEA

### Headquarters: Delta Electronics (Netherlands) B.V.

Sales: Sales.IA.EMEA@deltaww.com  
Marketing: Marketing.IA.EMEA@deltaww.com  
Technical Support: iatechnicalsupport@deltaww.com  
Customer Support: Customer-Support@deltaww.com  
Service: Service.IA.emea@deltaww.com  
TEL: +31(0)40 800 3800

### BENELUX: Delta Electronics (Netherlands) B.V.

De Witbogt 20, 5652 AG Eindhoven, The Netherlands  
Mail: Sales.IA.Benelux@deltaww.com  
TEL: +31(0)40 800 3800

### DACH: Delta Electronics (Netherlands) B.V.

Coesterweg 45, D-59494 Soest, Germany  
Mail: Sales.IA.DACH@deltaww.com  
TEL: +49(0)2921 987 0

### France: Delta Electronics (France) S.A.

ZI du bois Challand 2, 15 rue des Pyrénées,  
Lisses, 91090 Evry Cedex, France  
Mail: Sales.IA.FR@deltaww.com  
TEL: +33(0)1 69 77 82 60

### Iberia: Delta Electronics Solutions (Spain) S.L.U.

Ctra. De Villaverde a Vallecas, 265 1º Dcha Ed.  
Hormigueras – P.I. de Vallecas 28031 Madrid  
TEL: +34(0)91 223 74 20

Carrer Llacuna 166, 08018 Barcelona, Spain  
Mail: Sales.IA.Iberia@deltaww.com

### Italy: Delta Electronics (Italy) S.r.l.

Ufficio di Milano Via Senigallia 18/2 20161 Milano (MI)  
Piazza Grazioli 18 00186 Roma Italy  
Mail: Sales.IA.Italy@deltaww.com  
TEL: +39 02 64672538

### Russia: Delta Energy System LLC

Vereyskaya Plaza II, office 112 Vereyskaya str.  
17 121357 Moscow Russia  
Mail: Sales.IA.RU@deltaww.com  
TEL: +7 495 644 3240

### Turkey: Delta Greentech Elektronik San. Ltd. Sti. (Turkey)


Şerifali Mah. Hendem Cad. Kule Sok. No:16-A  
34775 Ümraniye – İstanbul  
Mail: Sales.IA.Turkey@deltaww.com  
TEL: + 90 216 499 9910

### GCC: Delta Energy Systems AG (Dubai BR)

P.O. Box 185668, Gate 7, 3rd Floor, Hamarain Centre  
Dubai, United Arab Emirates  
Mail: Sales.IA.MEA@deltaww.com  
TEL: +971(0)4 2690148

### Egypt + North Africa: Delta Electronics

511 Cairo Business Plaza, North 90 street,  
New Cairo, Cairo, Egypt  
Mail: Sales.IA.MEA@deltaww.com



# Industrial 4G/WAN Cloud Router DX-3021L9 Series User Manual

# Industrial 4G / WAN Cloud Router DX-3021L9 Series User Manual

## Revision History

Version	Revision	Date
1 <sup>st</sup>	The first version was published.	2020/01/22

**Delta Industrial 4G / WAN Cloud Router DX-3021L9 Series User Manual**  
**Contents**

**Chapter 1 Product Introduction**

<b>1.1</b>	<b>Product Overview .....</b>	<b>1-3</b>
1.1.1	Network Design .....	1-4
1.1.2	Features .....	1-5
1.1.3	Front Panel Ports and LEDs.....	1-6
1.1.4	Top Panel.....	1-6
1.1.5	Bottom Panel .....	1-7
1.1.6	Dimension .....	1-8
<b>1.2</b>	<b>Package Checklist .....</b>	<b>1-8</b>

**Chapter 2 User Interface**

<b>2.1</b>	<b>Web-based GUI Configuration.....</b>	<b>2-2</b>
2.1.1	System Connection .....	2-2
2.1.2	Default IP Address/Account/Password .....	2-2
2.1.3	Local Network Setups .....	2-2
2.1.4	Logging in.....	2-4
<b>2.2</b>	<b>DIADevice.....</b>	<b>2-5</b>
2.2.1	Device Connection and Detection .....	2-5
2.2.2	Network Setting.....	2-7
2.2.3	Bind Device.....	2-10
2.2.4	Open Device Webpage.....	2-12
<b>2.3</b>	<b>Typical application configuration .....</b>	<b>2-13</b>
2.3.1	Data collection .....	2-13
2.3.2	Remote debugging .....	2-19

**Chapter 3 Function Guide**

<b>3.1</b>	<b>Status .....</b>	<b>3-3</b>
3.1.1	Device Information .....	3-3
3.1.2	Network Status.....	3-5

3.1.3	Routing Table .....	3-6
3.1.4	Local Log.....	3-6
3.1.5	Traffic Statistics.....	3-7
3.1.6	Cloud Status.....	3-7
3.1.7	Connected Device .....	3-7
<b>3.2</b>	<b>Network.....</b>	<b>3-8</b>
3.2.1	Connection .....	3-8
3.2.2	Cellular Link1 .....	3-9
3.2.3	Cellular Link2.....	3-10
3.2.4	PIN Management .....	3-11
3.2.5	WAN Configurations .....	3-13
3.2.6	LAN Configurations .....	3-15
3.2.7	WLAN Setting .....	3-17
3.2.8	Static Routing Rules.....	3-19
3.2.9	Dynamic DNS .....	3-20
<b>3.3</b>	<b>Firewall .....</b>	<b>3-21</b>
3.3.1	Firewall Settings.....	3-22
3.3.2	DMZ Settings.....	3-22
3.3.3	Port Forward .....	3-23
3.3.4	Port Trigger .....	3-25
3.3.5	URL Filter .....	3-27
3.3.6	MAC Filter .....	3-28
3.3.7	IP Filter.....	3-29
<b>3.4</b>	<b>Interface .....</b>	<b>3-30</b>
3.4.1	RS232 .....	3-30
3.4.2	RS485 .....	3-40
3.4.3	Modbus TCP.....	3-48
3.4.4	Siemens TCP.....	3-51
3.4.5	DI/DO.....	3-53
3.4.6	USB.....	3-55
<b>3.5</b>	<b>System .....</b>	<b>3-56</b>
3.5.1	User Management .....	3-56
3.5.2	Time Zone Configurations .....	3-57
3.5.3	Log Settings .....	3-57

3.5.4	Firmware Upgrade .....	3-59
3.5.5	Backup & Restore .....	3-59
3.5.6	System Reboot .....	3-60
3.5.7	Network Diagnosis .....	3-60
3.5.8	Trouble shooting .....	3-61
3.5.9	Scheduled Jobs .....	3-61
3.5.10	Privilege Management .....	3-63
3.5.11	Event Management .....	3-66
3.5.12	Register Management .....	3-71
<b>3.6</b>	<b>Cloud Service .....</b>	<b>3-72</b>
3.6.1	Cloud Configuration .....	3-72
3.6.2	Proxy Setting .....	3-76
3.6.3	Tunnel Firewall .....	3-77
3.6.4	Cloud Log .....	3-78
<b>3.7</b>	<b>Quick Operation .....</b>	<b>3-79</b>
<b>Chapter 4 DIACOM</b>		
<b>4.1</b>	<b>Introduction to DIACom .....</b>	<b>4-2</b>
4.1.1	Select a Suitable Firmware Version .....	4-2
4.1.2	DIACom Installation .....	4-3
4.1.3	DIACloud Account Registration .....	4-3
4.1.4	Bind DIACloud Account .....	4-5
<b>4.2</b>	<b>DIACom Operation .....</b>	<b>4-6</b>
4.2.1	Setup a Secure Tunnel .....	4-6
4.2.2	Create a Virtual Serial-Port .....	4-10
4.2.3	Remote Control and Monitoring via DIACom .....	4-11
4.2.4	Automation Startup .....	4-13
<b>Chapter 5 DIACloud</b>		
<b>5.1</b>	<b>Introduction to DIACloud .....</b>	<b>5-2</b>
5.1.1	Select a Suitable Firmware Version .....	5-2
<b>5.2</b>	<b>Instructions for DIACloud .....</b>	<b>5-2</b>

5.2.1	Register and Login.....	5-2
5.2.2	Home .....	5-4
5.2.3	Devices.....	5-6
5.2.4	Alarm .....	5-17
5.2.5	Secure Tunnels.....	5-17
5.2.6	Sub Users .....	5-19
5.2.7	Logs .....	5-22
5.2.8	Orders .....	5-23
5.2.9	Profile.....	5-24

## **Chapter 6 DIACloud APP**

<b>6.1</b>	<b>Introduction to DIACloud APP .....</b>	<b>6-2</b>
6.1.1	Select a Suitable Firmware Version .....	6-2
6.1.2	DIACloud APP Installation .....	6-2
<b>6.2</b>	<b>DIACloud APP Function.....</b>	<b>6-3</b>
6.2.1	DIACloud APP Login .....	6-3
6.2.2	Device List .....	6-4
6.2.3	Device Details .....	6-5
6.2.4	Registers View .....	6-6
6.2.5	Alarm List.....	6-7

---

# Chapter 1 Product Introduction

## Table of Contents

- 1.1 Product Overview..... 1-3**
- 1.1.1 Network Design..... 1-4
- 1.1.2 Features..... 1-5
- 1.1.3 Front Panel Ports and LEDs ..... 1-6
- 1.1.4 Top Panel ..... 1-6
- 1.1.5 Bottom Panel ..... 1-7
- 1.1.6 Dimension ..... 1-8
- 1.2 Package Checklist ..... 1-8**

## About This Manual

The user manual is suitable for **DX-3021L9**.

## FCC Interference Statement

This equipment has been tested and found to comply with the limits for a class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates radio frequency signal and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

## CE Declaration of Conformity

In accordance with the Directives RED 2014/53/EU. The test record, data evaluation and DX-3021L9 configurations represented herein are true and accurate under the standards herein specified.

EN 301 511 V12.5.1 (2017-03)

Test Items:

Radiated spurious emissions – MS allocated channel (Clause 4.2.16)

Radiated spurious emissions – MS in idle mode (Clause 4.2.17)

EN 301 908-1 V11.1.1 (2016-07)



EN 301 489-1 V2.1.1 (2017-02)

Draft EN 301 489-52 V1.1.0 (2016-11)

## Disclaimers and Limitation of Liabilities

To the maximum extent permitted by law and regardless DELTA be aware or has been advised of the possibility of these damages, DELTA is not liable to any user or anyone else for: (a) any loss of use, data, reputation, goodwill, credit, opportunity, economy or profits, whether or not foreseeable; (b) any special, incidental, indirect, consequential, or punitive damages whatsoever; (c) any losses or damages based on any theory of liability, including breach of contract or warranty, negligence or other tortious action; (d) any losses or damages resulting from use or unable to use the systems or devices to which the Software or Services are incorporated or co-operated; and (e) any losses or damages arising from any other claim or in connection with the use of or access to the Software or Services.

## Warning

	<p>此设备应安装在限制进出的场所。限制进出场所指仅能透过特殊工具、锁和钥匙或其他安全手段才能进出的场所。</p> <p>This equipment should be installed in a place where access is restricted.</p> <p>Restricted places are places that can only be accessed through special tools,</p>
	<p>在接近热源部分的明显位置上会有警告标示。</p> <p>There will be a warning sign in an obvious position near the heat source part</p>

## Warning

Supplied by LPS power source

### 1.1 Product Overview

DX-3021L9 is an industrial router, it has 2 SIM card slots and supports multiple mobile networks like LTE, DC-HSPA+, UMTS, EDGE, GPRS, and GSM. When one cellular network fails to work, the device will automatically switch to the other cellular network. Besides the two cellular network connections, the WAN port can be another connection to Internet. Priorities of the connection to Internet over WAN and 2 cellular networks are configurable. As there is only one 4G module in the device, the two cellular networks cannot be active at the same time. Moreover, the product is equipped with multiple application interfaces, including Ethernet interface, RS232 serial interface and RS485 serial interface, and thus can satisfy the user's various different application demands.

The product supports DIACloud platform services, and by this platform, convenient and efficient point-to-point connection with the router, safe and reliable data transmission, remote device management and configuration, remote firmware upgrading, remote maintenance and other functions can be realized, so as to save the cost of device operation and maintenance for users.


The product can be widely used in the fields requiring mobile network interconnection, such as industrial automation, smart home, intelligent building, smart power grids, mobile video surveillance, intelligent self-service and intelligent transportation.

1



### 1.1.1 Network Design

DIACloud platform services supported, users can connect intelligent devices from different locations to the internet with DX-3021 and use point-to-point connection with the router for a safe and reliable data transmission and additionally save the costs of VPN device operation as well as maintenance. By browsing the web or apps on the handheld computers, managers can check the data and monitor the devices remotely in real-time




## 1.1.2 Features


- A wide range of LTE FDD and LTE TDD frequency bands supports, B38/B39/B40/B41 for LTE TDD, and B1/B2/B3/B4/B5/B7/B8/B12/B13/B18/B19/B20/B25/B26/B28 for LTE FDD
- Downward compatible with WCDMA (B1/B2/B4/B5/B6/B8/B19) and GSM (850/900/1800/1900MHz) networks
- Automatic redial when connection is broken
- Priorities of the connection to Internet over WAN and 2 cellular networks are configurable
- Provide Dual Port RS232 & RS485 and LAN Port Interfaces for Different Application Demands
- Built-in a Watchdog Timer to Ensure System Stability
- Built-in RTC and Support NTP Server
- Firmware Upgrade Locally and Remotely
- Support Firewall: Stateful Packet Inspection (SPI), Prevent Denial of Service (DoS) Attacks, NAT (Network Address Translation), Port Triggering, Port Mapping, IP Address Filtering, MAC Address Filtering, URL Filtering, DHCP Server, Dynamic DNS, Static Routes, Demilitarized Zone (DMZ)
- Various Protocols, TCP/IP, UDP, ICMP, DHCP, HTTP, DNS, SSH and More
- Modbus TCP, Modbus ASCII and Modbus RTU protocol
- Mitsubishi MC and Siemens ISO TCP protocol
- Support to upgrade device firmware and configure automatically via USB drive. User can access the USB drive by FTP also.
- Scheduled Task Management
- Support 2 DI/DO and user can config trigger events.
- Servers for Local Log and Remote Log
- Configurations Backup, Export and Import
- Network Flow Monitoring
- Network Fault Detection and Diagnosis
- DIACloud Service to Secure Point-to-point Data Transmission, to Manage Device Configurations Piece by Piece or in Batch and to Upgrade Firmware Remotely

1


### 1.1.3 Front Panel Ports and LEDs



### 1.1.4 Top Panel



### 1.1.5 Bottom Panel




#### Notice

This router's reset button is on the front panel. By pressing the Reset button, users can reset the router or reset the router to factory default settings. See the instruction below:

- Reset the Router: With the router powered on, press the Reset button and release the button right away.
- Reset to Factory Defaults: With the router powered on, press and hold the Reset button for 3~6 seconds and then release the button.
  - Reset can only be done when the device is running properly.
  - With the router powered on, press and hold the Reset button until all the LEDs go out (except the Power LED). Then release the button and wait the router to reboot to its factory default settings.

### 1.1.6 Dimension

Unit = mm



## 1.2 Package Checklist

Unpack the package carefully and check the package contents. The package should contain the following items:

- DX-3021L9 Industrial 4G Cloud Router x 1
- Quick Installation Guide x 1
- SMA Antenna (300cm) x 1



### Notice

Verify that nothing is missing from the DX-3021L9 package by using the check list above. If any item is found missing or damaged, please contact your local sales representative for support.

---

## Chapter 2 User Interface

### Table of Contents


<b>2.1</b>	<b>Web-based GUI Configuration</b> .....	<b>2-2</b>
2.1.1	System Connection .....	2-2
2.1.2	Default IP Address/Account/Password.....	2-2
2.1.3	Local Network Setups.....	2-2
2.1.4	Logging in .....	2-4
<b>2.2</b>	<b>DIADevice</b> .....	<b>2-5</b>
2.2.1	Device Connection and Detection .....	2-5
2.2.2	Network Setting .....	2-7
2.2.3	Bind Device .....	2-10
2.2.4	Open Device Webpage .....	2-12
<b>2.3</b>	<b>Typical application configuration</b> .....	<b>2-13</b>
2.3.1	Data collection .....	2-13
2.3.2	Remote debugging.....	2-19

## 2.1 Web-based GUI Configuration

The DX-3021L9 Industrial 4G Cloud Router provides a friendly Web Browser Configuration for users to set up and operate more intuitively.

### 2.1.1 System Connection

Connect the DX-3021L9 with a computer directly or via a switch/hub.






### 2.1.2 Default IP Address/Account/Password

The default IP address of router is 192.168.5.5. The default account and password is admin/admin.


### 2.1.3 Local Network Setups

After the connection of the local computer and the router is done, you will need to set the network configuration for your computer. There are 2 methods for the setting, we prefer you use the first one:

- **Obtain an IP address automatically by using the router as a DHCP server.**
  1. Open Network Connections by clicking the Start button , and then clicking Control Panel.
  2. Under Network and Sharing Center, click View network connections.
  3. Right-click the connection that you want to change, and then click Properties.  If you're prompted for an administrator password or confirmation, type the password or provide confirmation.
  4. Click the Networking tab. Under This connection uses the following items, click either Internet Protocol Version 4 (TCP/IPv4) or Internet Protocol Version 6 (TCP/IPv6), and then click Properties.




5. Click Obtain DNS server address automatically and then click OK to get a DNS server address automatically using DHCP.



- **Set up the IP address manually.**  
(The IP address of the computer should be in the same subnet as the router's.)


Since the router's default IP address is 192.168.5.5 and the subnet mask is 255.255.255.0, the computer's IP address can be set between 192.168.5.1 to 192.168.5.254 except 192.168.5.5. However, you'll need to make sure there are no IP conflicts.

Here, we set the IP address to 192.168.5.10 and the default gateway to 192.168.5.5. For DNS, the usable DNS address can be selected or the address can also be set to 192.168.5.5.



### 2.1.4 Logging in


1. Open your Internet Explorer browser and input LAN IP address (Default is 192.168.5.5) in the search bar and then press Enter.



2. You'll be prompted with the log-in page. Input the user name and the password (Default is admin/admin) and then press Enter to log in to the setup page.



- After login, you can see the main selection area on the left hand side and the upper area of the page. The detailed settings can be seen on the right-hand side of the page.



## 2.2 DIADevice


DIADevice is a tool for quickly configuring network devices. Users simply connect the DX device to the PC through the network cable. This tool can be used to quickly and easily configure the network setting of the device and complete the device binding DIACloud cloud account.

The DIADevice software is included in the latest DIACom software package. From the official website or sales staff to obtain DIACom packag.


The following example uses DX-3021 to show you how to configure your device with DIADevice.

### 2.2.1 Device Connection and Detection


- Connect the device to the power supply, and connect the device to the PC using a network cable. Plug the network cable connected to the Internet into the WAN port of the device
- Run DIADevice software, click "Detect" button.



3. After DIACom detects the device, it will automatically go to the login page, and the user needs to enter login password on the login page.



4. After passing the authentication, the device information page is displayed, including the basic device information (Device Name, S / N, firmware, LAN IP address), network status, WAN information, and cloud service information



## 2.2.2 Network Setting

This feature allows you to quickly configure your network in two steps.

1. Click "Network Setting"



2. You can setup the connection priority here, and then, it will guide you to config each the connection parameter page base on the priority what you setup.

2

The screenshot shows the 'DIA Device' configuration window. At the top, there are three diamond-shaped step indicators labeled 1, 2, and 3. Step 1 is highlighted in blue. The main configuration area contains the following fields:

Primary Connection	WAN
Secondary Connection	Cellular Link1
Tertiary Connection	Disabled
Auto Detect	Cloud Service
Dial Failure Restart	Disabled
Detect Interval	60


At the bottom right, there are two buttons: 'Back' and 'Next'.

3. WAN setting page and Proxy setting page(if need)

The screenshot shows the 'DIA Device' configuration window for WAN settings. At the top, there are three diamond-shaped step indicators labeled 1, 2, and 3. Step 2 is highlighted in blue. The main configuration area contains the following fields:

WAN Connection Mode	Static
IP Allocation Method	Manual
IP Address	1. . . 228
Network Mask	255.255.255.0
Gateway Address	10. . . 14
MTU	1500
DNS Assign	Dynamic

At the bottom right, there are two buttons: 'Prev' and 'Next'.




The screenshot shows the 'DIA Device' configuration window. At the top, there are three diamond-shaped navigation buttons labeled 1, 2, and 3. Button 2 is highlighted in blue. Below the navigation buttons is a form titled 'Proxy Setting' with the following fields:

- Proxy Setting:** A dropdown menu with 'Enabled' selected.
- Proxy Address:** A text input field.
- Port:** A text input field.
- Username:** A text input field.
- Password:** A text input field.

At the bottom right of the form, there are two blue buttons: '< Prev' and 'Next >'.

4. Cellular network setting page.




The screenshot shows the 'DIA Device' configuration window. At the top, there are three diamond-shaped navigation buttons labeled 1, 2, and 3. Button 2 is highlighted in blue. Below the navigation buttons is a form titled 'Cellular1' with the following fields:

- Working Mode:** A dropdown menu with 'Manual' selected.
- Dial Type:** A dropdown menu.
- Username:** A text input field.
- Password:** A text input field.
- APN:** A text input field.
- Authorization Mode:** A dropdown menu with 'Auto' selected.
- Dial Number:** A dropdown menu with '\*99# (UMTS/3G/3.5G)' selected.

At the bottom right of the form, there are two blue buttons: '< Prev' and 'Next >'.


5. After the router connected to the Internet, the network setting was completed successfully.



### 2.2.3 Bind Device

This feature allows you to quickly bind your device to the DIAcloud in three steps.

1. Click "Bind Device"



2. Enter the DIAcloud account number and password, and click Next.


The screenshot shows the 'DIA Device' configuration window. At the top, there are three diamond-shaped step indicators: 1 (highlighted in blue), 2 (grey), and 3 (grey). The main form area contains two input fields: 'Cloud Account' with the value '.....@163.com' and 'Password' with the value '.....'. At the bottom right, there are two buttons: 'Back' (disabled) and 'Next' (active).

3. After binding configuration is configured, click “Bind” to bind.


The screenshot shows the 'DIA Device' configuration window. At the top, there are three diamond-shaped step indicators: 1 (grey), 2 (highlighted in blue), and 3 (grey). The main form area contains several fields: 'Cloud Account' (.....@163.com), 'Device Name' (DX3021\_C888), 'Secure Tunnel' (default), 'Cloud DHCP' (Enabled), 'Retrieve IP address from cloud' (Yes), and 'Network Protocol' (UDP). At the bottom right, there are two buttons: 'Prev' (disabled) and 'Bind' (active).

4. If your device is successfully bound to the cloud, the following screen will appear

2





**Notice**

 If the device has been bound to the cloud account, you need to switch to another cloud account binding, you only need to repeat 1-3 steps and then enter the new cloud account you need to bind.

### 2.2.4 Open Device Webpage

Click open device webpage button, the browser will open the device settings page, the user can setup more the configuration items.





## 2.3 Typical application configuration


DX-3021 is an industrial-grade cloud router, through it users can easily and quickly collect remote data and remote device debugging.

### 2.3.1 Data collection

DX router can connect to the Slave via serial port or ethernet port, router built in more than 2000 registers, through standard Modbus RTU ASCII and Modbus/TCP protocol, and Mitsubishi MC and Siemens TCP protocol, work as Master/Slave role to collecting/receiving data, and upload data to the cloud.

The basic steps of data collection are as follows:


2




### 1. Register DIACloud Account

Cloud account is an important credential of DX router ownership. When the router is bound with a DIACloud account, only the account or the sub-account authorized by the account can access the device remotely. All data uploaded by the router belongs to this account, which can only be accessed by this account or sub-accounts authorized by this account. If you don't already have a cloud account, follow these steps to register:

- Browsing DIACloud website (<http://www.DIACloudSolutions.com>), click "CREATE AN ACCOUNT".



- Fill in account info and select “I Agree”, click “CREATE AN ACCOUNT” button.

A screenshot of a web form for account creation, enclosed in a blue border. The form contains the following fields and elements from top to bottom: an email input field with an envelope icon and an asterisk; a password input field with a lock icon and an asterisk; a confirm password input field with a lock icon and an asterisk; two radio buttons labeled 'Person' and 'Enterprise', with 'Enterprise' selected; a name input field with a person icon and an asterisk; a country dropdown menu with a globe icon; a verification code input field with a shield icon, an asterisk, and a small box containing the code 'A2GSU'; a checkbox labeled 'I Agree' with the word 'AGREEMENT' in red text to its right; and a grey button labeled 'CREATE AN ACCOUNT' at the bottom.

- Login your mailbox. Open the activation email sent from [no-reply@DIACloudSolutions.com](mailto:no-reply@DIACloudSolutions.com) and complete DIACloud account activation operation.

## 2. Config DX Router

Here show how to config the DX router, make it as the modbus master to collect the data from Delta PLC via RS-485.

- Connect DX router to local PC via cable, login the config GUI, See section 2.1 for details
- Due to DX-3021 support multiple up-link to connect to intenal, so, you can assign the connect priority in “NETWORK”-“Connection” page as below:

🏠 NETWORK > Connection Priority

### ☰ Connection Priority

---

Primary Connection	<input type="text" value="WAN"/>
Secondary Connection	<input type="text" value="Disabled"/>
Tertiary Connection	<input type="text" value="Disabled"/>
Auto Detect	<input type="text" value="Cloud Service"/>
Dial Failed To Restart	<input type="text" value="Disabled"/>
Detect Interval	<input type="text" value="60"/> (30~300s)
Default SMS SIM	<input type="text" value="SIM1"/>

Save

Cancel

And then, base the connection priority setting, goto corresponding to set up the up-link parameter.

🏠 NETWORK > WAN Configurations

### ☰ WAN Configurations

---

WAN Connection Mode	<input type="text" value="DHCP"/>
IP Allocation Method	<input type="text" value="Dynamic"/>
Packet MTU	<input type="text" value="1500"/>
(Don't change the settings unless really need to)	
Retrieve DNS Address By:	<input type="text" value="Dynamic"/>

Save

Cancel

After save the setting, check the network status from "STATUS"- "Network Status" page.

**Connection**

Connection Type	WAN	WAN Connection Mode	DHCP
IP Address	: [redacted] 102	Network Mask	<a href="#">255.255.255.0</a>
Gateway Address	[redacted] 1	Primary DNS	: [redacted].99
Secondary DNS	114.114.114.114		

- Click meun "INTERFACE"-“RS485” to goto RS-485 setting page, set up it’s working mode to “Master mode”, detail configure as the following:

**RS485**

Working Mode

Baud Rate

Data Bits

Stop Bits

Parity Bits

Slave ID

Mode

Timeout  (ms)

**Read/Write Configuration**

Scan Interval  (ms)

When communicate with PLC of Delta, the starting address can be set as the internal register number. For example, input 0 for register D0.

The acceptable address range of this device is: \$0-\$1535 or \$2048-\$4095 or M0-M511.

Row Number	Read/Write	Slave ID	Controller	Address Type	Slave Starting Address	Bit	Device Starting Address	Length (1-123)	Operation
1	Read/Write	1	Delta DVP PLC	D	100	0	\$2048	10	<input type="button" value="+"/> <input type="button" value="-"/>

- Click meun "SYSTEM"-“Register Management” to goto register setting page, set up the data upload rules, detail configure as the following:

☰ Add

Register Type  Word ▾

Register Address  (\$2048-4095, M0-511)

Length

Uploaded To Cloud  Yes ▾

Keep History  No ▾

- Click meun "Cloud Service"-“Cloud configurations” to goto account setting page, bind the device with DIACloud account, detail configure as the following:

🏠 CLOUD SERVICE > Cloud Configurations

☰ Cloud Configurations

User Name:

Password:

Parts of firewall function will loss effect when device is binding success!

Click the "verify" button to verify the user name/password, it will show below page after verification is pass. User can use the default parameters. Click the "bind" button to bind the device to this account.

☰ Cloud Configurations

User Name:

Password:

Secure Tunnel:  ▾

Device Name:

Secure Tunnel DHCP: Not available

When DHCP server in the secure tunnel network is not available, the IP address of the secure tunnel will be the LAN IP, if you want to change it ,please go to LAN configuration web page

Device IP:

Network Protocol:  ▾

After binding successful, you can log in the device configuration page again and check the binding information.

## 🏠 CLOUD SERVICE > Cloud Configurations

User Name:	diacloud@163.com	
Registration Status:	Registered	<a href="#">Unbind</a>
Service Status:	Enabled	<a href="#">Disable</a>
Secure Tunnel:	default	
Device Name:	DX3021_C888	
Secure Tunnel DHCP:	Not available	
Device IP:	192.168.10.50	
Network Protocol:	UDP	

### 3. View data in DIACloud

- Browsing DIACloud website, login with your account.
- Click menu “Devices”, find the device and click the “\*\*\*” to view the detail.
- Select “Registers” and then will show register list, the value are the collection data.


OVERVIEW	REGISTERS	SERVICES	MORE
<input type="text" value="Search"/> <span style="float: right;">&lt; 1/200 &gt;</span>			
\$2048	22363 2018-07-27 03:04		⋮
\$2049	22232 2018-07-27 03:04		⋮
\$2050	22206 2018-07-27 03:04		⋮
\$2051	0 2018-06-06 17:56		⋮
\$2052	0 2018-06-06 17:56		⋮
\$2053	22214 2018-07-27 03:04		⋮
\$2054	10 2018-06-06 17:56		⋮
\$2055	22047 2018-07-27 03:04		⋮
\$2056	3 2018-06-06 17:56		⋮

### 2.3.2 Remote debugging

DX router have built-in DIACloud cloud service, so when the router is bound to the DIACloud account and connected to the DIACloud cloud platform, the router and the cloud platform will create a secure tunnel, and all the devices in the same secure tunnel group under the account will be in the same secure virtual LAN. With our DIACom PC tool, users can also

add their local computers to the virtual LAN, allowing them to download and debug remote devices as if they were operating locally, either through the network port or by creating a virtual serial port.

2



**1. Register DIACloud Account**

If you have a DIACloud account already, skip this step. To register a new account, please refer to section 2.3.1.

**2. Config DX Router**

Here show how to config the DX router, to perform remote debug Delta PLC via RS-485.

- Connect DX router to local PC via cable, login the config GUI, See section 2.1 for details
- Due to DX-3021 support multiple up-link to connect to intenal, so, you can assign the connect priority in “NETWORK”-“Connection” page as below:

🏠 NETWORK > Connection Priority

### ☰ Connection Priority

Primary Connection	<input type="text" value="WAN"/>
Secondary Connection	<input type="text" value="Disabled"/>
Tertiary Connection	<input type="text" value="Disabled"/>
Auto Detect	<input type="text" value="Cloud Service"/>
Dial Failed To Restart	<input type="text" value="Disabled"/>
Detect Interval	<input type="text" value="60"/> (30~300s)
Default SMS SIM	<input type="text" value="SIM1"/>

Save

Cancel

And then, base the connection priority setting, goto corresponding to set up the up-link parameter.

🏠 NETWORK > WAN Configurations

### ☰ WAN Configurations

WAN Connection Mode	<input type="text" value="DHCP"/>
IP Allocation Method	<input type="text" value="Dynamic"/>
Packet MTU	<input type="text" value="1500"/>
(Don't change the settings unless really need to)	
Retrieve DNS Address By:	<input type="text" value="Dynamic"/>

Save

Cancel

After save the setting, check the network status from "STATUS"- "Network Status" page.

### ☰ Connection

Connection Type	WAN	WAN Connection Mode	DHCP
IP Address	[REDACTED] 102	Network Mask	<a href="#">255.255.255.0</a>
Gateway Address	[REDACTED] 1	Primary DNS	<a href="#">[REDACTED].99</a>
Secondary DNS	114.114.114.114		

- Click menu "INTERFACE"->"RS485" to go to RS-485 setting page, set up its working mode to "Transparent mode", configure as the following:

🏠 SYSTEM > RS485

### ☰ RS485


Working Mode	<input type="text" value="Transparent mode"/>
Baud Rate	<input type="text" value="9600"/>
Data Bits	<input type="text" value="8"/>
Stop Bits	<input type="text" value="1"/>
Parity Bits	<input type="text" value="None"/>



- Click menu "Cloud Service"->"Cloud configurations" go to account setting page, bind the device with DIACloud account, please refer to section 2.3.1 for the detail.

### 3. DIACom Tool


- Obtain the DIACom firmware package from the official website or from our sales representative. Administrator privileges are required to run and install the package. After install successfully, run this program and login with DIACloud account.



- Selected the tunnel group which router belong. Set up local IP address same segment with DX route. And click "Create Tunnel" button.


Status	Name	SN	Latency	IP Address	Operation
Online	DX3021_C888	DX30210119270027	7 ms	192.168.10.50	🗑️
Offline	VR500L1_7AE6	VR05000218410024	-	192.168.5.5	🗑️
Offline	告警测试	DX21000218420008	-	192.168.200.10	🗑️
Offline	VR500L1_6D81	VR05000218290012	-	192.168.5.5	🗑️
Offline	DX501L1_7B09	DX05010118410059	-	10.181.150.33	🗑️
Offline	lilytest	VR05000217220010	-	10.128.157.158	🗑️
Offline	VR500L1_2323	VR05000218010101	-	10.103.138.86	🗑️
Offline	VR500L1办公室挂机(勿动)	VR05000218290039	-	10.56.71.135	🗑️
Offline	VR-500H1	VR05000218201234	-	10.112.239.213	🗑️
Offline	VR-500H1	DX05000218290030	-	10.108.69.82	🗑️
Offline	VR-500H1	VR05000218290101	-	10.59.127.219	🗑️

Local IP Address N/A




- After the tunnel has been created, click button of the DX router, goto create virtual com page. If “Create” button is not available, please check the RS-485 wrok mode in DX router config page.





- After the virtual serial port is created, open the corresponding debugging tool WPLSoft of Delta PLC, you can remote download the program to the PLC, which connect to DX router through RS-485.



---

## Chapter 3 Functions

### Table of Contents

<b>3.1</b>	<b>Status</b> .....	<b>3-3</b>
3.1.1	Device Information .....	3-3
3.1.2	Network Status .....	3-5
3.1.3	Routing Table.....	3-6
3.1.4	Local Log.....	3-6
3.1.5	Traffic Statistics .....	3-7
3.1.6	Cloud Status .....	3-7
3.1.7	Connected Device.....	3-7
<b>3.2</b>	<b>Network</b> .....	<b>3-8</b>
3.2.1	Connection .....	3-8
3.2.2	Cellular Link1 .....	3-9
3.2.3	Cellular Link2.....	3-10
3.2.4	PIN Management .....	3-11
3.2.5	WAN Configurations .....	3-13
3.2.6	LAN Configurations .....	3-15
3.2.7	WLAN Setting.....	3-17
3.2.8	Static Routing Rules.....	3-19
3.2.9	Dynamic DNS.....	3-20
<b>3.3</b>	<b>Firewall</b> .....	<b>3-21</b>
3.3.1	Firewall Settings.....	3-22
3.3.2	DMZ Settings .....	3-22
3.3.3	Port Forward.....	3-23
3.3.4	Port Trigger .....	3-25
3.3.5	URL Filter .....	3-27
3.3.6	MAC Filter .....	3-28
3.3.7	IP Filter .....	3-29
<b>3.4</b>	<b>Interface</b> .....	<b>3-30</b>
3.4.1	RS232 .....	3-30
3.4.2	RS485 .....	3-40
3.4.3	Modbus TCP.....	3-48


3.4.4	Siemens TCP .....	3-51
3.4.5	DI/DO .....	3-53
3.4.6	USB .....	3-55
<b>3.5</b>	<b>System .....</b>	<b>3-56</b>
3.5.1	User Management .....	3-56
3.5.2	Time Zone Configurations .....	3-57
3.5.3	Log Settings .....	3-57
3.5.4	Firmware Upgrade .....	3-59
3.5.5	Backup & Restore .....	3-59
3.5.6	System Reboot .....	3-60
3.5.7	Network Diagnosis .....	3-60
3.5.8	Trouble shooting .....	3-61
3.5.9	Scheduled Jobs .....	3-61
3.5.10	Privilege Management .....	3-63
3.5.11	Event Management .....	3-66
3.5.12	Register Management .....	3-71
<b>3.6</b>	<b>Cloud Service .....</b>	<b>3-72</b>
3.6.1	Cloud Configuration .....	3-72
3.6.2	Proxy Setting .....	3-76
3.6.3	Tunnel Firewall .....	3-77
3.6.4	Cloud Log .....	3-78
<b>3.7</b>	<b>Quick Operation .....</b>	<b>3-79</b>

## 3.1 Status

You can view summary or detailed information on the Device Information, Network Status, Routing Table, Local Log, Traffic Statistics, Cloud Status, and Connected Device.

### 3.1.1 Device Information

This page shows basic information on the Hardware/Software version and Resource Usage Information.

 STATUS > Device Information

#### Hardware Version

---

RTM Version	DX-3021
Release Date	2019-09-04 23:55:06
S/N:	DX30210119270027
Module Model	EC20F
Module Revision	EC20CEFDR02A11M4G

#### Software Version

---

RTM Version	DX-3021 1.5.0.0
Release Date	2019-09-04 23:55:06
Current Version	DX-3021-1.5.0.0-2019-09-06
Upgrade Date	2019-09-06 18:23:30

#### Resource Usage Information

---

CPU Usage:	21%
Total Memory:	251964KB
Memory Used:	124316KB
Memory Usage:	49%

- Hardware Version

Item	Description
<b>RTM Version</b>	Release to manufacturing version of the router
<b>Release Date</b>	Hardware release date
<b>S/N</b>	Serial number of the router
<b>Module Model</b>	Cellular module model name
<b>Module Revision</b>	Cellular module Firmware version

- Software Version

Item	Description
<b>RTM Version</b>	Release to manufacturing version of the software
<b>Release Date</b>	Software release date
<b>Current Version</b>	Version number of the software currently used on the router
<b>Upgrade Date</b>	Upgrade time of the software currently used on the router

- Resource Usage Information

Item	Description
<b>CPU Usage</b>	The CPU usage of current router
<b>Total Memory</b>	The total memory on the router
<b>Memory Used</b>	The memory currently used on the router.
<b>Memory Usage</b>	The current ratio of the router usage

### 3.1.2 Network Status

This page shows basic information about router network.

Connection Status show the active uplink to Internet currently, and detail information about this uplink. Connection priority indicate the order which user appoint to connect to Internet for the router.

Gateway Address, primary DNS, and Secondary DNS.

SMS Status show the default SMS will sent/received by which SIM, and SIM1 and SIM2 status.

LAN Status show the LAN IP Address, four LAN ports status.

WLAN Status show Wi-Fi dongle working detail if user enable it by USB port.

STATUS > Network Status

#### Connection

Reconnect

Connection Type	WAN	WAN Connection Mode	
IP Address	192.168.2.102	Network Mask	<a href="#">255.255.255.0</a>
Gateway Address	192.168.2.1	Primary DNS	<a href="#">218.85.157.99</a>
Secondary DNS	114.114.114.114		

#### Connection Status

Primary Connection	WAN	Enable
Secondary Connection	Cellular Link2	Enable
Tertiary Connection	Disabled	

#### SMS Status

Current SMS SIM	SIM1
SIM1 Status	Cellular module not load or load failed
SIM2 Status	Cellular module not load or load failed

#### LAN

LAN IP Address	192.168.10.50		
LAN1 Status	Down	LAN2 Status	Down
LAN3 Status	Down	LAN4 Status	Down

#### WLAN

Working Mode	Disabled	SSID	N/A
Network Protocol		Channel	N/A

### 3.1.3 Routing Table

This page shows basic information on the routing table, including the Destination, Gateway, Network Mask, HOPS and Network Interface.

[STATUS](#) > Routing Table

Destination	Gateway	Network Mask	HOPS	Network Interface
0.0.0.0	192.168.2.1	0.0.0.0	0	eth0
192.168.2.0	0.0.0.0	<a href="#">255.255.255.0</a>	0	eth0
192.168.10.0	0.0.0.0	<a href="#">255.255.255.0</a>	0	br0
192.168.254.0	0.0.0.0	<a href="#">255.255.255.0</a>	0	br0

### 3.1.4 Local Log

This page shows logs of the router, including the System log, Warning log and the Debug log. You can use the buttons on the right hand side to refresh, clear or download the displayed logs.

[STATUS](#) > Device Logs

#### Log Type

Informative log    Warning log    Debug log

#### Log Content

Refresh

Clear

Download

Timestamp	Content
Sep 6 09:11:06	syslog.info syslogd started: BusyBox v1.22.1
Sep 6 09:11:34	user.info WATCHDOG[1552]: watchdog enabled!
Sep 6 09:11:35	user.info ethcfg[1609]: VLAN enable success
Sep 6 09:11:35	user.err udhcpd: Failure parsing line 5 of /etc/udhcpd.conf
Sep 6 09:11:35	user.err udhcpd: Failure parsing line 6 of /etc/udhcpd.conf
Sep 6 09:11:35	local0.info udhcpd: udhcpd (v0.9.9-pre) started
Sep 6 09:11:35	local0.err udhcpd: max_leases value (254) not sane, setting to 235 instead
Sep 6 09:11:36	user.info gre_app: [GRE_APP] gre_app start ....
Sep 6 09:11:36	user.info gre_app: [GRE] No configuration in grelist1
Sep 6 09:11:36	user.err gre_app: No configuration for gre,exit...
Sep 6 09:11:37	auth.info passwd: Password for root changed by root
Sep 6 09:11:37	authpriv.warn dropbear[1777]: Failed loading /etc/dropbear/dropbear_dss_host_key

PREV

1

2

3

...

10

11

12

NEXT

### 3.1.5 Traffic Statistics

This page shows network traffic information of the router, including the data sent and received over Cellular Link1&Link2, Wi-Fi, WAN and LAN. You can use the buttons on the right-hand side to refresh or clear the traffic information.

[STATUS](#) > Traffic Statistics

Refresh

Clear

#### Traffic Of Cellular Network

Cellular Link1 Sent	0 bytes	Cellular Link1 Received	0 bytes
Cellular Link2 Sent	0 bytes	Cellular Link2 Received	0 bytes
WIFI Sent	0 bytes	WIFI Received	0 bytes
WAN Sent	2654336 bytes	WAN Received	8391035 bytes

#### Traffic Of LAN

Data Sent: 2719891 bytes      Data Received: 589405 bytes

### 3.1.6 Cloud Status

This page shows cloud server information of the router, including the Registration Status, Service Status, and Activated Time.

[STATUS](#) > Cloud Status

#### Cloud Status

Registration Status: Not registered

Service Status: Disabled

Activated Time: N/A

### 3.1.7 Connected Device

This page shows information of the devices connected to the router, including the IP Address, Host Name, MAC Address.

[STATUS](#) > Connected Device

Refresh

ID	IP Address	Host Name	MAC Address	Address Allocated By
1	192.168.5.100	<unknown>	3C:97:0E:DE:7B:25	DHCP

## 3.2 Network

You can set up networks, including the Connection priority, Cellular Link1&Link2, PIN Management, WAN Configurations, LAN Configurations, WLAN Setting, Static Routing Rules and Dynamic DNS.

### 3.2.1 Connection

This page is used for setting up the connection priority. Router provide 3 links to connect to Internet, include cellular network 1&2 and WAN or WLAN, user can appoint the connect order in this page.

🏠 NETWORK > Connection Priority

#### ☰ Connection Priority

Primary Connection	<input type="text" value="WAN"/>
Secondary Connection	<input type="text" value="Disabled"/>
Tertiary Connection	<input type="text" value="Disabled"/>
Auto Detect	<input type="text" value="Cloud Service"/>
Dial Failed To Restart	<input type="text" value="Disabled"/>
Detect Interval	<input type="text" value="60"/> (30~300s)
Default SMS SIM	<input type="text" value="SIM1"/>

Save

Cancel

Description	Default
<b>Primary Connection</b>	
Appoint the first uplink interface for internet connection	WAN
<b>Secondary Connection</b>	
Appoint the second uplink interface for internet connection	Disabled
<b>Tertiary Connection</b>	
Set up the tertiary uplink interface for internet connection.	Disabled
<b>Auto Detect</b>	
Cloud Service test was launch to detect the connection is dropped or not. Another method is ping test. User can disable the detect also.	Cloud Service
<b>Target Address 1</b>	
Set the first IP/domain of the server that program will do a ping testing.	N/A
<b>Target Address 1</b>	

Description	Default
Set the second IP/domain of the server that program will do a ping testing.	N/A
<b>Dial Failure To Restart</b>	
Enable or disable the function if the dial failure will be in the default time to restart device.	Disabled
<b>Detect Interval</b>	
Set the interval time for the network detect	60
<b>Default SMS SIM</b>	
Set up the default SIM which be use to sent the SMS when SIM1 and SIM2 both are inactive.	SIM1

### 3.2.2 Cellular Link1

This page is used for setting up the Cellular Network for SIM1.

[🏠 NETWORK](#) > Cellular Link1

#### ☰ Cellular Link1

Working Mode	<input type="text" value="Manual"/>
Dial Type	<input type="text" value="DHCP"/>
User Name	<input type="text"/>
Password	<input type="text"/>
APN	<input type="text"/>
Authorization Mode	<input type="text" value="Auto"/>
Dial-Up Number	<input type="text" value="*99#(UMTS/3G/3.5G)"/>
MTU	<input type="text" value="1492"/>



Description	Default
<b>Working Mode</b>	
Select Auto or Others for the Operator from the dropdown list. <ul style="list-style-type: none"> <li><b>Auto:</b> the system will detect the operator from the inserted SIM card and set up the parameter accordingly.</li> <li><b>Manual:</b> users can set up the parameter manually.</li> </ul>	AUTO
<b>Dial Type</b>	
For 4G product, dial type only support DHCP currently.	DHCP

3

Description	Default
<b>User Name</b>	
This name is provided by the operator. When “Auto” is selected, the system will set the name up automatically and users cannot change the setting.	N/A
<b>Password</b>	
This password is provided by the operator. When “Auto” is selected, the system will set the password up automatically and users cannot change the setting.	N/A
<b>APN</b>	
This Access Point Name is provided by the operator.	N/A
<b>Authorization Mod</b>	
Options are “Auto”, “PAP” and “CHAP”.	Auto
<b>Dial-Up Number</b>	
This number is provided by the operator.	*99#
<b>MTU</b>	
Maximum Transmission Unit is the largest packet that can be transmitted over packet based networks.	1492

### 3.2.3 Cellular Link2

This page is used for setting up the Cellular Network for SIM2.

[🏠 NETWORK](#) > Cellular Link2

#### ☰ Cellular Link2

Working Mode	<input type="text" value="Manual"/>
Dial Type	<input type="text" value="DHCP"/>
User Name	<input type="text"/>
Password	<input type="text"/>
APN	<input type="text"/>
Authorization Mode	<input type="text" value="Auto"/>
Dial-Up Number	<input type="text" value="*99#(UMTS/3G/3.5G)"/>
MTU	<input type="text" value="1492"/>

Description	Default
<b>Working Mode</b>	
Select Auto or Others for the Operator from the dropdown list. <ul style="list-style-type: none"> <li><b>Auto:</b> the system will detect the operator from the inserted SIM card and set up the parameter accordingly.</li> <li><b>Manual:</b> users can set up the parameter manually.</li> </ul>	AUTO
<b>Dial Type</b>	
For 4G product, dial type only support DHCP currently.	DHCP
<b>User Name</b>	
This name is provided by the operator. When “Auto” is selected, the system will set the name up automatically and users cannot change the setting.	N/A
<b>Password</b>	
This password is provided by the operator. When “Auto” is selected, the system will set the password up automatically and users cannot change the setting.	N/A
<b>APN</b>	
This Access Point Name is provided by the operator.	N/A
<b>Authorization Mod</b>	
Options are “Auto”, “PAP” and “CHAP”.	Auto
<b>Dial-Up Number</b>	
This number is provided by the operator.	*99#
<b>MTU</b>	
Maximum Transmission Unit is the largest packet that can be transmitted over packet based networks.	1492

### 3.2.4 PIN Management

The SIM card operator set the PIN LOCK can use this feature to view or unlock PIN LOCK

- If the SIM card operator does not set the PIN LOCK, it will show “SIM card normal” ; If a SIM card was not inserted into this SIM slot, or the cellular module work on another SIM slot, it will show “Inactive” .

🏠 NETWORK > PIN Management

☰ SIM1 PIN Management

---

SIM card status                      SIM card normal

☰ SIM2 PIN Management

---

SIM card status                      Inactive

- If the SIM card operator has set the PIN LOCK as shown below

🏠 NETWORK > PIN Management

☰ SIM1 PIN Management

---

SIM card status                      PIN locked

Remaining attempts                3

PIN                                       (4-12,number)

Remember my PIN                     (Use this PIN to verify in next reboot)

Save

Cancel

☰ SIM2 PIN Management

---

SIM card status                      Inactive

- The verification fails, it will display as below.

**!** PIN verify failed, please input correct PIN code !

PIN Management    display the status of SIM card, and set PIN code if need

🏠 NETWORK > PIN Management

---

**☰ SIM1 PIN Management**

---

SIM card status                      PIN locked

Remaining attempts                  1

PIN                                       (4-12,number)

Remember my PIN                     (Use this PIN to verify in next reboot)

---

**☰ SIM2 PIN Management**

---

SIM card status                      Inactive

- The verification passes, it will display as below.

**!** Success !

PIN Management    display the status of SIM card, and set PIN code if need

🏠 NETWORK > PIN Management

---

**☰ SIM1 PIN Management**

---

SIM card status                      SIM card normal

---

**☰ SIM2 PIN Management**

---

SIM card status                      Inactive

### Notice



- If you enter the wrong PIN three times, your SIM card will become locked.
- Once SIM card is blocked, you need PUK code to unlock it or find operator's help.

### 3.2.5 WAN Configurations

This page is used for setting up the WAN, including the IP address, network mask, gateway and DNS.

🏠 NETWORK > WAN Configurations

☰ WAN Configurations

Connection Mode

IP Allocation Method

Packet MTU

Retrieve DNS Address By:

☰ WAN Configurations

Connection Mode

IP Allocation Method

IP Address

Network Mask

Gateway Address

Packet MTU

Retrieve DNS Address By:

Primary DNS

Secondary DNS

Description	Default
<b>Connection Mode</b>	
DX router can connect to the internet via the WAN port with a Dynamic IP or Static IP.	DHCP

3

Description	Default
<ul style="list-style-type: none"> <li>DHCP: DX router obtain an IP address automatically from DHCP Server.</li> <li>STATIC: Manually set up the IP address for DX router.</li> </ul>	
<b>IP Allocation Method</b>	
<p>The IP Allocation Method is the same as the WAN Connection Mode that you have set. You can apply to different option by modifying the Connection Mode.</p> <ul style="list-style-type: none"> <li>Dynamic: Dynamic Host Configuration Protocol (DHCP) allows you to obtain an IP address automatically from your router.</li> <li>Manual: Manually set up the IP address (Static).</li> </ul>	DHCP
<b>IP Address</b>	
Set up an IP address for your device to connect to the internet via the WAN port. It's configurable when the mode is set to Static.	N/A
<b>Network Mask</b>	
Set up the WAN network mask. It's configurable when the mode is set to Static.	N/A
<b>Gateway Address</b>	
Set up the gateway address. It's configurable when the mode is set to Static.	N/A
<b>MTU</b>	
Maximum Transmission Unit is the largest packet that can be transmitted over packet based networks.	1500
<b>Retrieve DNS Address By</b>	
<p>DNS address can be retrieved by DHCP setup or manually set. When connection mode is "STATIC", user must manual assign the DNS address.</p> <ul style="list-style-type: none"> <li>Dynamic: DX router obtain a DNS address automatically from DHCP router.</li> <li>Manual: Manually set up the DNS address.</li> </ul>	Dynamic
<b>Primary DNS</b>	
Set up the primary DNS. It's configurable when the mode is set to Static.	N/A
<b>Secondary DNS</b>	
Set up the secondary DNS. It's configurable when the mode is set to Static.	N/A

### 3.2.6 LAN Configurations

This page is used for setting up the LAN, including the Device Name, IP Address, Network Mask, and DHCP Server.

🏠 NETWORK > LAN

☰ LAN Configurations

3

IP Address

Network Mask

DHCP Server

Address Lease Time

First IP Address

Last IP Address

STP

PHY Auto Reset

Description	Default
<b>IP Address</b>	
Set up an IP address for your device.	192.168.5.5
<b>Network Mask</b>	
Set up the LAN network mask.	255.255.255.0
<b>DHCP Server</b>	
If DX router uses DHCP to assign IP addresses automatically on your network, you can specify the IP address range and lease time for the clients on your network. Once the DX router have bound the DIACloud and enabled the DIACloud DHCP, the DHCP in DX router will be disabled automatically.	Enable
<b>Address Lease Time</b>	
To set up the address lease time so that a client doesn't hold an IP address indefinitely. It allows for a mechanism to gracefully reuse DHCP addresses. Options here are 1 to 3 days.	One day
<b>First IP Address</b>	
To increase the number of addresses available to clients, you can change the Start Address.	192.168.1.100
<b>Last IP Address</b>	
To increase the number of addresses available to clients, you can change the End Address.	192.168.1.200

Description	Default
<b>STP</b>	
STP is a network protocol that builds a logical loop-free topology for Ethernet networks. The basic function of STP is to prevent bridge loops and the broadcast radiation that results from them. If this STP is enabled, the traffic usage will increase about 15Mbit in 24 hours.	Disable
<b>PHY Auto Reset</b>	
Disable or enable the auto reset function when LAN IP has been changed.	Disable

### 3.2.7 WLAN Setting

DX-3021L9 supports Wi-Fi dongle via USB interface. After setup the WLAN in this page, Wi-Fi will be an uplink option also.

Currently, only product DWA-131 of D-Link company is be support. If you want to enable Wi-Fi dongle function, please insert the DWA-131 into USB and then set the working mode to station.

[🏠 NETWORK > WLAN Setting](#)

#### ☰ WLAN Setting

Working Mode

Station ▾

Scan

#### ☰ Security Setting

Network Name(SSID)

Authentication Method

Open System ▾

Connection Mode

Automatic IP ▾

DNS Access Method

Automatic ▾

Save

Cancel

Click "Scan" button to show the available Wi-Fi AP list.

WLAN Setting

Working Mode

Station

Select SSID

Select	Network Name(SSID)	RSSI (DBm)	MAC(BSSID)	Channel	Encryption
<input type="radio"/>	GUI-TEST	-54	a0:63:91:6a:55:a4	8	[WPA2-PSK-CCMP][ESS]
<input type="radio"/>	2019	-56	42:37:86:09:29:9e	6	[WPA2-PSK-CCMP][ESS]
<input type="radio"/>	SOAP_0909	-62	26:14:07:77:2a:20	2	[WPA2-PSK-CCMP][ESS]
<input type="radio"/>	aecho_0909	-60	26:a4:07:9a:93:30	4	[WPA2-PSK-CCMP][ESS]
<input type="radio"/>	8	-54	08:02:8e:93:de:94	8	[ESS]
<input type="radio"/>	NETGEAR-Guest	-58	46:37:86:09:29:9e	6	[ESS]
<input type="radio"/>	NETGEAR-Guest	-60	1e:14:4b:22:3a:30	11	[ESS]
<input type="radio"/>	NETGEAR-Guest	-62	2a:18:07:11:2a:f0	6	[ESS]

3

Description	Default
<b>Working Mode</b>	
Set up Wi-Fi dongle working mode, currently support station only.	Disable
<b>Scan</b>	
Scan the available AP list.	
<b>Network Name</b>	
Specify the AP SSID which you intend to connect.	
<b>Authentication Method</b>	
Set up the AP security mode	
<b>WPA Encryption</b>	
Set up the encryption algorithm.	
<b>WPA Pre-Shared Key</b>	
Setup the password to connect to the AP.	
<b>Connection Mode</b>	
Set up the method how station get IP. - Automatic IP: AP assign the IP to station automatic -Static IP: Manual appoint the IP address, Subnet Mask, Gateway and MTU	Automatic IP
<b>IP Address</b>	
Setup the IP address for station	
<b>Subnet Mask</b>	
Setup the subnet mask for station	
<b>Default Gateway</b>	

Description	Default
Setup the gateway for station	
<b>DNS Access Method</b>	
Set up the method how station get DNS information. -Automatic: Get DNS information from AP. -Static: Manual appoint the DNS server, include primary and secondary DNS Server	Automatic
<b>Primary DNS</b>	
Setup the primary DNS server	
<b>Secondary DNS</b>	
Setup the secondary DNS server	

### 3.2.8 Static Routing Rules

This page is used for setting up the Static Routing, including the Rule Name, Network Interface, Enabled, Destination IP, Network Mask, Gateway Address and Metric. Click the "Add A Rule" to add static routing rules.

[🏠 NETWORK > Static Routing Rules](#)

Add A Rule

ID	Enabled	Name	Destination	Gateway	Network Interface
----	---------	------	-------------	---------	-------------------

After clicking the "Add A Rule" , you will see the following page.

[🏠 NETWORK > Static Routing Rules](#)

#### ☰ Add A Rule

Rule Name

Network Interface

Enabled

Destination IP

Network Mask

Gateway Address

Metric  (2~15)

Save Back

Description	Default
-------------	---------

Description	Default
<b>Rule Name</b>	
Set up a name for your rule. The name shall be composed of letters, numbers and underline, starting with a letter or number. The maximum string length is 32 bytes.	N/A
<b>Network Interface</b>	
For a specific network destination address, select the network interface of the router for sending data package. Options are LAN and WAN.	WAN
<b>Enabled</b>	
Activate the static routing functionality.	Yes
<b>Destination IP</b>	
Set up a Destination IP address for your device.	N/A
<b>Network Mask</b>	
Set up the subnet mask corresponding to the destination network segment. If the final destination of the routing is a single host, please type in 255.255.255.255.	N/A
<b>Gateway Address</b>	
Set up the next-hop routing address.	N/A
<b>Metric</b>	
Set up the hops. The number of hops that are passed for reaching the destination address. One hop indicates passing one router passed. The range is 2~15.	2

### 3.2.9 Dynamic DNS

This page is used for setting up the Dynamic DNS Settings, including the Dynamic DNS, Service Provider, Domain User Name, Password, and the Refreshing Interval.

🏠 NETWORK > Dynamic DNS

### ☰ Dynamic DNS Settings

Dynamic DNS	Disable ▾
Service Provider	www.DynDns.org ▾
Domain	<input type="text"/>
User Name	<input type="text"/>
Password	<input type="password"/>
Refreshing Interval	86400 (120~86400s)

Save

Cancel

Description	Default
<b>Dynamic DNS</b>	
Dynamic Host Configuration Protocol allows you to obtain an IP address automatically from your router. You can enable or disable this functionality.	Disable
<b>Service Provider</b>	
Select the dynamic domain service provider. Options are www.DynDNS.org and www.NOIP.com	www.DynDns.org
<b>Domain</b>	
The domain applied for to the corresponding dynamic domain service provider.	N/A
<b>User Name</b>	
The name of the user registered at the corresponding dynamic domain service provider.	N/A
<b>Password</b>	
The corresponding password to the registered user.	N/A
<b>Refreshing Interval</b>	
Set up the time for the router to update its public network IP from the dynamic domain service provider. The value range is 120~86400 sec.	86400

## 3.3 Firewall

You can set up firewall configurations, including the Firewall Settings, DMZ Settings, Port Forward, Port Trigger, URL Filter, MAC Filter, and IP Filter.

### 3.3.1 Firewall Settings

This page is used for setting up the basic firewall settings, including the SPI firewall switch, WAN Ping response, LAN SSH function and WAN SSH.

[🏠 FIREWALL](#) > Firewall Settings

#### ☰ Basic Firewall Settings

Firewall	<input type="text" value="Enable"/>
WAN Ping	<input type="text" value="Not responded"/>
LAN SSH	<input type="text" value="Enable"/>
WAN SSH	<input type="text" value="Disable"/>
Remote Access Port	<input type="checkbox"/> 80 <input type="checkbox"/> 502



Description	Default
<b>Firewall</b>	
The SPI Firewall keeps track of the state of network connections travelling across it, protecting your Internet connection against Internet threats and Denial of Service (DoS).	Enable
<b>WAN Ping</b>	
It creates a filter that your router not to respond to Ping command and prevents other users on the internet from pinging your pc and gaining your IP address.	Not responded
<b>LAN SSH</b>	
Set up whether to allow LAN end to connect with the router via SSH.	Enable
<b>WAN SSH</b>	
Set up whether to allow WAN end to connect with the router via SSH.	Disable
<b>Remote Access Port</b>	
If checked, the user is allowed to access port 80 or port 502 through the IP of WAN, port 80 is for access the configuration page of the device. Port 502 is the port of Modbus TCP Server.	Uncheck

### 3.3.2 DMZ Settings

This page is used for setting up the DMZ server.

[FIREWALL](#) > DMZ Settings

### DMZ Settings

DMZ Server

DMZ Host IP Address

Save

Cancel

Description	Default
<b>DMZ Server</b>	
Demilitarized zone (DMZ) is a special segment of the local network reserved for servers accessible from the Internet, adding an additional layer of security.	Disable
<b>DMZ Host IP Address</b>	
Set up the IP address for the DMZ host.	N/A

### 3.3.3 Port Forward

This page is used for setting up the port forward, including configuring the Network Services, Service Name, Protocol, Public Port, Server Port, and Server IP Address.

Click the "Add A Port Forward Rule" to add port forwarding entries to the router.

[FIREWALL](#) > Port Forward

Add A Port Forward Rule

ID	Service Name	Protocol	Public Port	Server Port	Server IP Address
----	--------------	----------	-------------	-------------	-------------------

After clicking the "Add A Port Forward Rule" , you will see the following page.

☰ Add A Portforward Rule

Network Services

Service Name

Protocol

Public Port   (1~65534)

Server Port   (1~65534)

Server IP Address 192.168.1.

3

Description	Default
<b>Network Services</b>	
Select the common network services. Refer to the following common service list for optional values.	Customized
<b>Service Name</b>	
Set up the service name for port forwarding. The name is composed of letters, numbers and underline, starting with a letter or number. The maximum string length is 32 bytes.	N/A
<b>Protocol</b>	
Set up the protocol type for port forwarding.	TCP/UDP
<b>Public Port</b>	
Set up the public port for port forwarding. The port range is 1~65534. A Public port should be less than or equal to the server port.	Single Port
<b>Server Port</b>	
Set up the server port for port forwarding. The port range is 1~65534. A server port should be greater than or equal to the public port. When the public port is set to a Single Port, the server port can only be set to a Single Port. When the public port is set to a Port Range, the server port can be set to a Single Port or a Port Range. And when the public port is set to a single port, all the port will be forwarded to ONE single port. Examples of different port forwarding settings: 1:1 Public Port <input type="text" value="Single Port"/> <input type="text" value="1001"/> (1~65534) Server Port <input type="text" value="Single Port"/> <input type="text" value="80"/> (1~65534)	Single Port

Description		Default
N:1		
Public Port	A Port Range ▼ 1001 - 1008 (1~65534)	
Server Port	Single Port ▼ 80 (1~65534)	
N:N		
Public Port	A Port Range ▼ 1001 - 1008 (1~65534)	
Server Port	A Port Range ▼ 1001 - 1008 (1~65534)	
<b>Server IP Address</b>		
Set up the server IP address that applies to the port mapping rule.		192.168.1.*

Common Service List for Port Forwarding			
Service name	Protocol	Starting Port	Ending Port
Customized	TCP, UDP, TCP/UDP	1~65534	1~65534
FTP	TCP	20	21
HTTP	TCP	80	80
ICUII	TCP	23566	23566
IP_PHONE	TCP	6670	6670
NetMeeting	TCP	1720	1720
News	TCP	119	119
PPTP	TCP/UDP	1723	1723
Telnet	TCP	23	23
Quakell/III	TCP/UDP	27960	27960
Real-Audio	TCP	6970	7170

### 3.3.4 Port Trigger

This page is used for setting up the port trigger, including configuring the Service Name, Service User, Service Type, Trigger Port, Protocol Role, Begin Port, End Port, and Status.

Port triggering is port forwarding with an on/off switch for the ports that have been forwarded. Have data flow out of a trigger port or not by enabling or disabling this functionality. Set up the time for the Port Trigger Timeout and click "Save" to save the setting.

Click the "Add A Trigger Rule" to add port trigger entries to the router.

[🏠 FIREWALL > Port Trigger](#)

Port Trigger  Port Trigger Timeout  Minute

ID	Service Name	Service Type	Inbound Connection	Service User	Status
----	--------------	--------------	--------------------	--------------	--------

3

After clicking the "Add A Trigger Rule", you will see the following page.

[🏠 FIREWALL > Port Trigger](#)

**Add A Trigger Rule**

Service Name

Service User

Service Type

Trigger Port  (1~65534)

**Inbound Connection**

Protocol Role

Begin Port  (1~65534)

End Port  (1~65534)

Status

Description	Default
<b>Service Name</b>	
Set up the service name for port triggering. The name is composed of letters, numbers and underline, starting with a letter or number. The maximum string length is 32 bytes.	N/A
<b>Service User</b>	
Select the service user to apply the port triggering rule.	Any Address
<b>Service Type</b>	
Set up the protocol type for port triggering.	TCP

Description	Default
<b>Triggering Port</b>	
Set up the triggering port. The port range is 1~65534.	N/A
<b>Protocol Role</b>	
Set up the protocol type for the inbound connection.	TCP/UDP
<b>Begin port</b>	
Set up the starting port for the inbound connection. The port range is 1~65534.	N/A
<b>End Port</b>	
Set up the ending port for the inbound connection. The port range is 1~65534.	N/A
<b>Status</b>	
Enable/disable the port triggering functionality.	Disabled

### 3.3.5 URL Filter

This page is used for setting up the URL Filter, including configuring the URL Address, LAN IP Address and Status.

URL Filter is used to block particular website from the local network. Select Enable/Disable to activate/deactivate this functionality. Click the "Add An URL Address" to block the URL.

[🏠 FIREWALL > URL Filter](#)

URL Address Filter

ID	URL Address	LAN IP Address	Status
----	-------------	----------------	--------

After clicking the "Add An URL Address", you will see the following page.

[🏠 FIREWALL > URL Filter](#)

#### ☰ Add URL

URL Address

LAN IP Address

Status

Description	Default
<b>URL Address</b>	
Manually input the URL address that you'd like to block, for example	N/A

Description	Default
www.baidu.com.	
<b>LAN IP Address</b>	
Set up the LAN IP address that you'd like to block. Options are "Any Address", "Single Address" and "Address Range".	Any Address
<b>Status</b>	
Enable/disable the URL Filter functionality.	Enabled

### 3.3.6 MAC Filter

This page is used for setting up the MAC Filter, including configuring the MAC Address, Device Name and Status.

MAC Filter is used to block particular MAC address from the local network. Select Enable/Disable to activate/deactivate this functionality. Click the "Add A MAC Address" to block the MAC Address.

[🏠 FIREWALL > MAC Filter](#)

MAC Filter

ID	MAC Address	Device Name	Status
----	-------------	-------------	--------

After clicking the "Add A MAC Address", you will see the following page.

[🏠 FIREWALL > MAC Filter](#)

#### ☰ Add A MAC Address

MAC Address

Device Name

Status

Description	Default
<b>MAC Address</b>	
Manually input the MAC address that you'd like to block.	N/A
<b>Device Name</b>	
Set up the device name corresponding to the set MAC address.	N/A
<b>Status</b>	
Enable/disable the MAC Filter functionality.	Enabled

### 3.3.7 IP Filter

This page is used for setting up the IP Filter, including configuring the Source IP, Source Port, Destination IP, Destination Port, Protocol and Status.

IP Filter is used to block particular IP address from the local network. Select Enable/Disable to activate/deactivate this functionality. Click the "Add An IP Address" to block the IP Address.

[🏠 FIREWALL > IP Filter](#)

IP Filter

ID	Source IP Address Range	Source Port Range	Range Of Destination IP Address	Range Of Destination Port	Protocol	Status
----	-------------------------	-------------------	---------------------------------	---------------------------	----------	--------

After clicking the "Add An IP Address" , you will see the following page.

[🏠 FIREWALL > IP Filter](#)

#### ☰ Add An IP Address

Source IP

Source Port

Destination IP

Destination Port

Protocol

Status

Description	Default
<b>Source IP</b>	
Set up the source IP.	Any Address
<b>Source Port</b>	
Set up the source port where the datagram came from.	Any port
<b>Destination IP</b>	
Set up the destination IP.	Any Address
<b>Destination Port</b>	
Set up the destination port where the datagram is going to.	Any port
<b>Protocol</b>	
Set up the protocol type for the IP Filter.	TCP/UDP
<b>Status</b>	

Description	Default
Enable/disable the URL Filter functionality.	Enabled

## 3.4 Interface

You can set up the interface configurations, including the RS232, RS485, Modbus TCP, DI/DO and USB interface.

### 3.4.1 RS232

RS232 (Recommended Standard - 232) is a telecommunication standard for binary serial communications between devices. It supports seven work modes, include: Transparent mode, Slave mode, Master mode, Serial Server-TCP Server, Serial Server-TCP Client, Serial Server-UDP Client and MC Master mode.

You can set up the configurations for RS232, including Baud Rate, Data Bits, Stop Bits, Parity Bits and Flow Control.

Description	Default
<b>Working Mode</b>	
Select the working mode for the current active serial port.	Close
<b>Baud Rate</b>	
Set up the baud rate for the serial port. Options are 2400, 4800, 9600, 19200, 38400, 57600 and 115200.	9600
<b>Data Bits</b>	
Set up the data bits for the serial port. Options are 7 and 8. It must be set to 8 when communication mode is Modbus RTU.	8
<b>Stop Bits</b>	
Set up the stop bits for the serial port. Options are 1 and 2.	1
<b>Parity Bits</b>	
Set up the parity bits for the serial port. Options are None, Odd and Even.	None
<b>Flow Control</b>	
Set up the flow control. Options are None, XON, XOFF, RTS, and CTS.	None

- **Transparent mode**

This mode is suitable for uploading and downloading data remotely via the serial port.

### RS232

Working Mode	Transparent mode
Baud Rate	9600
Data Bits	8
Stop Bits	1
Parity Bits	None
Flow Control	None

Save

Cancel

- Slave mode**

This mode is suitable for the PLC to perform the read/ write tasks on the open register of the DX Router.

### RS232

Working Mode	Slave mode
Baud Rate	9600
Data Bits	8
Stop Bits	1
Parity Bits	None
Flow Control	None
Slave ID	1
Mode	Modbus RTU
Timeout	200 (ms)

Save

Cancel

Description	Default
<b>Slave ID</b>	
Set up the MODBUS ID. The value is between 1 and 247.	1
<b>Mode</b>	
Set up the communication mode for the device. Device support Modbus RTU and Modbus ASCII	Modbus RTU

Description	Default
<b>Timeout</b>	
Set up the timeout timer from 200ms to 5000ms. If the set value is out of range, it will be automatically changed to its maximum or minimum value.	200ms

- Master mode**

This mode is suitable for the DX router to perform the read/write tasks on the open register of the PLC.

**RS232**

**3**

Working Mode:

Baud Rate:

Data Bits:

Stop Bits:

Parity Bits:

Flow Control:

Slave ID:

Mode:

Timeout:  (ms)

**Read/Write Configuration**

Scan Interval:  (ms)

When communicate with PLC of Delta, the starting address can be set as the internal register number. For example, input 0 for register D0.

The acceptable address range of this device is: \$0-\$1535 or \$2048-\$4095 or M0-M511.

Row Number	Read/Write	Slave ID	Controller	Address Type	Slave Starting Address	Bit	Device Starting Address	Length (1-123)	Operation
1	Read/Write	1	Delta DVP PLC	D		0	\$		<input type="button" value="+"/> <input type="button" value="-"/>

Description	Default
<b>Slave ID</b>	
Set up the MODBUS ID for DX router. Invalid in Master mode.	1
<b>Mode</b>	
Set up the communication mode for the device. Device support Modbus RTU	Modbus RTU

Description	Default
and Modbus ASCII.	
<b>Timeout</b>	
Set up the timeout timer from 200ms to 5000ms. If the set value is out of range, it will be automatically changed to its maximum or minimum value.	200ms
<b>Scan Interval</b>	
Set up the time for scan interval, ranging from 50ms to 60000ms.	30000ms
<b>Add Mappings</b>	
Click the button to add a new mapping;	N/A
<b>Delete All Mappings</b>	
Delete all mappings of RS-232 master mode	N/A
<b>Export Configure List</b>	
Export the configure list to the file and save to local PC	N/A
<b>Import Configure List</b>	
Open local file and import the configure list	N/A
<b>Read/Write</b>	
<p>Set up the access permissions for the mapped register address;</p> <ul style="list-style-type: none"> <li>• <b>Read-only:</b> The device regular read data from appointed registers in the slave, but will not update the data to the slave</li> <li>• <b>Write-only:</b> The device updates the data to the slave when the registers values were changed, but will not read the data from the slave</li> <li>• <b>Read/write:</b> The device regular read data from appointed registers in the slave, will update the data to the slave when the registers values are changed.</li> </ul>	Read/Write
<b>Slave ID</b>	
Set up the corresponding slave communication port. The value is between 1 and 247.	1
<b>Controller</b>	
<p>In master mode, device types options are:</p> <ul style="list-style-type: none"> <li>• <b>Delta PLC:</b> Use this option for Delta DVP / AH / AS series PLCs</li> <li>• <b>Other:</b> Use this option for non-Delta PLCs. HEX means hexadecimal address; DEC means decimal address.</li> </ul>	Delta DVP PLC
<b>Address Type</b>	
<p>In master mode, it depending on the selected controller type change:</p> <ul style="list-style-type: none"> <li>• <b>Delta PLC:</b> The address type is D/M/S/X/Y; D for word type, M/S/X/Y for bit type</li> <li>• <b>Other:</b> The address type is 0x/1x/3x/4x/Swap: <ul style="list-style-type: none"> <li>-0x: Read or write coil data (Modbus function code: 01/05)</li> <li>-1x: Read discrete inputs (Modbus function code: 02)</li> </ul> </li> </ul>	D

Description	Default
-3x: Read or write input registers (Modbus function code: 04) -4x: Read or write holding registers (Modbus function code: 03/16) -Swap: Read or write holding registers, transposition store to DX router's register in pairs	
<b>Slave Starting Address (decimal)</b>	
Set up the slave starting address for read/write the registers in a PLC. <ul style="list-style-type: none"> <li><b>Delta PLC:</b> Enter the internal D register number. If you need to read / write D0, please enter 0 here.</li> <li><b>Other:</b> Enter the Hexadecimal or Decimal actual address. For example: Holding Register: 400100, take 0100 (decimal) that is 64 (hex).</li> </ul>	N/A
<b>Bit</b>	
For X/Y type data of Delta AH/AS series, the address format is x1.x2, then x1 input to slave starting address column, x2 input to this column.	N/A
<b>Device Starting Address (decimal)</b>	
Set up the device starting address (decimal, input range is from \$2048 to \$4095 for word type data, input range is from M0 to M511 for bit type data). \$ or M specifies that the match must start at the beginning of a Device Starting Address.	N/A
<b>Length (1-123)</b>	
Set up the number of the continuous address followed by the default mapped address will be read or write. Input range is from 1 to 64.	N/A
<b>Operation</b>	
Click the +/- button to add mapping or delete mapping.	N/A
<b>Edit</b>	
Click an item of register mapping forms that can be edited.	N/A

- Serial Server-TCP Server**

DX router act as a TCP Server, when received the packet from client, parse the packet and transmit to RS-232.

## RS232

Working Mode	<input type="text" value="Serial Server - TCP Server"/>
Baud Rate	<input type="text" value="9600"/>
Data Bits	<input type="text" value="8"/>
Stop Bits	<input type="text" value="1"/>
Parity Bits	<input type="text" value="None"/>
Flow Control	<input type="text" value="None"/>
TCP Alive Check Time	<input type="text" value="7"/> (0-99 min)
Listening Port	<input type="text" value="16000"/>
Packing Length	<input type="text" value="0"/> (0-1024)
Force Transmit	<input type="text" value="0"/> (0-65535 ms)

Save

Cancel

Description	Default
<b>TCP Alive Check Time</b>	
Setting how long TCP activity keep idle, then the TCP connection will be drop. Input range is from 0 to 99 minutes. 0 means will never drop it.	7
<b>Listening Port</b>	
Set up the listening port in server.	16000
<b>Packing Length</b>	
Setting the length of packet, packet will be transmitted when the size reaches the values. Input range is from 0 to 1024 byte. 0 means will transmit at once when received the data.	0
<b>Force Transmit</b>	
Setting how long the program waiting, then transmit the packet. Input range is from 0 to 65535 millisecond. 0 means will never force to transmit.	0

- **Serial Server-TCP Client**

DX router act as a TCP Client, packet RS-232 data and transmit to Server by TCP protocol.

**RS232**

**Working Mode**

**Baud Rate**

**Data Bits**

**Stop Bits**

**Parity Bits**

**Flow Control**

**TCP Alive Check Time**  (0-99 min)

**Destination IP Address1**  **Port**

**Destination IP Address2**  **Port**

**Destination IP Address3**  **Port**

**Destination IP Address4**  **Port**

**Designated Local Port1**

**Designated Local Port2**

**Designated Local Port3**

**Designated Local Port4**

**Packing Length**  (0-1024)

**Force Transmit**  (0-65535 ms)

Description	Default
<b>TCP Alive Check Time</b>	
Setting how long TCP activity keep idle, then the TCP connection will be drop. Input range is from 0 to 99 minutes. 0 means will never drop it.	7
<b>Destination IP address and Port</b>	
Setting the serial Server IP address and listening port. You can set 4 different destination at most.	
<b>Designated local port</b>	
Set up the local port for transmission.	14001~14004
<b>Packing Length</b>	

Description	Default
Setting the length of packet, packet will be transmitted when the size reaches the values. Input range is from 0 to 1024 byte. 0 means will transmit at once when received the data.	0
<b>Force Transmit</b>	
Setting how long the program waiting, then transmit the packet. Input range is from 0 to 65535 millisecond. 0 means will never force to transmit.	0

• **Serial Server-UDP Client**

DX router act as a UDP Client, packet RS-232 data and transmit to Server by UDP protocol.



 **RS232**

Working Mode:

Baud Rate:

Data Bits:

Stop Bits:

Parity Bits:

Flow Control:

	Begin	End	port
Destination IP Address1	<input type="text"/>	<input type="text"/>	<input type="text" value="6001"/>
Destination IP Address2	<input type="text"/>	<input type="text"/>	<input type="text" value="6002"/>
Destination IP Address3	<input type="text"/>	<input type="text"/>	<input type="text" value="6003"/>
Destination IP Address4	<input type="text"/>	<input type="text"/>	<input type="text" value="6004"/>

Local Listen Port:

Packing Length:  (0-1024)

Force Transmit:  (0-65535 ms)

Description	Default
<b>Destination IP address and Port</b>	
Setting the serial Server IP address and listening port. You can set 4 groups destination at most. For each group, it allows 99 IP address max.	

Description	Default
<b>Local listen port</b>	
Set up the local port for transmission.	15000
<b>Packing Length</b>	
Setting the length of packet, packet will be transmitted when the size reaches the values. Input range is from 0 to 1024 byte. 0 means will transmit at once when received the data.	0
<b>Force Transmit</b>	
Setting how long the program waiting, then transmit the packet. Input range is from 0 to 65535 millisecond. 0 means will never force to transmit.	0

3

• **MC master mode**

This mode is suitable for the DX router to perform the read/write tasks on the open register of the MITSUBISHI FX series PLC via serial port.

☰ **RS232**

Working Mode

Baud Rate

Data Bits

Stop Bits

Parity Bits

Flow Control

Slave ID

Mode

Timeout  (ms)

**Read/Write Configuration**

Scan Interval  (ms)

The acceptable address range of this device is: \$0-\$1535 or \$2048-\$4095 or M0-M511.

Row Number	Read/Write	Slave ID	Controller	Address Type	Slave Starting Address	Bit	Device Starting Address	Length (1-64)	Operation
1	Read/Write <input type="text" value="v"/>	0	MITSUBISHI PLC <input type="text" value="v"/>	D <input type="text" value="v"/>		0	\$		<input type="button" value="+"/> <input type="button" value="-"/>

Description	Default
<b>Slave ID</b>	
Set up the MODBUS ID for DX router. Invalid in MC Master mode.	0
<b>Mode</b>	
It's fixed to "MC ASCII" in MC master mode.	Modbus RTU
<b>Timeout</b>	
Set up the timeout timer from 200ms to 5000ms. If the set value is out of range, it will be automatically changed to its maximum or minimum value.	200ms
<b>Scan Interval</b>	
Set up the time for scan interval, ranging from 50ms to 60000ms.	30000ms
<b>Add Mappings</b>	
Click the button to add a new mapping;	N/A
<b>Delete All Mappings</b>	
Delete all mappings of RS-232 MC master mode	N/A
<b>Export Configure List</b>	
Export the configure list to the file and save to local PC	N/A
<b>Import Configure List</b>	
Open local file and import the configure list	N/A
<b>Read/Write</b>	
<p>Set up the access permissions for the mapped register address;</p> <ul style="list-style-type: none"> <li>• <b>Read-only:</b> The device regular read data from appointed registers in the slave, but will not update the data to the slave</li> <li>• <b>Write-only:</b> The device updates the data to the slave when the registers values were changed, but will not read the data from the slave</li> <li>• <b>Read/write:</b> The device regular read data from appointed registers in the slave, will update the data to the slave when the registers values are changed.</li> </ul>	Read/Write
<b>Slave ID</b>	
It's fixed to 0 in MC master mode.	0
<b>Controller</b>	
It's fixed to "MITSUBISHI PLC" in MC master mode.	Delta DVP PLC
<b>Address Type</b>	
The address type is D/M/X/Y; D for word type, M/X/Y for bit type	D
<b>Slave Starting Address (decimal)</b>	
Set up the slave starting address for read/write the registers in MITSUBISHI PLC.	N/A
<b>Bit</b>	

Description	Default
It's invalid in MC master mode.	
<b>Device Starting Address (decimal)</b>	
Set up the device starting address (decimal, input range is from \$2048 to \$4095 for word type data, input range is from M0 to M511 for bit type data). \$ or M specifies that the match must start at the beginning of a Device Starting Address.	N/A
<b>Length</b>	
Set up the number of the continuous address followed by the default mapped address will be read or write. Input range is from 1 to 64.	N/A
<b>Operation</b>	
Click the +/- button to add mapping or delete mapping.	N/A
<b>Edit</b>	
Click an item of register mapping forms that can be edited.	N/A

### 3.4.2 RS485

RS-485 (Recommended Standard - 485) is a telecommunication standard for binary serial communications between devices. It supports six work modes, include: Transparent mode, Slave mode, Master mode, Serial Server-TCP Server, Serial Server-TCP Client and Serial Server-UDP Client.

You can set up the configurations for RS-485, including Baud Rate, Data Bits, Stop Bits, Parity Bits, and many more.

Description	Default
<b>Working Mode</b>	
Select the working mode for the current active serial port.	Close
<b>Baud Rate</b>	
Set up the baud rate for the serial port. Options are 2400, 4800, 9600, 19200, 38400, 57600 and 115200.	9600
<b>Data Bits</b>	
Set up the data bits for the serial port. Options are 7 and 8. It must be set to 8 when communication mode is Modbus RTU.	8
<b>Stop Bits</b>	
Set up the stop bits for the serial port. Options are 1 and 2.	1
<b>Parity Bits</b>	
Set up the parity bits for the serial port. Options are None, Odd and Even.	None

- **Transparent mode**

This mode is suitable for uploading and downloading data remotely via the serial port.

### RS485

Working Mode	Transparent mode ▾
Baud Rate	9600 ▾
Data Bits	8 ▾
Stop Bits	1 ▾
Parity Bits	None ▾

Save

Cancel

- Slave mode**

This mode is suitable for the PLC to perform the read/ write tasks on the open register of the DX Router.

### RS485

Working Mode	Slave mode ▾
Baud Rate	9600 ▾
Data Bits	8 ▾
Stop Bits	1 ▾
Parity Bits	None ▾
Slave ID	1
Mode	Modbus RTU ▾
Timeout	200 (ms)

Save

Cancel

Description	Default
<b>Slave ID</b>	
Set up the MODBUS ID. The value is between 1 and 247.	1
<b>Mode</b>	
Set up the communication mode for the device. Device support Modbus RTU and Modbus ASCII	Modbus RTU
<b>Timeout</b>	

Description	Default
Set up the timeout timer from 200ms to 5000ms. If the set value is out of range, it will be automatically changed to its maximum or minimum value.	200ms

• **Master mode**

This mode is suitable for the DX router to perform the read/write tasks on the open register of the PLC.

**RS485**

Working Mode

Baud Rate

Data Bits

Stop Bits

Parity Bits

Slave ID

Mode

Timeout  (ms)

**Read/Write Configuration**

Scan Interval  (ms)

When communicate with PLC of Delta, the starting address can be set as the internal register number. For example, input 0 for register D0.

The acceptable address range of this device is: \$0-\$1535 or \$2048-\$4095 or M0-M511.

Row Number	Read/Write	Slave ID	Controller	Address Type	Slave Starting Address	Bit	Device Starting Address	Length (1-123)	Operation
1	Read/Write	1	Delta DVP PLC	D		0	\$		<input type="button" value="+"/> <input type="button" value="-"/>

Description	Default
<b>Slave ID</b>	
Set up the MODBUS ID for DX router. Invalid in Master mode.	1
<b>Mode</b>	
Set up the communication mode for the device. Device support Modbus RTU and Modbus ASCII.	Modbus RTU
<b>Timeout</b>	
Set up the timeout timer from 200ms to 5000ms. If the set value is out of range, it will be automatically changed to its maximum or minimum value.	200ms

Description	Default
<b>Scan Interval</b>	
Set up the time for scan interval, ranging from 50ms to 60000ms.	30000ms
<b>Add Mappings</b>	
Click the button to add a new mapping;	N/A
<b>Delete All Mappings</b>	
Delete all mappings of RS-485 master mode	N/A
<b>Export Configure List</b>	
Export the configure list to the file and save to local PC	N/A
<b>Import Configure List</b>	
Open local file and import the configure list	N/A
<b>Read/Write</b>	
<p>Set up the access permissions for the mapped register address;</p> <ul style="list-style-type: none"> <li>• <b>Read-only:</b> The device regular read data from appointed registers in the slave, but will not update the data to the slave</li> <li>• <b>Write-only:</b> The device updates the data to the slave when the registers values were changed, but will not read the data from the slave</li> <li>• <b>Read/write:</b> The device regular read data from appointed registers in the slave, will update the data to the slave when the registers values are changed.</li> </ul>	Read/Write
<b>Slave ID</b>	
Set up the corresponding slave communication port. The value is between 1 and 247.	1
<b>Controller</b>	
<p>In master mode, device types options are:</p> <ul style="list-style-type: none"> <li>• <b>Delta PLC:</b> Use this option for Delta DVP / AH / AS series PLCs</li> <li>• <b>Other:</b> Use this option for non-Delta PLCs. HEX means hexadecimal address; DEC means decimal address.</li> </ul>	Delta DVP PLC
<b>Address Type</b>	
<p>In master mode, it depending on the selected controller type change:</p> <ul style="list-style-type: none"> <li>• <b>Delta PLC:</b> The address type is D/M/S/X/Y; D for word type, M/S/X/Y for bit type</li> <li>• <b>Other:</b> The address type is 0x/1x/3x/4x/Swap: <ul style="list-style-type: none"> <li>-0x: Read or write coil data (Modbus function code: 01/05)</li> <li>-1x: Read discrete inputs (Modbus function code: 02)</li> <li>-3x: Read or write input registers (Modbus function code: 04)</li> <li>-4x: Read or write holding registers (Modbus function code: 03/16)</li> <li>-Swap: Read or write holding registers, transposition store to DX router's register in pairs</li> </ul> </li> </ul>	D

Description	Default
<b>Slave Starting Address (decimal)</b>	
Set up the slave starting address for read/write the registers in a PLC. <ul style="list-style-type: none"> <li>• <b>Delta PLC:</b> Enter the internal D register number. If you need to read / write D0, please enter 0 here.</li> <li>• <b>Other:</b> Enter the Hexadecimal or Decimal actual address. For example: Holding Register: 400100, take 0100 (decimal) that is 64 (hex).</li> </ul>	N/A
<b>Bit</b>	
For X/Y type data of Delta AH/AS series, the address format is x1.x2, then x1 input to slave starting address column, x2 input to this column.	
<b>Device Starting Address (decimal)</b>	
Set up the device starting address (decimal, input range is from \$2048 to \$4095 for word type data, input range is from M0 to M511 for bit type data). \$ or M specifies that the match must start at the beginning of a Device Starting Address.	N/A
<b>Length (1-123)</b>	
Set up the number of the continuous address followed by the default mapped address will be read or write. Input range is from 1 to 64.	N/A
<b>Operation</b>	
Click the +/- button to add mapping or delete mapping.	N/A
<b>Edit</b>	
Click an item of register mapping forms that can be edited.	N/A

- **Serial Server-TCP Server**

DX router act as a TCP Server, when received the packet from client, parse the packet and transmit to RS-485.

## RS485

Working Mode	<input type="text" value="Serial Server - TCP Server"/>
Baud Rate	<input type="text" value="9600"/>
Data Bits	<input type="text" value="8"/>
Stop Bits	<input type="text" value="1"/>
Parity Bits	<input type="text" value="None"/>
TCP Alive Check Time	<input type="text" value="7"/> (0-99 min)
Listening Port	<input type="text" value="16000"/>
Packing Length	<input type="text" value="0"/> (0-1024)
Force Transmit	<input type="text" value="0"/> (0-65535 ms)

Save

Cancel

Description	Default
<b>TCP Alive Check Time</b>	
Setting how long TCP activity keep idle, then the TCP connection will be drop. Input range is from 0 to 99 minutes. 0 means will never drop it.	7
<b>Listening Port</b>	
Set up the listening port in server.	16000
<b>Packing Length</b>	
Setting the length of packet, packet will be transmitted when the size reaches the values. Input range is from 0 to 1024 byte. 0 means will transmit at once when received the data.	0
<b>Force Transmit</b>	
Setting how long the program waiting, then transmit the packet. Input range is from 0 to 65535 millisecond. 0 means will never force to transmit.	0

- Serial Server-TCP Client**

DX router act as a TCP Client, packet RS-485 data and transmit to Server by TCP protocol.

**RS485**

Working Mode

Baud Rate

Data Bits

Stop Bits

Parity Bits

TCP Alive Check Time  (0-99 min)

Destination IP Address1  Port

Destination IP Address2  Port

Destination IP Address3  Port

Destination IP Address4  Port

Designated Local Port1

Designated Local Port2

Designated Local Port3

Designated Local Port4

Packing Length  (0-1024)

Force Transmit  (0-65535 ms)

Description	Default
<b>TCP Alive Check Time</b>	
Setting how long TCP activity keep idle, then the TCP connection will be drop. Input range is from 0 to 99 minutes. 0 means will never drop it.	7
<b>Destination IP address and Port</b>	
Setting the serial Server IP address and listening port. You can set 4 different destination at most.	
<b>Designated local port</b>	
Set up the local port for transmission.	14001~14004
<b>Packing Length</b>	
Setting the length of packet, packet will be transmitted when the size reaches	0

Description	Default
the values. Input range is from 0 to 1024 byte. 0 means will transmit at once when received the data.	
<b>Force Transmit</b>	
Setting how long the program waiting, then transmit the packet. Input range is from 0 to 65535 millisecond. 0 means will never force to transmit.	0

• **Serial Server-UDP Client**

DX router act as a UDP Client, packet RS-485 data and transmit to Server by UDP protocol.

**RS485**

Working Mode:

Baud Rate:

Data Bits:

Stop Bits:

Parity Bits:

	Begin	End	port
Destination IP Address1	<input type="text"/>	<input type="text"/>	: <input type="text" value="6001"/>
Destination IP Address2	<input type="text"/>	<input type="text"/>	: <input type="text" value="6002"/>
Destination IP Address3	<input type="text"/>	<input type="text"/>	: <input type="text" value="6003"/>
Destination IP Address4	<input type="text"/>	<input type="text"/>	: <input type="text" value="6004"/>

Local Listen Port:

Packing Length:  (0-1024)

Force Transmit:  (0-65535 ms)

Description	Default
<b>Destination IP address and Port</b>	
Setting the serial Server IP address and listening port. You can set 4 groups destination at most. For each group, it allows 99 IP address max.	
<b>Local listen port</b>	
Set up the local port for transmission.	15000

Description	Default
<b>Packing Length</b>	
Setting the length of packet, packet will be transmitted when the size reaches the values. Input range is from 0 to 1024 byte. 0 means will transmit at once when received the data.	0
<b>Force Transmit</b>	
Setting how long the program waiting, then transmit the packet. Input range is from 0 to 65535 millisecond. 0 means will never force to transmit.	0

3

### 3.4.3 Modbus TCP

This page allows users to set whether to enable Modbus TCP client mode and set relevant parameters.

🏠 SYSTEM > Modbus TCP

#### ☰ Modbus TCP

Working Mode

\*32 modbus TCP servers supported at most

Row Number	Server IP	Server Port	Response Timeout(ms)	Scan Interval(ms)	Operation
------------	-----------	-------------	----------------------	-------------------	-----------

Click "Add Server" , it will show below page.

#### Modbus TCP Client Setting

Server IP

Server Port

Response Timeout  (ms)

#### Read/Write Configuration

Scan Interval  (ms)

When communicate with PLC of Delta, the starting address can be set as the internal register number. For example, input 0 for register D0.

The acceptable address range of this device is: \$0-\$1535 or \$2048-\$4095 or M0-M511.

Make sure that the server already exists before importing, otherwise the importing is invalid and it will return to the original state.

Row Number	Read/Write	Slave ID	Controller	Address Type	Slave Starting Address	Bit	Device Starting Address	Length (1-123)	Operation
1	Read/Write ▾	1	Delta DVP PLC ▾	D ▾		0	\$		<input type="button" value="+"/> <input type="button" value="-"/>

Description	Default
<b>Working Mode</b>	
<ul style="list-style-type: none"> <li>• <b>Modbus TCP Server:</b> Only Modbus TCP server works. And supports up to 32 Client to connect.</li> <li>• <b>Modbus TCP Server+Client:</b> Modbus TCP server + Modbus TCP client work at the same time. MODBUS TCP Client supports to connect to 32 different servers at most.</li> </ul>	Modbus TCP Server
<b>Server IP</b>	
Set up the IP address of a PLC in the Modbus TCP Client mode	N/A
<b>Server Port</b>	
Set up the server port of a PLC in the Modbus TCP Client mode	502
<b>Response Timeout</b>	
Set up the timeout timer from 50ms to 10000ms. If the set value is out of range, it will be automatically changed to its maximum or minimum value. The default is 300ms.	300
<b>Scan Interval</b>	
Set up the time for scan interval, ranging from 50ms to 60000ms; the default is 3000ms.	30000
<b>Add Mappings</b>	
Click the button to add a new mapping;	N/A
<b>Delete All Mappings</b>	
Delete all mappings of this server	N/A
<b>Export Configure List</b>	
Export the configure list to the file and save to local PC	N/A
<b>Import Configure List</b>	
Open local file and import the configure list	N/A
<b>Read/Write</b>	
Set up the access permissions for the mapped register address; <ul style="list-style-type: none"> <li>• <b>Read-only:</b> The device regular read data from appointed registers in the slave, but will not update the data to the slave</li> <li>• <b>Write-only:</b> The device updates the data to the slave when the registers values were changed, but will not read the data from the slave</li> <li>• <b>Read/write:</b> The device regular read data from appointed registers in the slave, will update the data to the slave when the registers values are changed.</li> </ul>	Read/Write
<b>Slave ID</b>	
Set up the corresponding slave communication port. The value is between 1 and 247.	1

Description	Default
<b>Controller</b>	
In master mode, device types options are: <ul style="list-style-type: none"> <li><b>Delta PLC:</b> Use this option for Delta DVP / AH / AS series PLCs</li> <li><b>Other:</b> Use this option for non-Delta PLCs. HEX means hexadecimal address; DEC means decimal address.</li> </ul>	Delta DVP PLC
<b>Address Type</b>	
In master mode, it depending on the selected controller type change: <ul style="list-style-type: none"> <li><b>Delta PLC:</b> The address type is D/M/S/X/Y; D for word type, M/S/X/Y for bit type</li> <li><b>Other:</b> The address type is 0x/1x/3x/4x/Swap: <ul style="list-style-type: none"> <li>-0x: Read or write coil data (Modbus function code: 01/05)</li> <li>-1x: Read discrete inputs (Modbus function code: 02)</li> <li>-3x: Read or write input registers (Modbus function code: 04)</li> <li>-4x: Read or write holding registers (Modbus function code: 03/16)</li> <li>-Swap: Read or write holding registers, transposition store to DX router's register in pairs</li> </ul> </li> </ul>	D
<b>Slave Starting Address (decimal)</b>	
Set up the slave starting address for read/write the registers in a PLC. <ul style="list-style-type: none"> <li><b>Delta PLC:</b> Enter the internal D register number. If you need to read / write D0, please enter 0 here.</li> <li><b>Other:</b> Enter the Hexadecimal or Decimal actual address. For example: Holding Register: 400100, take 0100 (decimal) that is 64 (hex).</li> </ul>	N/A
<b>Bit</b>	
For X/Y type data of Delta AH/AS series, the address format is x1.x2, then x1 input to slave starting address column, x2 input to this column.	
<b>Device Starting Address (decimal)</b>	
Set up the device starting address (decimal, input range is from \$2048 to \$4095 for word type data, input range is from M0 to M511 for bit type data). \$ or M specifies that the match must start at the beginning of a Device Starting Address.	N/A
<b>Length (1-123)</b>	
Set up the number of the continuous address followed by the default mapped address will be read or write. Input range is from 1 to 64.	N/A
<b>Operation</b>	
Click the +/- button to add mapping or delete mapping.	N/A
<b>Edit</b>	
Click an item of register mapping forms that can be edited.	N/A

### 3.4.4 Siemens TCP

This page allows users to set DX router act as Siemens TCP client and set relevant parameters.

🏠 SYSTEM > Siemens TCP

#### ☰ Siemens TCP Client

\*32 Siemens TCP servers supported at most

Add Server

Row Number	Server IP	Controller	Response Timeout(ms)	Scan Interval(ms)	Operation
------------	-----------	------------	----------------------	-------------------	-----------

Click "Add Server" , it will show below page.

#### Siemens TCP Client Setting

Controller  ▾

Server IP

Response Timeout  (ms)

#### Read/Write Configuration

Scan Interval  (ms)

The acceptable address range of this device is: \$0-\$1535 or \$2048-\$4095 or M0-M511.

The length should be 1 when the data type is BIT.

Make sure that the server already exists before importing, otherwise the importing is invalid and it will return to the original state.

Add Mappings

Delete All Mappings

Export Configure List

Import Configure List

浏览...

Row Number	Read/Write	Data Type	Address Type	DB Number	Slave Offset Address	Bit	Device Starting Address	Length (1-123)	Operation
1	Read/Write ▾	WORD ▾	DB ▾			0	\$		<span style="color: green;">+</span> <span style="color: red;">-</span>

Save

Cancel

Description	Default
<b>Add Server</b>	
Set up the Siemens TCP server info. Supports to connect to 32 different servers at most.	Modbus TCP Server
<b>Controller</b>	
Set up the device type of the Siemens PLC.	S7-300
<b>Server IP</b>	
Set up the IP address of the Siemens PLC.	N/A
<b>Local TSAP</b>	
Set up local TSAP ID when controller is "S7-200 ISO TCP" or "S7-1200/1500 ISO TCP"	

Description	Default
<b>Remote TSAP</b>	
Set up destination TSAP ID when controller is "S7-200 ISO TCP" or "S7-1200/1500 ISO TCP"	
<b>Response Timeout</b>	
Set up the timeout timer from 50ms to 10000ms. If the set value is out of range, it will be automatically changed to its maximum or minimum value. The default is 300ms.	300
<b>Scan Interval</b>	
Set up the time for scan interval, ranging from 50ms to 60000ms.	30000
<b>Add Mappings</b>	
Click the button to add a new mapping;	N/A
<b>Delete All Mappings</b>	
Delete all mappings of this server	N/A
<b>Export Configure List</b>	
Export the configure list to the file and save to local PC	N/A
<b>Import Configure List</b>	
Open local file and import the configure list	N/A
<b>Read/Write</b>	
Set up the access permissions for the mapped register address; <ul style="list-style-type: none"> <li>• <b>Read-only:</b> The device regular read data from appointed registers in the slave, but will not update the data to the slave</li> <li>• <b>Write-only:</b> The device updates the data to the slave when the registers values were changed, but will not read the data from the slave</li> <li>• <b>Read/write:</b> The device regular read data from appointed registers in the slave, will update the data to the slave when the registers values are changed.</li> </ul>	Read/Write
<b>Data Type</b>	
Set up the data type to be collected. Options are: <ul style="list-style-type: none"> <li>• BIT: bit type</li> <li>• WORD: word type</li> <li>• DWORD(Swap): double word type, and transposition store to DX router's register in pairs</li> </ul>	WORD
<b>Address Type</b>	
<ul style="list-style-type: none"> <li>• <b>Controller is "S7-200 ISO TCP"</b> : Address type options are V/M/Q/I, combine with data type, it will generate: <ul style="list-style-type: none"> <li>- Bit type: VB/MB/QB/IB</li> <li>- Word type: VW/MW/QW/IW</li> <li>- DWord type: VD/MD/QD/ID</li> </ul> </li> </ul>	DB

Description	Default
<ul style="list-style-type: none"> <li>Controller is “S7-300” or “S7-200 ISO TCP” : Address type options are DB/M/Q/I, combine with data type, it will generate: <ul style="list-style-type: none"> <li>- Bit type: DBn_DBX/MB/QB/IB</li> <li>- Word type: DBn_DBW/MW/QW/IW</li> <li>-DWord type: DBn_DBD/MD/QD/ID</li> </ul> </li> </ul>	
<b>DB Number</b>	
Set up the unit number of the Siemens PLC start address, it is invalid when controller is” S7-200 ISO TCP”:	D
<b>Slave Offset Address</b>	
Set up the starting address for read/write the registers in Siemens PLC. For example, V100 register, just input 100.	N/A
<b>Bit</b>	
For Bit type data, the address format is x.y, then x input to slave starting address column, y input to this column.	
<b>Device Starting Address (decimal)</b>	
Set up the device starting address (decimal, input range is from \$2048 to \$4095 for word type data, input range is from M0 to M511 for bit type data). \$ or M specifies that the match must start at the beginning of a Device Starting Address.	N/A
<b>Length (1-123)</b>	
Set up the number of the continuous address followed by the default mapped address will be read or write. Input range is from 1 to 64.	N/A
<b>Operation</b>	
Click the +/- button to add mapping or delete mapping.	N/A
<b>Edit</b>	
Click an item of register mapping forms that can be edited.	N/A

### 3.4.5 DI/DO

DX-3021L9 have two sets DI/DO interface, user can setup the trigger even for DI/DO action in this page.

🏠 INTERFACE > DI/DO

☰ **DI Setting**

DI1	<input type="text" value="Disabled"/>	Triggering Event	<input type="text" value="Disabled"/>
DI2	<input type="text" value="Disabled"/>	Triggering Event	<input type="text" value="Disabled"/>

☰ **DO Setting**

System Event	<input type="text" value="Disabled"/>	Triggering DO1	<input type="text" value="Disabled"/>
System Event	<input type="text" value="Disabled"/>	Triggering DO2	<input type="text" value="Disabled"/>

Description	Default
<b>DI1/DI2</b>	
Specify what happens to the DI1/DI2 state, then trigger the event. Options as below: -Disabled: disable DI1/DI2 trigger function -Off->On: When DI1/DI2 status change from OFF to ON, trigger the event -On->Off: When DI1/DI2 status change from ON to OFF, trigger the event	Disabled
<b>Triggering Event</b>	
Specify the trigger event, total 11 events are support: -Restart router -Enable/disable cellular -Enable/disable WAN -Enable/disable Internet -Enable/disable Cloud Service -DO1 on/off -DO2 on/off	Disabled
<b>System Event</b>	
Specify what happens in the system, then trigger the DO action. -Cloud Service Connected/Disconnected -Internet Connected/Disconnected -Cellular Abnormally -WAN Down/Up	Disabled
<b>DO1/DO2</b>	

Description	Default
Setup the DO1/DO2 action when specified event happen. Options include DO On and DO Off.	Disabled

### 3.4.6 USB

This page will show detail information about USB drive, and enable/disable the USB function.

[🏠 INTERFACE > USB Setting](#)

#### ☰ USB Setting

USB Total Capacity

USB Available Capacity

USB Log Backup

FTP Server

FTP user

FTP password

Save

Cancel

Description	Default
<b>USB Total Capacity</b>	
Show the total size of the USB drive.	N/A
<b>USB Available Capacity</b>	
Show the free size of the USB drive.	N/A
<b>USB Log Backup</b>	
Enable or disable log backup function. The router's log will duplicate to USB drive after this function has been enable.	Disabled
<b>FTP Server</b>	
Enable or disable FTP server function. User can remote access this USB drive by FTP protocol after this function has been enable.	Disabled
<b>FTP User</b>	
Setup the FTP account name	admin
<b>FTP Password</b>	

Description	Default
Setup the FTP account password.	admin

### 3.5 System

You can set up the system configurations, including the User Management, Time Zone Configurations, Log Setting, Firmware Upgrade, Backup & Restore, Scheduled Jobs, Network Diagnosis, System Reboot, Event Management and Register Management.

#### 3.5.1 User Management

You can change the administrator password and set session timeout here. The password must be a combination of 5 to 12 characters, numbers and/or underline symbols.

🏠 SYSTEM > User Management

##### ☰ Device Name Setting

Device Name  Save Cancel

##### ☰ Change Administrator Password

Old Password

New Password

The password must be a combination of 5 to 12 characters, numbers and underline marks

Confirm Password

Save Cancel

##### ☰ Session Timeout Setting

Session Timeout:  (10-1440 min) Save

Description	Default
<b>Device Name</b>	
Set up a device name for your router. The name shall be composed of letters, numbers and underline, starting with a letter or number. The maximum string length is 32 bytes.	DX3021 + “_” + “the last four digits of Mac address”
<b>Old Password</b>	

Description	Default
Input the original password.	admin
<b>New Password</b>	
Input the new password you'd like to use. The password length should be 5-12 digits and is composed of lowercase letters, uppercase letters (case sensitive), numerals 0-9 and underline.	N/A
<b>Confirm Password</b>	
Again input the password you'd like to use to double confirm there is no typo.	N/A
<b>Session Timeout</b>	
Session timeout is an expired time limit for a logged in user which has been inactive for a period of time. Setting range is from 10 to 1440 minutes	30

### 3.5.2 Time Zone Configurations

You can change the current time of the device. Use the dropdown list to select the correct time zone for your device.

[SYSTEM](#) > Time Zone Settings

#### The current time of device 2019-08-27 17:10:37

Local PC Time      2019-08-27 17:10:40      [Set Local PC Time](#)

Time Zone Settings            [Save](#)

Description	Default
<b>The current time of device</b>	
Here shows the current time of your device.	N/A
<b>Set Local PC Time</b>	
Set the routing time by PC currently time.	N/A
<b>Time Zone Setting</b>	
Select the operating time zone of your device: GMT-12:00 - GMT+13:00.	N/A

### 3.5.3 Log Settings

This page is used for configuring the log settings, including Log to Console, Remote Log Service, Remote Log Server Address, and Port of Remote Log Server.

🏠 SYSTEM > Log Settings

### ☰ Log Settings

Log To Console

Remote Log Service

Remote Log Server Address

Port Of Remote Log Server  (1~65534)

Save

Cancel

Description	Default
<b>Log to Console</b>	
Set up the log to the console port.	No
<b>Remote Log Service</b>	
Enable/disable the remote log service.	Disable
<b>Remote Log Server Address</b>	
Set up the remote log server address	N/A
<b>Port of Remote Log Server</b>	
Set up the remote log server port, ranging from 1 to 65534.	514

#### Notice



Remote log service is used for qualified engineers to check the device remotely when errors occurred. With this service, there is no need to log in to the device, device logs can be exported to the remote log server. The server should support the syslog protocol. When this functionality is enabled, it will take up some resources. Do not enable this functionality disabled, unless it's necessary.

### 3.5.4 Firmware Upgrade

This page is used for upgrading the system.

🏠 SYSTEM > Firmware Upgrade

#### ☰ Firmware Upgrade

DO NOT turn off the power supply or reboot the device during the upgrade process. Please select the correct firmware package which is consistent with the device model, otherwise the device may be damaged !

(Before upgrade the firmware, please backup the settings and data. Please contact the local dealers or manufacturers when failed to upgrade the firmware)

Select Firmware

Description	Default
<b>Select Firmware</b>	
Click "Browse" to select the new firmware file.	N/A
<b>Upgrade</b>	
Click "Upgrade" to upgrade firmware. The device will reboot after the upgrade is done.	N/A

### 3.5.5 Backup & Restore

This page is used for backing up and restoring the configurations.

🏠 SYSTEM > Backup & Restore

#### ☰ Backup & Restore

Device configurations can be backed up and saved to local PC

Configuration restoration will remove the current settings in the device and restore the configurations in your .cfg file

Select .Cfg File

Configurations will be reset to the factory default settings, device will be reboot after the reset

Description	Default
<b>Backup</b>	
Click "Backup" to save the device configurations on your computer.	N/A
<b>Restore</b>	

Description	Default
Click "Browse" to select the backup file and then click "Restore" to restore the configurations. The device configuration will be restored to the previous version and the device will reboot after the restoring is done.	N/A
<b>Restore To Factory Default</b>	
Click "Restore To Factory Default" to reset the configurations to the factory defaults. The device will reboot after the reset is done.	N/A

### 3.5.6 System Reboot

This page is used for manually rebooting the system. Click "Restart Device" and the system will reboot.

🏠 SYSTEM > System Reboot

#### ☰ System Reboot

The network will be temporarily shut down during system reboot, please wait!

Restart Device

### 3.5.7 Network Diagnosis

This page is used for diagnosing the network status; methods are Ping Test and Route Trace.

🏠 SYSTEM > Network Diagnosis

#### ☰ Network Diagnosis

Diagnosing Method


Host Name/IP Address

Description	Default
Diagnosing Method	

Description	Default
Select the Diagnosing Method; options are Ping Test and Route Trace.	Ping Test
<b>Host Name/IP Address</b>	
Select the domain name or IP address of the server that you want to test. The default options are www.google.com, www.yahoo.com, www.MSN.com, www.amazon.com, www.wikipedia.org, www.facebook.com, www.diacloudsolutions.com and others. When user choose others, user can input the domain/IP manual.	www.diacloudsolutions.com
<b>Start</b>	
Click "Start" to start the network diagnosing. While running the network diagnosing, the settings cannot be changed.	N/A


### 3.5.8 Trouble shooting

After enable the trouble shooting function, the DX router will automatically upload the log to the designated server, so that our engineers can remotely analyze and locate the fault of the router. The DX router also can download and run script to help diagnose problems from the designated server automatic if necessary.

 [SYSTEM > Trouble Shooting](#)

#### Trouble Shooting Setting


Trouble Shooting

Enable 

Save

### 3.5.9 Scheduled Jobs

This page is used for scheduling job configurations, including ADD A New Job, Export Job List, and Import Job List.

 [SYSTEM > Scheduled Jobs](#)

<a href="#">Add A New Job</a>	<a href="#">Export Job List</a>	<a href="#">Import Job List</a>	<a href="#">Browse...</a>	
ID	Job Name	Job Type	Timestamp	Enabled

- **Add A New Job**

Click "Add A New Job" , and then you will see the following page. Follow the instruction to add a new scheduled job.

SYSTEM > Scheduled Jobs

Add A New Job

Job Name

Enabled

**Time Configurations**

---

Recurring Job   Hour  Minute

Date  Year  Month  Day

---

Job Type

Description	Default
<b>Job Name</b>	
Set up a name for your scheduled job. The name shall be composed of letters, numbers and underline, starting with a letter or number. The maximum string length is 32 bytes.	N/A
<b>Enable</b>	
Select "Enable" to activate this functionality.	Enable
<b>Recurring Job</b>	
The scheduled job can be done Once, Every day, Every week, or Every month. And the specific time can be further defined.	Once 01:00
<b>Date</b>	
Select a specific date to perform the scheduled job.	2015.01.01
<b>Job Type</b>	
Select one of the job type for the scheduled job. <ul style="list-style-type: none"> <li>Restart device</li> <li>Enable DIACloud Service</li> <li>Disable DIACloud Service</li> </ul>	Restart device

● **Export Job List**

Click "Export Job List" to export the scheduled jobs for future usage.

🏠 SYSTEM > Scheduled Jobs

ID	Job Name	Job Type	Timestamp	Enabled
----	----------	----------	-----------	---------

### ● Import Job List

Click "Chose file" to select the scheduled jobs file you have saved and then click "Import Job List" to import the scheduled jobs you have set before.

🏠 SYSTEM > Scheduled Jobs

ID	Job Name	Job Type	Timestamp	Enabled
----	----------	----------	-----------	---------

## 3.5.10 Privilege Management

Privilege management use in order to set the white list of phone numbers and the device operation can be triggered via the specific SMS text from the white list of phone numbers.

You can fill in the target mobile phone number and press 'Send' button to test the Short Message function of the device.

The SMS commands listed below:

Function	SMS Command	Description
SMS Query commands	"ZLCX" or "zlcx"	List all SMS commands and explanations.
Status Query	"ZTCX" or "ztcx"	Discover the router's current status information, including the following: <ol style="list-style-type: none"> <li>1. Cellular network state</li> <li>2. Firewall state</li> <li>3. DIACloud state</li> </ol>
Restart Device	"CQLY" or "cqly"	Restart the router
Enable cellular network	"KQBH" or "kqbh"	Dial-up the router to internet
Disable cellular network	"DKBH" or "dkbh"	The router disconnects from the internet
Enable DIA cloud service	"KQVD" or "kqvd"	DIA cloud service enables on the router
Disable DIA cloud service	"GBVD" or "gbvd"	DIA cloud service disables on the router

SYSTEM > Privilege Management

Current SMS SIM: Sim1

Short Message Center Number 1: Auto detect [Save]

Short Message Center Number 2: Auto detect [Save]

Send Short Message Test: Country Code [telephone number] [Send]

Short Message Control Gateway

[Add A Telephone Number] [Export The List] [Import A List] [浏览...]

ID	Name	Telephone Number	Operation Privileges	Enabled	Short Message Reply	Operation
----	------	------------------	----------------------	---------	---------------------	-----------

Short Message Control PLC

[Add A Telephone Number] [Export The List] [Import A List] [浏览...]

ID	Name	Telephone Number	Enabled	Short Message Reply	Operation
----	------	------------------	---------	---------------------	-----------

Control List Of Event Management

[Add A Telephone Number] [Export The List] [Import A List] [浏览...]

ID	Name	Telephone Number	Email	Operation
----	------	------------------	-------	-----------

Currently, there are three the main SMS settings: 1. Short Message Control Gateway. 2. Short Message Controlling PLC. 3. Control List of Event Management. Setting interface as follows:

SYSTEM > Privilege Management

Add A New Short Message Control User

Name: [ ]

Telephone Number: Country Code - [telephone number]

Enabled: Yes [v]

Short Message Reply: Yes [v]

Operation Privileges

- Restart device
- Status query
- Short message query commands
- Enable DIA cloud service
- Disable DIA cloud service
- Enable cellular network
- Disable cellular network

[Save] [Back]

🏠 SYSTEM > Privilege Management

☰ Add A New Short Message User Controlling PLC

Name

Telephone Number  -

Enabled  ▾

Short Message Reply  ▾

🏠 SYSTEM > Privilege Management

☰ Add A New User Of Event Management

Name

Telephone Number  -

Email

Description		Default
<b>Current SMS SIM</b>		
Show which sim is the default sim to sent Short Message. It can be config in [Network] - [Connection] function.		N/A
<b>Short Message Center Number1/2</b>		
Input the short message center number supported by this SIM 1&2 card, the input format is: "+" "country code" "short message center number". <b>Example: +8613800100500</b>		N/A
<b>Send Short Message Test</b>		
Confirm SMS module related functions are executed correctly, you can send a function test message to the specified number to send a test message to verify the relevant settings are correct.  The input format is as follows: <ul style="list-style-type: none"> <li>Country Code: "+" "Country Code".</li> <li>Cell phone number: 13800100500.</li> </ul> <b>Example: +8613800100500</b>		N/A
<b>Add A Telephone Number</b>	<b>ID</b>	
	The maximum allow the 10 phone numbers	N/A
	<b>Name</b>	

Description		Default
	Set up a name for phone number, The name shall be composed of letters, numbers and underline, starting with a letter or number. The maximum string length is 32 bytes.	N/A
<b>Telephone Number</b>		
	Set up a telephone number and country code which can receive the alarm message.  The input format is as follows: <ul style="list-style-type: none"> <li>Country Code: "+" "Country Code".</li> <li>Cell phone number: 13800100500.</li> </ul> <b>Example: +8613800100500</b>	N/A
<b>Enabled</b>		
	Set up the permission to enable or disable	Yes
<b>Short Message Reply</b>		
	When the router receives the SMS commands, the router will response a confirmed message.	Yes
<b>Email</b>		
	Set up an Email address to receive the alarm message. This setting work with The Event management.	N/A
<b>Edit</b>		
	Edit the existing event	N/A
<b>Delete</b>		
	Delete the existing event	N/A
<b>Export The List</b>		
	Export the event of SMS	Fixed_sms_control_list.cfg
<b>Import A List</b>		
	Import the event of SMS to the router	N/A

### 3.5.11 Event Management

This page is used for setting up 3 types of events, Communication Verification, Alarm Event and SMS Queries Event.

- Communication Verification:** when this option is selected, the router will monitor and check if this channel is trustable to ensure a safe communication between a router and a PLC via MODBUS TCP, MODBUS ASCII or MODBUS RTU.

SYSTEM > Event Management

Event Management

Event Type

Input Expression

The expression is the numeric expression in C, the syntax complies with standard C programming syntax. The expression can be a single variable itself, or a constant, or a single variable equation. The name of the variable is limited to be "A", the expression can be: (A+100)\*45

The operators that the expression supports are as below:

Operators	Types	Examples	Description
+	Arithmetic operator	A+100	Addition
-	Arithmetic operator	A-100	Subtraction
*	Arithmetic operator	A*100	Multiplication
/	Arithmetic operator	A/100	Division
&	Logic operator	A&A+100	Logic AND
	Logic operator	A A+100	Logic OR
()	Bracket operator	(A+100)*45	Change operation order
^	XOR operation	A^100	XOR operation

- **Alarm Event:** users can set up the Alarm Name, Alarm Description, Alarm Criteria, Target Receiver and Operation.

SYSTEM > Event Management

Event Management

Event Type

Send Short Message By

Please ensure the data traffic of your SIM card is available if you choose send short message by device SIM card, or it will affect the functionality !

Alarm Name	Alarm Description	Alarm Criteria	Target Receiver	Status	Operation
------------	-------------------	----------------	-----------------	--------	-----------

Click "Add" button to create new alarm event, Click "Export configure List" button to export the setting as a file and save to local PC. Click "Import configure List" button to import the setting from a file.

And, in the existing List, click “Details” to edit the existing event, click “Delete” button to delete the selected event. Click “Copy” to duplicate the event.

🏠 SYSTEM > Event Management

☰ Alarm Event

3

Alarm Name

Alarm Description

Alarm Criteria

Event Interval  (0~6000)minute

Repeat Times  (0~999)times

Alarm Status  ▾

Alarm Content

```
{Date} {Time} Alarm form 2048, the value of 2048 is {2048}
```

Target Receiver  Steven\_Li

Description	Default
<b>Alarm Name</b>	
Input an alarm name. The name shall be composed of numbers, English letters, uppercase and lowercase. The maximum string length is 32 bytes.	N/A
<b>Alarm Description</b>	
The alarm description shall be composed of numbers, English letters, uppercase and lowercase. The maximum string length is 50 bytes.	N/A
<b>Alarm Criteria</b>	
Setup the alarm trigger condition. The format of alarm variable is {\$number 0-4095}, the alarm criteria can be a single alarm variable, or a formula of one or several alarm criteria. For example, the formula can be: {\$2048}>100	N/A
<b>Event Interval</b>	
The time interval of alarm sending	0
<b>Repeat Times</b>	
The repeated times of alarm sending	0
<b>Alarm Status</b>	
Enable or disable this alarm setting	Enable

Description	Default
<b>Alarm Content</b>	
<p>Set up the information shown on the alarm contents. The content of the alarm will be sent to the target when alarm criteria are met. The information order can be self-defined.</p> <ul style="list-style-type: none"> <li>• <b>Time:</b> the time when the alarm occurred</li> <li>• <b>Date:</b> the date when the alarm occurred</li> <li>• <b>Name:</b> the name of the occurred alarm</li> <li>• <b>Description:</b> the description of the occurred alarm</li> </ul> <p><b>For example:</b> Register \$2048 represents electrical voltage, the value of register \$2048 is 10, and the alarm content is set as: {Date} {Time} Voltage = {\$2048}, then the alarm content received by users will be: 2016/06/01 10:00:00(currently time) Voltage = 10. The maximum content length is 160 characters.</p>	N/A
<b>Target Receiver</b>	
Set up the recipient. User can maintain the list by <b>【Control List Of Event Management】</b> in Privilege Management function.	N/A

- SMS Queries Event: user can declar a query event, when the mobile number in the Control List of event send a query message, system will reply the special content to the mobile number.

🏠 SYSTEM > Event Management

### ☰ Event Management

Event Type



Add

Export Configure List

Import Configure List

浏览...

Query Name	Query Description	Query Content	Target Receiver	Operation
------------	-------------------	---------------	-----------------	-----------

Click "Add" button to create new queries event, Click "Export configure List" button to export the setting as a file and save to local PC. Click "Import configure List" button to import the setting from a file.

And, in the existing list, click "Details" to edit the existing event, click "Delete" button to delete the selected event. Click "Copy" to duplicate the event.

SYSTEM > Event Management

SMS Queries Event

Query Name

Query Description

Query Content

Target Receiver  Steven\_Li

3

Description	Default
<b>Query Name</b>	
Input an query name. The name shall be composed of numbers, English letters, and underline. The maximum string length is 9 characters. For example, after you create a query event name query1, you can send a message with content #MSG#query1 to device SIM card number, then it will reply you the content you setup in the event.	N/A
<b>Query Description</b>	
The query description shall be composed of numbers, English letters, uppercase and lowercase. The maximum string length is 50 bytes.	N/A
<b>Query Content</b>	
<p>Set up the information shown on the alarm contents. The content of the alarm will be sent to the target when alarm criteria are met. The information order can be self-defined.</p> <ul style="list-style-type: none"> <li><b>Time:</b> the time when the alarm occurred</li> <li><b>Date:</b> the date when the alarm occurred</li> <li><b>Name:</b> the name of the occurred alarm</li> <li><b>Description:</b> the description of the occurred alarm</li> </ul> <p><b>For example:</b> Register \$2048 represents electrical voltage, the value of register \$2048 is 10, and the alarm content is set as: {Date} {Time} Voltage = {\$2048}, then the query content received by users will be: 2016/06/01 10:00:00(currently time) Voltage = 10. The maximum content length is 95 characters.</p>	N/A
<b>Target Receiver</b>	
Set up the recipient. User can maintain the list by <b>【Control List Of Event Management】</b> in Privilege Management function. System only response the query from receiver list.	N/A

**Notice**

{ } is a special system symbol, which is used to reference system variables or system registers, like \${Time}, \${Date} or \${Number 0 - 4095}. Please use it with caution.

### 3.5.12 Register Management

This page is used for setting up the rules of register data upload to Cloud. Click “Add” to set a new rule. Click “Edit” to modify the existing rule. Click “Delete” to delete the existing rule.

SYSTEM > Register Management

	<a href="#">Add</a>	<a href="#">Export Configure List</a>	<a href="#">Import Configure List</a>	<a href="#">浏览...</a>	
ID	Register Start Address	Length	Upload To Cloud	History Data	
1	\$2048	10	Yes	No	<a href="#">Edit</a>   <a href="#">Delete</a>

The address segment M0~M511 and \$2048~\$4095 can be self-defined. The Start address, Length, Uploaded to Cloud or not and keep history or not can be set up.. After clicking “Add”, the following page will show up.

SYSTEM > Register Management

**Add**

Register Type	<input type="text" value="Word"/>	
Register Address	<input type="text" value="\$"/>	(\$2048-4095, M0-511)
Length	<input type="text"/>	
Uploaded To Cloud	<input type="text" value="Yes"/>	
Keep History	<input type="text" value="No"/>	

Description	Default
<b>Export Configure List</b>	
Export the configure list to the file and save to local PC	N/A
<b>Import Configure List</b>	
Open local file and import the configure list	N/A
<b>Register Type</b>	
Set up the register data type, options are “Word” and “Bit”.	Word
<b>Register Start Address</b>	
This rule will effect from which register address. For bit type the range is 0~511 and start with “M”, for word type the range is 2048~4095 and start with \$.	N/A

Description	Default
<b>Length</b>	
How many registers will be effect by this rule. For bit type the range is 1~512, for word type the range is 1~2048.	N/A
<b>Uploaded To Cloud</b>	
Whether to upload the variable information to Cloud.	Yes
<b>Keep History Data</b>	
This function will keep or overwrite the history data when the register values are uploaded to Cloud. <ul style="list-style-type: none"> <li><b>Yes:</b> The existed register values in the cloud <b>WON'T</b> be overwritten by the new uploaded register values.</li> <li><b>No:</b> The existed register values in the cloud <b>CAN</b> be overwritten by the new uploaded register values.</li> </ul>	No

**Notice**

When the values in the register changes, the results will be uploaded to cloud.

## 3.6 Cloud Service

### 3.6.1 Cloud Configuration

In this page, user can assign the cloud account which will be used to connect to DIACloud by device. Input the user name, the password and click "Verify". Refer to Chapter 4 for DIACloud account registration.

1. Login with your DIACloud account then click the "Verify" button to authenticate with DIACloud server.

[🏠 CLOUD SERVICE > Cloud Configurations](#)

#### ☰ Cloud Configurations

User Name:

Password:

2. After authentication successfully, the cloud configurations will show up then the user can modify the secure tunnel and device name.

🏠 CLOUD SERVICE > Cloud Configurations

### ☰ Cloud Configurations

User Name:

Password:

Secure Tunnel:  ▼

Device Name:

Secure Tunnel DHCP: Not available

When DHCP server in the secure tunnel network is not available, the IP address of the secure tunnel will be the LAN IP, if you want to change it ,please go to LAN configuration web page

Device IP:

Network Protocol:  ▼



3. The user also can set IP address manually.

Get IP From Cloud  ▼

Cloud IP Range: 192.168.200.100 - 192.168.200.200

Cloud Netmask: 255.255.255.0

Device IP:


( Device IP should be in the same subnet with cloud IP )

4. Click the "Bind" button, the DX router will bind with DIACloud server and established a secure tunnel between DIACloud server and the DX router. Meanwhile a new IP will assigns to DX router from DIACloud server (assign from the cloud HDCP server or a user specified).

🏠 CLOUD SERVICE > Cloud Configurations

Cloud account register success, starting  
secure tunnel,please wait.....

5. Your browser will access to the DX router with new IP address automatically if DIACloud account binds with DIACloud server successfully. Please make sure a PC and DX router are in the same subnet; otherwise PC will not be able to access to the DX router.



3

- 6. If the network is in the poor condition, The binding process could be successfully but the Service Status is shown "Disable".

🏠 CLOUD SERVICE > Cloud Configurations

User Name:	██████████5@163.com	
Registration Status:	Registered	<input type="button" value="Unbind"/>
Service Status:	Disabled	<input type="button" value="Enable"/>
Secure Tunnel:	default	
Device Name:	DX2100_E9A4	
Secure Tunnel DHCP:	Not available	
Device IP:	192.168.5.5	
Network Protocol:	<input type="text" value="UDP"/>	

- 7. In this situation, the browser will access with 192.168.1.1 and the service status will be "Disable". You can re-enable the service status to rebuild the secure tunnel again in cloud configurations.

8. When the service status is shown “Enable”, that means the DIACloud service is activated on DX router. The user also can get the related information in cloud platform.

 [CLOUD SERVICE](#) > [Cloud Configurations](#)

User Name:	██████████@163.com	
Registration Status:	Registered	<a href="#">Unbind</a>
Service Status:	Enabled	<a href="#">Disable</a>
Secure Tunnel:	default	
Device Name:	DX2100_E9A4	
Secure Tunnel DHCP:	Not available	
Device IP:	192.168.5.5	
Network Protocol:	UDP	

9. Click the “Unbind” button, DX router will remove the registered account in DIACloud.

Description	Default
<b>User Name</b>	
Set up the name for the DIACloud account.	N/A
<b>Password</b>	
Set up the password for the account.	N/A
<b>Verify</b>	
Check if the username and the password are matched.	N/A
<b>Secure Tunnel</b>	
Select the device under the account to join in a certain secure tunnel network group. For secure tunnel related settings, go to <a href="http://www.DIACloudsolutions.com/">http://www.DIACloudsolutions.com/</a>	Default
<b>Device Name</b>	
Set up the name for the device	N/A
<b>Secure Tunnel DHCP</b>	
When secure tunnel DHCP server is available, and the IP address is allocated by the DHCP server in secure tunnel network, the IP address of this device can be found in the cloud portal.	N/A
<b>Get IP From Cloud</b>	
When selecting “Yes”, IP address can be obtained by the cloud. When selecting “No”, the IP address can be manually set.	Yes
<b>Network protocol</b>	

Description	Default
Set the network protocol of the security tunnel. Options are TCP and UDP. <ul style="list-style-type: none"> <li><b>UDP:</b> UDP has a faster data transfer speed. If the network is not lost packet, please use this option</li> <li><b>TCP:</b> When the network packet loss is serious, it is recommended to select TCP. After binding the cloud account, you can still change this option, but you must disable the cloud service before changing. When the agent is turned on, the user can only select TCP.</li> </ul>	UDP
<b>Cloud IP Range</b>	
Display the Cloud IP Range. The Cloud IP Range is depended on the secure tunnel setting. For the secure tunnel setting, please refer to 5.2.5 Tunnel Network.	N/A
<b>Cloud Netmask</b>	
Display the Cloud Netmask. The Cloud Netmask is depended on the secure tunnel setting. For the secure tunnel setting, please refer to 5.2.5 Tunnel Network.	N/A
<b>Device IP</b>	
User can assign an IP address manually; remember that IP address should be the same subnet as the secure tunnel setting. For the secure tunnel setting, please refer to 5.2.5 Tunnel Network.	N/A

### Notice



- Users can log-in to <http://www.DIACloudSolutions.com/> and register for a DIACloud account.
- In rare case, you can't access the web because the computer did not refresh the IP and DNS after the activation, please re-plug the cable to resolve the issue.

### 3.6.2 Proxy Setting

If the user's networking environment requires outbound network connections to go through a HTTP or HTTPS proxy, user can setup it in here.

**Proxy Setting**

HTTP Proxy

Proxy Addr

Proxy Port

Proxy Username

Proxy Password

Save And Test

Description	Default
<b>HTTP Proxy</b>	
Enable or disable the http proxy	Disable
<b>Proxy Addr</b>	
Set up the domain/IP of the proxy server	N/A
<b>Proxy Port</b>	
Set up the port of the proxy server	N/A
<b>Proxy Username</b>	
Set up the user name to login the proxy server	N/A
<b>Proxy Password</b>	
Set up the password to login the proxy server.	N/A
<b>Save and Test</b>	
Save the configuration and test to connect to the DIACloud.	N/A

**3.6.3 Tunnel Firewall**

In this page, user can set up the firewall for the secure tunnel.

🏠 CLOUD SERVICE > Secure Tunnel Firewall

☰ Multicast Setting

Allow Multicast In Secure Tunnel

☰ Firewall Settings

Firewall Of Secure Tunnel

ID	MAC Address	Operation
----	-------------	-----------

3

🏠 CLOUD SERVICE > Secure Tunnel Firewall

☰ Add A MAC Address

MAC Address

Description	Default
<b>Allow multicast in secure tunnel</b>	
Set the security tunnel, whether to allow multicast transmission of the nature of the packet. <b>Options:</b> Allowed, not allowed	Yes
<b>Firewall of secure tunnel</b>	
Set up the specified MAC device will be allow or forbid to transmit the data in the secure tunnel. Options as below: <ul style="list-style-type: none"> <li>• <b>Disable:</b> Disable this function.</li> <li>• <b>Black List:</b> If the network device's MAC address is blacklisted, these devices will <b>NOT</b> be able to transmit packets to the secure tunnel</li> <li>• <b>White List:</b> If the network device's MAC address is blacklisted, these devices will be able to transmit packets to the secure tunnel.</li> </ul>	Disable
<b>Add</b>	
Add a new MAC address into the list.	N/A

### 3.6.4 Cloud Log

Any information about cloud event can be exported from this function

🏠 CLOUD SERVICE > Cloud Log

### ☰ Cloud Log Level

Cloud Log Level

Error ▼

Save

Cloud log level will take effect when you restart the relative module.

### ☰ Download Cloud Log

Select The Module:

Uploader ▼

Download

Description	Default
<b>Cloud Log Level</b>	
<p>You can set different levels of log messages and saved to export to the engineering staff to view. Options as below (Level from low to high):</p> <ul style="list-style-type: none"> <li>• <b>Trace:</b> The TRACE Level designates finer-grained informational events than the DEBUG</li> <li>• <b>Debug:</b> Fine-grained informational events that are most useful to debug an application</li> <li>• <b>Info:</b> The INFO level designates informational messages that highlight the progress of the application at coarse-grained level.</li> <li>• <b>Warm:</b> The WARN level designates potentially harmful situations.</li> <li>• <b>Error:</b> The ERROR level designates error events that might still allow the application to continue running.</li> <li>• <b>Fatal:</b> The FATAL level designates very severe error events that will presumably lead the application to abort.</li> </ul>	<p>Error</p>
<b>Select Log Level</b>	
<p>Specify to download the cloud service module log. Options as below:</p> <ul style="list-style-type: none"> <li>• Uploader: Data upload module</li> <li>• Secure Tunnel: Secure Tunnel module</li> <li>• Binding: Account binding module</li> </ul>	<p>Uploader</p>

## 3.7 Quick Operation

DX-3021L9 provides the multiple quick operation via USB interface.



- Upgrade the router firmware
- Import the router configuration
- Active the router with the DIACloud account.


The quick operation will trigger by the following file is created in the USB drive after the DX-3021L9 reboots:

- The upgrade-package file 'DX3021\_UpgradeImage\_NorFlash\_xxxx\_xxxx.bin'

- The device configuration files 'backup.cfg'. (Please refer 3.4.8 Backup & Restore)
- The cloud configuration file 'Provision.bin' (Please refer to the following steps).

Follow below steps, show how to quick bind DIACloud account for the router automatic.

1. Go to the DIACloud platform (DIACloudSolutions.com).
2. Log in the DIACloud webpage and click "SECURE TUNNELS"
3. Click to select the Network which you'd like to use and then click the  to see and check the details.
4. Click the  to download the generated Provision.bin to the local computer.



#	Network Name ↑	DHCP	DHCP IP Range	Data	Status	Operation
1	test	Disable	192.168.200.100 192.168.200.200	1.90 GB	Normal	...

Total 1 virtual network(s)



Network Name

default

DHCP



DHCP IP Start

5. Copy Provision.bin file to USB drive.
6. Power off the device and then insert the USB drive into the device. Turn on the device and it will automatically bind. Check the status indicator to see if the binding is successful.

The following beep codes are for Quick Configurations, its definition that the various combinations of the configuration file exist on USB drive. (x – fail, √ - success or not this operation)

Beep Code	Upgrade firmware	Import config	Bind account
1 long	x	√	√
1 long, 1 short	√	x	√
1 long, 2 short	x	x	√
1 long, 3 short	√	√	x
1 long, 4 short	x	√	x
1 long, 5 short	√	x	x
1 long, 6 short	x	x	x

None	√	√	√
------	---	---	---

**Notice**



- Please do not change the file name of firmware upgrade-package.
- Please do not create the two different upgrade-package files in USB drive. In order to avoid the upgrading process fails.
- At least a 10-minute interval of separation between the twice quick configuration

---


## Chapter 4 DIACom

### Table of Contents

<b>4.1</b>	<b>Introduction to DIACom</b> .....	<b>4-2</b>
4.1.1	Select a Suitable Firmware Version .....	4-2
4.1.2	DIACom Installation.....	4-3
4.1.3	DIACloud Account Registration .....	4-3
4.1.4	Bind DIACloud Account.....	4-5
<b>4.2</b>	<b>DIACom Operation</b> .....	<b>4-6</b>
4.2.1	Setup a Secure Tunnel .....	4-6
4.2.2	Create a Virtual Serial-Port .....	4-10
4.2.3	Remote Control and Monitoring via DIACom .....	4-11
4.2.4	Automation Startup .....	4-13

## 4.1 Introduction to DIACom

DIACom allows you to create a secure tunnel between your PC and router, making it possible for your PC to communicate remotely with the devices connected to the router. Thus engineers can control, monitor, operate, program and diagnose the device remotely whenever there is internet connectivity.



### Notice



- DIACloud provides you with cloud services, including the connected device management, secure tunnel network creation, data upload/download, and directional transmission.
- If you need to configure or monitor your controller, you will need to install programmable logic controller software, for example WPLSoft/ISPSOft for Delta PLC.

### 4.1.1 Select a Suitable Firmware Version

Find a suitable DIACom firmware version according to the following table below for your router.

**Corresponding Table:**

Device Model	Firmware Version
DX-2100	V1.3.3.0 or above
DX-2300	V1.3.3.0 or above
DX-3021	V1.5.0.0 or above



### Notice

If the device firmware is lower than 1.3.3.0, please use DIACom 1.2.8.0 or lower.

## 4.1.2 DIACom Installation

Obtain the DIACom firmware package from the official website or from our sales representative. Administrator privileges are required to run and install the package. Uninstall older versions of DIACom before downloading new DIACom firmware package.



### Notice

DIACom supports Windows XP, Windows 7 (32-bit and 64-bit) and Windows 8 (32-bit and 64-bit).


## 4.1.3 DIACloud Account Registration

1. Before registration, you should have a valid email account. (DIACloud uses your email address as your account.)
2. Open the DIACloud web page (<http://www.DIACloudSolutions.com>). The system will redirect you to the registration page:

The screenshot shows the DIACloud web interface. At the top, there's a blue header with the 'DIACloud' logo on the left and a globe icon on the right. Below the header is a white registration/login form. The form includes an 'Email \*' field with a red underline, a 'Password \*' field with a red underline, a 'Remember Me' checkbox which is checked, and a 'LOGIN' button. At the bottom of the form area, there are two links: 'CREATE AN ACCOUNT' and 'FORGOT PASSWORD?'. The entire page has a blue background.



### Notice

\*Click  at the upper right corner to change the interface language to English.

3. Input your email address, password and other relevant information on the registration page. Select "I Agree" and click "CREATE AN ACCOUNT".

**DIA Cloud**

Email \*

Password \*

Confirm Password \*

Person  Enterprise

Name \*

Country


Verification Code \* 6E216

I Agree **AGREEMENT**


CREATE AN ACCOUNT

Already have an account? **LOGIN**

4. After clicking “CREATE AN ACCOUNT”, a congratulation page will be prompted and an activation email will be sent to the email address you have used as your DIA Cloud account.



5. You will find an activation email sent from [no-reply@diacLOUDSOLUTIONS.COM](mailto:no-reply@diacLOUDSOLUTIONS.COM) in your email box. Open the email, click “here” link in the email and complete DIA Cloud account activation operation. And you will be redirected to the DIA Cloud login page. Input your account and password to log in to the DIA Cloud.




#### 4.1.4 Bind DIACloud Account

Follow the steps blow to bind your DIACloud Account.

1. Local Network Setups: Please refer to Chapter 2.1 to 2.1.3 Web-based GUI Configuration for more information.
2. Bind DIACloud Account: Please refer to Chapter 3.5 Cloud Service for more information.

**Notice**

- **Secure Tunnel:** Secure tunnel is a virtual network. Users can set up several groups of secure tunnel for easier device management.
- **Device Name:** the serial number + “\_” + “Mac address” of the device is the device name by default.
- **Get IP From Cloud:**
  - When selecting “Yes”: The system will assign an IP address for the device according to the Secure Tunnel settings and the availability of the IP addresses. Take note of the assigned IP address, it will be used when logging to the DIACloud.
  - When selecting “No”: The IP address can be manually set.



Secure Tunnel DHCP:	Available
Get IP From Cloud	<input type="button" value="No"/> ▾
Cloud IP Range:	192.168.200.100 - 192.168.200.200
Cloud Netmask:	255.255.255.0
Device IP:	<input style="width: 100%;" type="text"/>

( Device IP should be in the same subnet with cloud IP )


The IP address of the DX-2100 Series and the WAN of your connected PC should be in different network segments.

## 4.2 DIACom Operation


### 4.2.1 Setup a Secure Tunnel

Make sure there is internet connectivity, before creating a secure tunnel between your local PC and router via the DIACom. Http Proxy and Port Agent are configurable in DIACom network setting function, you can set it to avoid the possible limitation.


1. Run DIACom and log in with your router's cloud account.



2. Click  to go into network setting page if need be.




- **Http proxy:** Please fill in the proxy server address, port, username and password if the LAN needs to set the proxy to access the Internet. Click "Save" button to enable the config.
- **Diagnose:** The user can click the Diagnostic button to test the current internet settings, whether to connect to the DIACloud server



**Notice**

- DIACom will automatically determine whether the port agent needs to enable.
- Make sure that the external network port 80 and port 443 are opened and can access any network domains and IP addresses

- After the login is successful, the software displays the security tunnel page. The security tunnel list is displayed on the left side of the page, and the network information of the security tunnel and the device list are displayed on the right. Users can choose to use DHCP or manually set the cloud IP address
  - **DHCP:** Obtain an IP address from Cloud automatically when Cloud DHCP function is available.
  - **Static:** Manually set the IP address, the IP should be in the same subnet with DX device




## Notice

If it is found that the static IP address is configured from DIACom, the IP address of the local IP address in the bottom right corner will be different from the original setting. Please change according to the following settings.


1. Go to Network and Sharing Center and click on the DIACom Ethernet Adapter for your network connection.



2. Right-click, then click Properties.
3. Click the Networking tab. Under This connection uses the following items, click either Internet Protocol Version 4 (TCP/IPv4) .



4. Set the IP address of the local computer manually. However, you'll need to make sure there are no IP conflicts.



4

4. After the configuration is complete, click the Create Tunnel button to establish a connection with the specified tunnel.
5. The following information is displayed: tunnel connection status, local delay to the DIACloud cloud server, and the IP address used by the local virtual network adapter. The details are as follows:

Status	Name	SN	Latency	IP Address	Operation
Online	DX2100_958B	DX21000518050274	118 ms	192.168.10.10	
Online	DX3021_C888	DX30210119270027	3 ms	192.168.10.50	
Offline	DX2300_8C8B	DX23000316180001	-	192.168.10.40	
Offline	DX2100_E988	DX21000216140003	-	192.168.10.30	

Secure tunnel is set up. 168 ms Local IP Address 192.168.10.2

6. After successful connection with the cloud, the local computer will be able to use debugging tools or monitoring software to debug, monitor, and program the remote network interface

devices. In addition, you can remotely configure the router's router page (click the device in the device list Of the IP address) of the router for remote configuration.

### Notice



- You can create different groups of secure tunnels, divide different devices into groups according to their needs, and implement group management devices
- To avoid the virtual network card IP network segment and the local computer network card of the actual network to avoid the same network conflict
- After the secure tunnel is successfully connected, you must first disconnect the current connection to select another security tunnel,

## 4.2.2 Create a Virtual Serial-Port


To debug a remote serial device, click the icon  at the back of the corresponding remote device to enter the Create Virtual Serial Interface

Status	Name	SN	Latency	IP Address	Operation
Online	DX2100_958B	DX21000518050274	118 ms	192.168.10.10	
Online	DX3021_C888	DX30210119270027	3 ms	192.168.10.50	
Offline	DX2300_8C8B	DX23000316180001	-	192.168.10.40	
Offline	DX2100_E988	DX21000216140003	-	192.168.10.30	

The latest device firmware (V1.3.3) supports RS-232 and RS-485 at the same time in the transparent mode, the interface as shown below:

### Notice

- If the device's RS-232 / RS-485 is not operating in Transparent mode, the corresponding button is grayed out.
- DIACom will prompt an error message if the FW version of DX is under V1.3.3.



- When RS-232 or RS-485 works in Transparent mode, click on the [Create Serial Port] button on RS-485 to create a virtual serial port.

## 4.2.3 Remote Control and Monitoring via DIACom

### 4.2.3.1 Via a LAN Port


If your router is connected to remote devices via a LAN port, you can use the configuring/monitoring software on your local computer to configure and monitor after opening a virtual tunnel. Some program would require the IP addresses of your remote device. Simply input the required information in the configuring/monitoring software and then you can configure and monitor the connected device remotely.

### 4.2.3.2 Via a RS232/RS485 Port


After opening a virtual tunnel, you will need to follow the setups below before using WPLSoft or other configuring/monitoring software on your local computer to configure and monitor the connected device remotely.

1. Click IP address in the DIACom device list or open a browser and input the IP address of the router which is connected to your remote device on the search bar and then log in.
2. Go to the System setup page, select the setup option RS232 or RS485 and input the required information to set up. Make sure the parameters are consistent with your remote device.
  - Working Mode : Transparent mode
  - Parameters of COM (Baud Rate, Data Bits, Stop Bits, Parity Bits, Flow Control)


Working Mode	<input type="text" value="Transparent mode"/>
Baud Rate	<input type="text" value="9600"/>
Data Bits	<input type="text" value="8"/>
Stop Bits	<input type="text" value="1"/>
Parity Bits	<input type="text" value="Even"/>

3. Go back to the DIACom and click  to create a virtual tunnel. Once the creation is done, the virtual serial-port number will show up on the same page. Users can use it to configure and monitor the connected device remotely. Click “Delete” to delete the virtual serial-port.

**Notice**


 If the PLC is Siemens S7-200, you can select the “PPI” in the DIACom to support PPI protocol.


4. Open the WPLSoft to check if the COM parameters are consistent with the settings on your router. When these parameters are consistent, you can use the WPLSoft to configure/monitor your device remotely.



#### 4.2.4 Automation Startup

The user can set Automation Startup for DIACOM, The setting steps see blow.

1. Login to DIACom.
2. Click on the icon button  in the upper right corner of the windows, and select "Settings".
3. Boot automatically log in the required configuration is as follows. Users can set according to your needs. If you only need DIACom to connect the security tunnel automatically, the device list, RS-485 and RS-232 do not need to be set.



4. Check " Start DIACom on windows logon ", and click "OK" button to save the settings.

**Notice**



- Login must be checked "remember password", otherwise DIACom can not be activated automatically
- Confirm that the IP / Serial Port settings do not cause conflicts

---

## Chapter 5 DIACloud

### Table of Contents

<b>5.1</b>	<b>Introduction to DIACloud .....</b>	<b>5-2</b>
5.1.1	Select a Suitable Firmware Version .....	5-2
<b>5.2</b>	<b>Instructions for DIACloud.....</b>	<b>5-2</b>
5.2.1	Register and Login .....	5-2
5.2.2	Home.....	5-4
5.2.3	Devices .....	5-6
5.2.4	Alarm.....	5-17
5.2.5	Secure Tunnels.....	5-17
5.2.6	Sub Users .....	5-19
5.2.7	Logs .....	5-22
5.2.8	Orders.....	5-23
5.2.9	Profile .....	5-24

## 5.1 Introduction to DIACloud

DIACloud Web is a web portal of DIACloud cloud platform. Users can check the status of connected industrial device through DIACloud Web, browse data that has been collected, receive warnings, notices and other messages that are sent by cloud platform, create and manage sub-account and virtual safety network and check login and interface logging, to improve the manageability of devices, optimize the device performance and efficiency, save the operation cost and enhance the service quality.

### 5.1.1 Select a Suitable Firmware Version


Please confirm that your Firmware version of router meets the requirements in the following table before use:

Device Model	Firmware Version
DX-2100	V1.3.0.1 or above
DX-2300	V1.0.0.1 or above

## 5.2 Instructions for DIACloud



### 5.2.1 Register and Login


1. Open the DIACloud web page (<http://www.DIACloudSolutions.com>). If you have got an account, input your account and password in the following page to log in; if you have not got an account, click "CREAT AN COUNT" to register. Then the system will redirect you to the registration page:



2. Input your email address, password and other relevant information on the registration page. Select "I Agree" and click "CREATE AN ACCOUNT". Pls insure your region information is correct, otherwise it maybe cause problem in payment when you extend your service.


**Notice**

 Click  at the upper right corner to change the interface language to English or Chinese.



The screenshot shows the DIACloud account creation interface. It features a blue header with the 'DIACloud' logo. Below the header, there are several input fields: 'Email \*', 'Password \*', 'Confirm Password \*', 'Name \*', and 'Country'. There are also radio buttons for 'Person' and 'Enterprise' (selected), and a 'Verification Code \*' field with a sample code '61MIU'. At the bottom, there is a checkbox for 'I Agree' with a red 'AGREEMENT' link, and a grey 'CREATE AN ACCOUNT' button.

3. After clicking "CREATE AN ACCOUNT", a congratulation page will be prompted and an activation email will be sent to the email address you have used as your DIACloud account.



4. You will find an activation email sent from [no-reply@DIACloudSolutions.com](mailto:no-reply@DIACloudSolutions.com) in your email box. Open the email, click "here" link in the email and complete DIACloud account activation operation. And you will be redirected to the DIACloud login page. Input your account and password to log in to the DIACloud.

**Activate your account on DIACloud**

发件人: DIACloud<no-reply@diacLOUDSOLUTIONS.COM>

收件人: 我<steven8160@163.com>

时间: 2016年05月11日 11:07 (星期三)

Dear User,

Please complete your registration by following the link below:

<http://www.diacLOUDSOLUTIONS.COM/#/activate?n=steven8160%40163.com&t=fM1xduuNyNZSo4NNyVQCUX5ACGrO5II>

Please activate your account within 48 hours, otherwise you need to re-create your account.

If you did not register recently, or believe you have received this email in error. Please disregard this message.

请点击下面的链接完成注册:

<http://www.diacLOUDSOLUTIONS.COM/#/activate?n=steven8160%40163.com&t=fM1xduuNyNZSo4NNyVQCUX5ACGrO5II>

请在48小时内激活您的账号, 否则您需要重新注册。

如果该账号不是您本人注册的, 请忽略本邮件。


Thanks!





The DIACloud Team

5. Open the DIACloud web page (<http://www.DIACloudSolutions.com>). Log in using your account that you have registered.


### 5.2.2 Home

The Home Page will show up after login.



Item	Description
Menu	User can switch to corresponding function through menu on the left.
Devices Total	The number of total devices
Devices is Online	The number of total online devices
Alarms in 24 Hours	The number of alarms in Recently 24 hours
Secure Tunnel is Usable	It will show the number of Secure Tunnel groups under the account.
	Switching among the Chinese and English
	Show the service package you selected, user can add package to shopping cart through Devices function and Profile function.
	Show the alarm message(s) in latest 7 days
	Show the profile or logout

Online payment process as below:

1. After click , it will show the detail information in shopping cart.

Shopping Cart
🔄

#	Package Name	Unit Price	Number	Price	Operation
1	<b>DX-Service-T1GB-WW</b> ( SN : DX21000216140002 ) Data traffic fee of 1-year package for 1G bytes extra traffics per month between device and DIACloud	\$ 0.01	4	\$ 0.04	🗑️
2	<b>DX-Service-S1MB-WW</b> Cloud Storage fee of 5-years package for 200MB storage space in one account	\$ 0.01	1	\$ 0.01	🗑️

Total 2 item(s) in Cart
Total Price **\$ 0.05**
CHECKOUT

2. Click CHECKOUT to generate an order. DIACloud provides the follow types of invoices.
  - No need For Invoice
  - Electric Invoice
  - Paper Invoice

**Confirm Order**

---

**Order Detail**

DX-Service-T1GB-CN ( SN : DXR02010F270086 )	¥200	x1
---	------	----

Total Price: **¥ 200**

**Invoice**

No need for Invoice  
  Electric Invoice  
  Paper Invoice

Invoice Title(The name of your company) \*

---

Email \*


---

[BACK TO CART](#)  
 [CONFIRM ORDER](#)

3. Click [CONFIRM ORDER](#), we accept PayPal payments and process credit cards on your order forms.

**Payment Method**

Total to pay now **\$ 0.05**



[PAY NOW](#)








### 5.2.3 Devices



It will switch to page of device list after clicking “Devices” in navigation bar.


#	Status ↓	Device Name	SN	Device Type	Storage Usage	Data Usage	Created	Operation
1	online	DX2100_B0B4	DXR02010F210059	DX2100	0.00 MB	0.00 MB	2016-10-17 09:09	...
2	offline	DX2100_F0D3	DXR02010F270038	DX2100	0.00 MB	0.00 MB	2016-07-22 12:36	...
3	offline	DX2300_894D	DX23000216260012	DX2300	0.00 MB	0.00 MB	2016-07-28 22:31	...
4	offline	DX2300_89AB	DX23000216260059	DX2300	0.00 MB	0.00 MB	2016-09-08 13:34	...
5	offline	DX2300_894B	DX23000216260011	DX2300	0.00 MB	0.00 MB	2016-11-14 10:54	...
6	offline	sey1	DX23000216260048	DX2300	0.00 MB	0.01 MB	2016-11-18 15:16	...

Total 6 Device(s)



Item	Description
<input type="text" value="Search"/>	You can filter the device base on you input the key word of the device name.

 All	Filter base on tunnel group, show all devices or only show the devices under user specified tunnel group.
Devices List	Show the list of device. The information include device's name, device's SN, device's type, storage usage, data usage, the time of binding device. <ul style="list-style-type: none"> <li>Green represents that the device is on-line</li> <li>Gray represents the device is off-line.</li> </ul>
	<ul style="list-style-type: none"> <li> : Represents that all device is displayed currently, and you can switch to on-line device list after clicking this icon.</li> <li> : Represents that on-line device is displayed currently, and you can switch to list of on-line device after clicking this icon.</li> </ul>
	Show relevant position information of device.
	Refresh pages
	Show detail information of the device


-  : It will show relevant position information of device after you click "", which is shown as follows:






It will show the device name and SN of the device after clicking position icon in the map. When there is large number of device of user, it will switch to corresponding device when user clicks blue arrows at the edge of the map.


-  : More detail information about device will be shown after clicking  under the "Operation" at the most right side of device list:


- OVERVIEW:** The page will show the basic information of the device and latest alarm message.






5

Item	Description
Operation zone of device	<p>It represents that device is on-line if background color is blue, and device is off-line if it is gray.</p> <ul style="list-style-type: none"> <li>  : Show device names; it can switch device after clicking the drop down arrow.                     </li> <li>  : Realize refresh of device data on operation page.                     </li> <li>  : Close the operation page.                     </li> </ul>
Page switching	<p>Operation is divided into 4 pages:</p> <ul style="list-style-type: none"> <li>Overview</li> <li>Registers</li> <li>Package</li> <li>More</li> </ul> <p>Different buttons are used to switch different paggers.</p>
Basic information zone	<p>Basic information is shown in Overview page.</p> <ul style="list-style-type: none"> <li><b>IP Address:</b> it means the IP that has been bound for device;</li> <li><b>Tunnel Network:</b> it means virtual network that has been bound to device;</li> <li><b>Boot Time:</b> it means the boot time of device;</li> <li><b>RS232 Mode:</b> work modes of RS232, including transparent transmission mode and slave station mode;</li> <li><b>RS485 Mode:</b> work modes of RS 485, including transparent transmission mode, slave station mode and master station mode;</li> <li><b>Modbus TCP:</b> work modes of Modbus TCP, including Modbus TCP Server,</li> </ul>

	<p>Modbus TCP Client and Closed</p> <ul style="list-style-type: none"> <li>● <b>RSSI:</b> it means signal strength of device which contains 5 bars; the larger the number of green bars is, the stronger the signal strength is;</li> </ul>
Latest Alarms	<p>The latest five Alarm of the current device. “ <p>2. <b>REGISTER:</b> The page will show and manage register value that uploaded from DX production.</p> </p>




5

Item	Description
 Search	The filtering function displays a list of keywords that match specific register.
	Click  and add the corresponding register and register value, then click “SAVE” button. DIACloud server will send the corresponding data to the device.
< 1/205 >	“<” Pervious page · “>” Next page · “1/205” show the current page of register table and the total amount of register table page.
Register Table	Show the register table, registers show a maximum of 10 posts per page.
Register Name	Show the register name, when you do not make an alias configuration in the register, the register number is displayed; an alias configuration in the register will be displayed after you configure the alias

Register Value	Show the current register value and data transfer time.
⋮	<p>You can view the current register of historical data or delete the current register; it can also be configured register.</p> <p>P.S. If this register is not set to remember history (device configuration page), the menu does not appear [History] after clicking ⋮ icon.</p>


The History and Config options will be shown after clicking ⋮





5

Item	Description
History	It represents trend chart of historical data
Delete	User can delete the all data of this register
Config	User can customize name of register and content returned.

- **History** : The following figure will be shown after clicking “History”:



Item	Description
Date Start	Set the Date Start and query the historical data for a specific time
Date End	Set the Date End and query the historical data for a specific time
Register Value History Diagram	The latest trend chart of value of register;
Time Axis	User can change time scope of historical data by sliding “  ”.
	Export the data to XLS.file.

- **Config** : The following information will be shown after clicking “Config”

Register Configuration
✕

Register Address  
2050

---

length  
Word ▼

Alias Name \*  
\$2050

---

function(val) {  
JavaScript Template  
return val;  
}

---


<
>

SAVE

Item	Description						
Length	<p>Length can be set to Word, DWord and Float.</p> <ul style="list-style-type: none"> <li> <b>DWord:</b> DWord needs to use two DX internal registers. For example: \$2050 and \$2051 are set to DWord and it will combin to \$2050, \$2050 will be <b>LOW Byte</b> and \$2051 will be <b>HIGH Byte</b>.                             <div data-bbox="371 488 1126 645" style="border: 1px solid black; padding: 5px; margin: 5px 0;"> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 30%; padding: 2px;">\$2050</td> <td style="width: 30%; padding: 2px;">786447 </td> <td style="width: 40%; padding: 2px;">2017-08-14 11:33 </td> </tr> <tr> <td style="border-top: 1px solid black; padding: 2px;">\$2052</td> <td style="border-top: 1px solid black; padding: 2px;">233 </td> <td style="border-top: 1px solid black; padding: 2px;">2017-08-07 09:06 </td> </tr> </table> </div> </li> <li> <b>Float:</b> Float needs to use two DX internal registers. For example: \$2050 and \$2051 are set to DWord and it will combin to \$2050, \$2050 will be <b>LOW Byte</b> and \$2051 will be <b>HIGH Byte</b>.                             </li> </ul>	\$2050	786447	2017-08-14 11:33	\$2052	233	2017-08-07 09:06
\$2050	786447	2017-08-14 11:33					
\$2052	233	2017-08-07 09:06					
Alias Name	The user can set the name of the register to be displayed in the "Alias Name"						
function(val)	function(val) is used for convert the register value, and the grammar of function-supported JavaScript is similar.						


**There are two examples for “function (val)”.**

- Example 1 :** If you want to show the wind speed as 10m/s. (Data +unit, such as: speed 10m/s).  
 Input the code: **return val+"m/s"** in function (val){...} as the following picture and save the configuration.



- **Example 2:** If you want to convert the register value to the text such as the register value of 1 shows the text as 'NO'; register value of 2 shows the text as 'OFF'

Input the code in function (val) {...} as the following picture and Click "Save" button.



Register Configuration

Register Address  
2050


length  
Word

Alias Name\*  
Y0

```
function(val) {  
  JavaScript Template  
  if(val==1) return "ON";  
  if(val==2) return "OFF";  
}
```

SAVE

3. **SERVICES:** This page shows the Device Data Usage, Device Storage Usage and Account Storage Usage for users.



5


Item	Description
Data	<ul style="list-style-type: none"> <li>• <b>Device Data Usage:</b> Show device traffic usage till now and total capacity.</li> <li>• <b>Account Traffic Usage:</b> <ol style="list-style-type: none"> <li>1. Account traffic is the total amount of traffic showing additional purchases.</li> <li>2. Account traffic can be shared with all devices under your account.</li> <li>3. Before the device traffic is exhausted cloud traffic, the account traffic will not be used.</li> </ol> </li> <li>• <b>BUY</b>: User can purchase more traffic package for this account if need. After successful payment, the moment is ready for use.</li> <li>• <b>HISTORY</b>: Show the Data Usage History in past 12 months.</li> </ul>
Storage	<ul style="list-style-type: none"> <li>• <b>Device Storage Usage:</b> Show device storage usage till now and total capacity</li> <li>• <b>Account Storage Usage:</b> <ol style="list-style-type: none"> <li>1. Account storage is the total amount of traffic showing additional purchases.</li> <li>2. Account storage can be shared with all devices under your account.</li> <li>3. Before the device storage is exhausted storage space, the account storage will not be used.</li> </ol> </li> </ul>

- **BUY**: User can purchase more traffic package for this account if need. After successful payment, the moment is ready for use.

- After Click the **BUY** in Data field, it will show the traffic package select page. User can add a package to cart or pay it direct.

The screenshot shows a modal window titled "Add To Cart" with a close button (X) in the top right corner. The main content area is divided into two columns. The left column displays the package details: "DX-Service-T1GB-WW", "Data traffic fee of 1-year package for 12G bytes extra traffics one year between device and DIACloud", "Unit Price: \$ 0.01", and "Expired: 2018-08-14". The right column contains a form with a "Package Name" dropdown menu set to "DX-Service-T1GB-WW", a "Number \*" input field with the value "1", and a "CHECKOUT" button. At the bottom right of the modal, there are two buttons: "ADD TO CART" (highlighted in red) and "CHECKOUT".

- After Click the **HISTORY**, it will show the Data Usage History in past 12 months.



- After Click the **BUY** in Storage field, it will show the storage package select page. User can add a package to cart or pay it direct.

Add To Cart
✕

**DX-Service-S1MB-WW**

Cloud Storage fee of 5-years package for 200MB storage space in one account

Unit Price: \$ 0.01

Expired: 2022-08-13

Package Name

DX-Service-S1MB-WW ▼

Number\*

1

ADD TO CART
CHECKOUT

4. **MORE:** This page will show the Serial Number, Software Version, Hardware Version, and IMEI for users.

DX2100\_B0B4 ▼
↻
✕

OVERVIEW
REGISTERS
SERVICES
MORE


Serial Number	DXR02010F210059
Software Version	DX2100WW-1.3.3.1-2016-11-14
Hardware Version	DX2100 v3
IMSI	466974400866952










DELETE

Item	Description
Serial Number	Serial number of device
Software Version	Version information of software
Hardware Version	Version information of hardware
IMSI	International Mobile Subscriber Identification Number.
<span style="background-color: #ff5722; color: white; padding: 5px 15px; border-radius: 5px;">DELETE</span>	Delete binding relationship between device and the account. Device needs to be un-bund after clicking this button, and user can

	recover the device by rebinding.
--	----------------------------------


## 5.2.4 Alarm

Click the Alarm in the left menu. The warning information in the latest 7 days will be shown in this page. The warning information includes name and serial number of device, content of warning, status of email that is being sent (green“” represents that the email has been sent successfully, and red represents fail.), time of warning and content record of warning.

#	Device Name	Alarm Message	Status	Created
1	VFDControl DXR02010F210059	!!!!!!!!WARNING!!!!!!!!!!!! VFD Status : Emergency Stopped Time : 2016/03 /1418:18:28 MS300 has been stopped, please contact the relevant member!!!		2016-03-14 18:18:31
2	VFDControl DXR02010F210059	!!!!!!!!WARNING!!!!!!!!!!!! VFD Status : Emergency Stopped Time : 2016/03 /1418:16:25 MS300 has been stopped, please contact the relevant member!!!		2016-03-14 18:16:41
3	HMI DXR02010F210039	0 1 2016/03/14 18:15:42		2016-03-14 18:16:15
4	VFDControl DXR02010F210059	!!!!!!!!WARNING!!!!!!!!!!!! VFD Status : Emergency Stopped Time : 2016/03 /0913:28:10 MS300 has been stopped, please contact the relevant member!!!		2016-03-09 13:28:12
5	VFDControl DXR02010F210059	!!!!!!!!WARNING!!!!!!!!!!!! VFD Status : Emergency Stopped Time : 2016/03 /0913:27:57 MS300 has been stopped, please contact the relevant member!!!		2016-03-09 13:28:01
6	VFDControl DXR02010F210059	!!!!!!!!WARNING!!!!!!!!!!!! VFD Status : Emergency Stopped Time : 2016/03 /0913:26:46 MS300 has been stopped, please contact the relevant member!!!		2016-03-09 13:26:50
7	VFDControl DXR02010F210059	!!!!!!!!WARNING!!!!!!!!!!!! VFD Status : Emergency Stopped Time : 2016/03 /0913:24:22 MS300 has been stopped, please contact the relevant member!!!		2016-03-09 13:24:32
8	HMI DXR02010F210039	0 1 2016/03/09 13:20:16		2016-03-09 13:20:47
9	VFDControl DXR02010F210059	!!!!!!!!WARNING!!!!!!!!!!!! VFD Status : Emergency Stopped Time : 2016/03 /0913:01:37 MS300 has been stopped, please contact the relevant member!!!		2016-03-08 19:01:42

## 5.2.5 Secure Tunnels

Secure Tunnel is an important concept in DIACloud. Its objective is to realize virtual Switch across Internet; when device is bound to this network, it will be equivalent to adding device with one LAN port; when PC operates DIACom and creates a virtual network, PC and the device will be under the same switch at this time. It is shown as follows








5

Users can manager the tunnel network in this page. Interface is shown as follows:

#	Network Name ↑	DHCP	DHCP IP Range	Status	Operation
1	DeltaNetwork	Enable	192.168.200.100 192.168.200.200	Normal	...
2	HM2016	Enable	192.168.199.100 192.168.199.200	Normal	...

Total 2 tunnel network(s)

tem	Description
🔍 Search	Search the existed tunnel network
Tunnel network List	List all tunnel network under this account
+	Add a new tunnel network
🔄	Refresh the tunnel network list
...	Edit the tunnel network

Item	Description
Tunnel Network Information	The detail information of tunnel network: <ul style="list-style-type: none"> <li>• <b>Network Name:</b> User can enter a name of tunnel network.</li> <li>• <b>DHCP Option:</b> Automatic IP Address Assignment by DIACloud.</li> <li>• <b>DHCP IP Start:</b> it represents the beginning IP in automatic IP distribution address pool of DIACloud</li> <li>• <b>DHCP IP End:</b> it represents the ending IP in automatic IP distribution address pool of DIACloud.</li> </ul>
	If the DHCP of this tunnel network is enabled, click  will export configurations include DIACloud Servier /account /Tunnel networks info to a file (default file name Provision_vlnname_date_time.bin). Note: Detail configuration, please refer to <b>3.2 SD Card Quick Installation.</b>
	Delete the current tunnel network
	Close the current operation window.
	Save the configuration of tunnel network

### 5.2.6 Sub Users

All accounts that are registered through register page of DIACloud (<http://www.DIACloudSolutionscom/#/signup>) are main accounts. Every main account can create sub-account, and users can realize power separation and grouping management of device by conducting authorization for virtual network and DIACom by sub-account. Use can conduct addition and operation for sub-account through the “Sub Users” page.

#	Account ↑	Login to EthDirect	Status	Created	Operation
1	3208467055@qq.com	Disabled	Activated	2016-02-24 20:02:29	...
2	444386414@qq.com	Enabled	Activated	2015-10-27 22:04:34	...
3	shinewaker@sina.cn	Enabled	Activated	2016-02-25 17:06:26	...
4	test_1ot@126.com	Enabled	Activated	2016-02-29 17:35:54	...
Total 4 user(s)					

Item	Description
Search	Search the sub users.
Sub Users List	Show the list of all sub users in main account.
+	Add a sub user.
	Refresh the list of sub users.
...	Modify the access control of the tunnel network.

- ... : User can modify the access control of the tunnel network.

Account\*
✖

██████i@outlook.com

Edit register

Login to DIACom

Secure Tunnels

Project1



Test\_Hangzhou


default1


default

SAVE

Item	Description
Sub Users Information	<ul style="list-style-type: none"> <li>• <b>Edit register:</b> Allow the Sub User to modify register</li> </ul>

	<ul style="list-style-type: none"> <li>• <b>Login to DIACom:</b> Allow the sub user to access the DIACom if the option is enabled.</li> <li>• <b>Tunnel Network:</b> Allow the sub user to access the Tunnel Network if the option of Tunnel Network is checked.</li> </ul>
	Delete a sub user.
	Close the current operation window.

-  : User can add sub users after clicking the “+” in the page, and. The following interface will be shown after clicking the “+” in the page:



1. Fill in corresponding account information and conduct authorization for it.
2. The system will send an activation email which is attached with random login password to email box of sub user. The account status is “Un-activated” now.
3. Goto the mailbox, click the hyperlink to complete account activation operation, then sub user can login DIACloud with new account.
4. The page will link to the following page after clicking the activation link in the email:

Activate your account on DIACloud Inbox x



**DIACloud** <no-reply@diacLOUDSOLUTIONS.COM>  
to me ▾

3:40 PM (0 minutes ago) ☆ ↶ ▾

Dear User,

Please complete your registration by following the link below:

<http://www.diacLOUDSOLUTIONS.COM/#/activate?n=ww7843673%40gmail.com&t=l8SmPDnpyl24XV6llncjZJ5hbGSSUAE>

Please activate your account within 48 hours, otherwise you need to re-create your account.

If you did not register recently, or believe you have received this email in error. Please disregard this message.

请点击下面的链接完成注册:

<http://www.diacLOUDSOLUTIONS.COM/#/activate?n=ww7843673%40gmail.com&t=l8SmPDnpyl24XV6llncjZJ5hbGSSUAE>

请在48小时内激活您的账号，否则您需要重新注册。

如果该账号不是您本人注册的，请忽略本邮件。

Thanks!

The DIACLOUD Team

5

- When user login to DIACLOUD with main account and the sub user that we created has been activated.

### 5.2.7 Logs

This page will show the web operation information of some users. It includes: login IP, setup of register, API interface call of DIACLOUD and other information.



#	User Name	Log Content	Created
1	13616061750@163.com	push reg , cmd = 21300,1,2049,556	2016-04-01 11:12:41
2	13616061750@163.com	Login from 211.97.130.218	2016-04-01 11:11:36
3	13616061750@163.com	Login from 218.66.157.46	2016-04-01 10:45:41
4	13616061750@163.com	Login from 211.97.130.218	2016-04-01 10:43:23
5	13616061750@163.com	Edit tunnel network, id= 1247, name = test02, dhcp = 1	2016-04-01 10:38:20
6	13616061750@163.com	Logout	2016-04-01 10:37:55
7	13616061750@163.com	Login from 218.66.157.46	2016-04-01 10:37:54
8	13616061750@163.com	Login failed. username=13616061750@163.com from ip=218.66.157.46	2016-04-01 10:37:48
9	13616061750@163.com	Login failed. username=13616061750@163.com from ip=218.66.157.46	2016-04-01 10:37:41
10	13616061750@163.com	Login failed. username=13616061750@163.com from ip=218.66.157.46	2016-04-01 10:37:35

10 ▾ 1 - 10 / 1134 ⏪ ⏩

### 5.2.8 Orders

In this page, user can check his all orders. Continue to pay for the unpaid orders or cancel the unpaid orders.

#	Order NO.	Amount	Created	Status	Operation
1	120160506042313747581	\$ 100	2016-05-06 16:23:13	Wait for Payment <a href="#">Order Detail</a>	<b>PAY</b> <a href="#">Cancel</a>
2	120160506042243779488	\$ 99.99	2016-05-06 16:22:43	Wait for Payment <a href="#">Order Detail</a>	<b>PAY</b> <a href="#">Cancel</a>
3	120160506110245733298	\$ 99.99	2016-05-06 11:02:45	Wait for Payment <a href="#">Order Detail</a>	<b>PAY</b> <a href="#">Cancel</a>
4	120160505060220111921	\$ 0.01	2016-05-05 18:02:20	Finished <a href="#">Order Detail</a>	
5	120160505052319041416	\$ 0.01	2016-05-05 17:23:19	Finished <a href="#">Order Detail</a>	
6	120160505052149784903	\$ 0.01	2016-05-05 17:21:49	Finished <a href="#">Order Detail</a>	
7	120160505052038875275	\$ 0.01	2016-05-05 17:20:39	Finished <a href="#">Order Detail</a>	
8	120160505051413353285	\$ 0.01	2016-05-05 17:14:13	Finished <a href="#">Order Detail</a>	
9	120160505051019658664	\$ 0.01	2016-05-05 17:10:20	Wait for Payment <a href="#">Order Detail</a>	<b>PAY</b> <a href="#">Cancel</a>
10	120160505050752270363	\$ 0.01	2016-05-05 17:07:52	Wait for Payment <a href="#">Order Detail</a>	<b>PAY</b> <a href="#">Cancel</a>

10 ▾ 1 - 10 / 51 ⏪ ⏩

Item	Description
<a href="#">Order Detail</a>	View the order detail information
<b>PAY</b>	Pay for the unpaid order
<a href="#">Cancel</a>	Cancel the order, order will remove from the list.


- Order detail

Order Detail			
#	Package Name	Unit Price	Number
1	DX-Service-S1MB-WW Cloud Storage fee of 5-years package for 200MB storage space in one account	\$ 0.01	x1
			<b>Total Price \$ 0.01</b>

- Payment Method: Currently, we only support PayPal payment for the world wide user.

Payment Method

Total to pay now **\$ 99.99**




[PAY NOW](#)

## 5.2.9 Profile

In this page, QR Code of user, Package info, password management and other information will be shown.

Profile



Account [REDACTED]@126.com

Login to DIACom Enabled

Country United States

PACKAGE INFO
CHANGE PASSWORD

Account Storage Usage 0.00 MB / 0.00 MB [BUY](#)

---


Account Traffic Usage 370.00 MB / 370.00 MB [BUY](#)

---

Item	Description
QR Code	You can get the part information of user by using DIACloud APP and scanning QR Code.
Account	The current account information.
Package info	<ul style="list-style-type: none"> <li>Show account traffic/storage usage till now</li> <li><a href="#" style="background-color: #007bff; color: white; padding: 2px 5px; border-radius: 3px;">BUY</a> User can purchase more traffic/storage package for this account if need</li> </ul> <p> Account traffic/storage will share to all devices under this account.</p>
Change Password	<p>Change the password of DIACloud user account.</p> <p>Note: parts of old users use password in 6 digits; the new password has been increased to 8 digits to improve safety of their accounts.</p>

Change Password page as below

**Profile**



Account ██████████@126.com

Login to DIACom Enabled

Country United States

[PACKAGE INFO](#) [CHANGE PASSWORD](#)

---

Account Storage Usage 0.00 MB / 0.00 MB [BUY](#)

Account Traffic Usage 370.00 MB / 370.00 MB [BUY](#)

---


# Chapter 6 DIACloud APP

## Table of Contents

- 6.1 Introduction to DIACloud APP.....6-2**
  - 6.1.1 Select a Suitable Firmware Version .....6-2
  - 6.1.2 DIACloud APP Installation .....6-2
  
- 6.2 DIACloud APP Function .....6-3**
  - 6.2.1 DIACloud APP Login .....6-3
  - 6.2.2 Device List.....6-4
  - 6.2.3 Device Details .....6-5
  - 6.2.4 Registers View .....6-6
  - 6.2.5 Alarm List.....6-7

## 6.1 Introduction to DIACloud APP

DIACloud APP is the client software of DIACloud cloud platform running on mobile devices. The APP supports both iOS and Android mobile system, it enables users to view the field data collected, the locations of the field devices, and the alarms/notifications pushed by the industrial IOT cloud platform, so that keep users posted anytime and anywhere, and therefore improve the manageability of devices, optimize the device performance and efficiency, save the operation cost and enhance the service quality.



### 6.1.1 Select a Suitable Firmware Version

The APP can support the devices below:

Device Model	Firmware Version
DX-2100	V1.3.0.1 or above
DX-2300	V1.0.0.1 or above

### 6.1.2 DIACloud APP Installation


The DIACloud APP is available on Google Play and Apple APP Store.

Mobile Device	OS Version
Android	4.4.0 or above
iPhone	6.2.0 or above






## 6.2 DIACloud APP Function

### 6.2.1 DIACloud APP Login

Enter the DIACloud account and password, then click the “Sign in” button to login the APP. Click the “Sign up” to register an account if you don’t have one.




6




Item	Description
	Scan QR code, the QR code is generated by DIACloud Web portal, which carries the user name and password information. By scanning the QR code, user won't need to input user name. By default, the APP will connect the default DIACloud server in the cloud, if the APP is to connect other servers, QR code should be scanned to provision the APP.
	DIACloud account, Email format
	The password of DIACloud account, click  to see what are you input
Auto Login	Save the password and login the APP automatically
Login	Login to App
Sign up	Create a new DIACloud account
Forget	Reset the password if you forget it.
	Switch the language.

## 6.2.2 Device List

Device list will be shown after user login the APP.




Device tab and alarm tab will be shown in the APP. In the device tab, the device information will be shown, include the value of registers of the remote device. And the value of the register can be changed in the APP as well. In the alarm tab, users can read the alarm messages.

Item	Description
	Logoff or exit App
Search	Search device base on key word
All/Online	<ul style="list-style-type: none"> <li>Click "ALL" to show all device</li> <li>Click "Online" only show online device. Digit at the back is the all/online device count.</li> </ul>
Device list	Display device online/offline status, device name, device serial number. Click it will go into device detail page
	Switch to device list page
	Switch to alarm list page.

### 6.2.3 Device Details

Device details will be shown by selecting a device in the device list.





Item	Description
Type	Type of the device
Time	The time when the device is online.
IP	IP Address of the device
Account	DIACloud account activating the device.
Mode	The working mode of RS485 and RS232.- <ul style="list-style-type: none"> <li>• <b>RS232:</b> Transparent transmission mode or Slave mode</li> <li>• <b>RS485:</b> Transparent transmission mode / Slave mode / Master mode</li> </ul>
Map	Showing the location of the device on the map P.S. DX-2300 Series doesn't support this function.


## 6.2.4 Registers View

Click [Register] on the device details page to switch to the register page

In the register page, the user can browse the collected data. The register data can be refreshed by the pull-down screen. When the number of registers is large, you can pull up the screen to display more data.


Addr.	Value
电压	6
2049	0
2050	6
2051	0
2052	0
2053	0
2054	1446
2055	0
2056	0


Item	Description
	Refresh the register data.
	Edit the register value.



Click “ok” button, the register value will be pushed to the device.

### 6.2.5 Alarm List

Alarm criteria can be set on the device configuration web page. When the alarm criteria are met, the device will send out alarm messages. User can click the “Alarm” tab to read the alarm messages. When there are new alarm messages, the number of the unread messages will be shown on the icon .

- Alarm tab will be shown by clicking icon , the alarm messages in Red are unread messages. Digit in parentheses is the number of alarm messages.
- Pull down the APP to refresh the alarm list.

