

Industrial Automation Headquarters

Delta Electronics, Inc.
Taoyuan Technology Center
No.18, Xinglong Rd., Taoyuan City,
Taoyuan County 33068, Taiwan
TEL: 886-3-362-6301 / FAX: 886-3-371-6301

Asia

Delta Electronics (Jiangsu) Ltd.
Wujiang Plant 3
1688 Jiangxing East Road,
Wujiang Economic Development Zone
Wujiang City, Jiang Su Province, P.R.C. 215200
TEL: 86-512-6340-3008 / FAX: 86-769-6340-7290

Delta Greentech (China) Co., Ltd.
238 Min-Xia Road, Pudong District,
ShangHai, P.R.C. 201209
TEL: 86-21-58635678 / FAX: 86-21-58630003

Delta Electronics (Japan), Inc.
Tokyo Office
2-1-14 Minato-ku Shibadaimon,
Tokyo 105-0012, Japan
TEL: 81-3-5733-1111 / FAX: 81-3-5733-1211

Delta Electronics (Korea), Inc.
1511, Byucksan Digital Valley 6-cha, Gasan-dong,
Geumcheon-gu, Seoul, Korea, 153-704
TEL: 82-2-515-5303 / FAX: 82-2-515-5302

Delta Electronics Int'l (S) Pte Ltd.
4 Kaki Bukit Ave 1, #05-05, Singapore 417939
TEL: 65-6747-5155 / FAX: 65-6744-9228

Delta Electronics (India) Pvt. Ltd.
Plot No 43 Sector 35, HSIIDC
Gurgaon, PIN 122001, Haryana, India
TEL : 91-124-4874900 / FAX : 91-124-4874945

Americas

Delta Products Corporation (USA)
Raleigh Office
P.O. Box 12173, 5101 Davis Drive,
Research Triangle Park, NC 27709, U.S.A.
TEL: 1-919-767-3800 / FAX: 1-919-767-8080

Delta Greentech (Brasil) S.A.
Sao Paulo Office
Rua Itapeva, 26 - 3° andar Edificio Itapeva One-Bela Vista
01332-000-São Paulo-SP-Brazil
TEL: 55 11 3568-3855 / FAX: 55 11 3568-3865


Europe

Delta Electronics (Netherlands) B.V.
Eindhoven Office
De Witbogt 20, 5652 AG Eindhoven, The Netherlands
TEL : +31 (0)40-8003800 / FAX : +31 (0)40-8003898

DX-020BD20-02

2020-05-14

*We reserve the right to change the information in this manual without prior notice.



DX-3001 H9-V Industrial 3G/WAN VPN Router User Manual

DX-3001H9-V Series Industrial 3G/WAN VPN Router User Manual

Revision History

| Version | Revision | Date |
|-----------------|--|------------|
| 1 st | The first version was published. | 2016/10/21 |
| 2 nd | <ol style="list-style-type: none">1. Chapter 3: Add new functions of Auto Detect/Dial Failure to Restart/Detect interval/WAN Backup/WAN Check Interval in section 3.2.1.2. Add new function of PIN Management in section 3.2.4.3. Add new function of Remote Web Manage Setting in section3.3.8. | 2020/5/14 |

DX-3001H9-V Industrial 3G/WAN VPN

Router User Manual

Table of Contents

Chapter 1 Product Introduction

| | | |
|------------|----------------------------------|------------|
| 1.1 | Product Overview | 1-4 |
| 1.1.1 | Network Design..... | 1-5 |
| 1.1.2 | Features | 1-5 |
| 1.1.3 | Front Panel Ports and LEDs | 1-6 |
| 1.1.4 | Top Panel | 1-6 |
| 1.1.5 | Bottom Panel | 1-7 |
| 1.1.6 | Dimension | 1-8 |
| 1.2 | Package Checklist | 1-8 |

Chapter 2 User Interface

| | | |
|------------|--|------------|
| 2.1 | Web-based GUI Configuration | 2-2 |
| 2.1.1 | System Connection..... | 2-2 |
| 2.1.2 | Default IP Address/Account/Password..... | 2-2 |
| 2.1.3 | Local Network Setups | 2-2 |
| 2.1.4 | Logging in | 2-4 |

Chapter 3 Functions

| | | |
|------------|---------------------------|------------|
| 3.1 | Status | 3-3 |
| 3.1.1 | Network Status | 3-3 |
| 3.1.2 | Device | 3-4 |
| 3.1.3 | Log | 3-6 |
| 3.2 | Network | 3-7 |
| 3.2.1 | Connection Priority | 3-7 |
| 3.2.2 | Cellular Link1 | 3-10 |
| 3.2.3 | Cellular Link2..... | 3-12 |
| 3.2.4 | PIN Management | 3-14 |
| 3.2.5 | WAN Setting..... | 3-16 |
| 3.2.6 | LAN | 3-17 |

| | | |
|------------|--------------------------------|-------------|
| 3.3 | Firewall | 3-19 |
| 3.3.1 | Basic | 3-19 |
| 3.3.2 | DMZ | 3-20 |
| 3.3.3 | Port Forward..... | 3-20 |
| 3.3.4 | Port Trigger | 3-22 |
| 3.3.5 | URL Filter | 3-24 |
| 3.3.6 | MAC Filter | 3-25 |
| 3.3.7 | IP Filter..... | 3-25 |
| 3.3.8 | Remote Web Manage Setting..... | 3-26 |
| 3.4 | VPN | 3-28 |
| 3.4.1 | IPSec..... | 3-28 |
| 3.4.2 | OPENVPN | 3-31 |
| 3.4.3 | PPTP..... | 3-33 |
| 3.4.4 | L2TP..... | 3-35 |
| 3.4.5 | GRE..... | 3-37 |
| 3.4.6 | Certificate | 3-39 |
| 3.4.7 | VPN Log..... | 3-40 |
| 3.5 | Interface | 3-40 |
| 3.5.1 | RS232 | 3-40 |
| 3.5.2 | RS485 | 3-41 |
| 3.5.3 | Profile Management | 3-42 |
| 3.5.4 | FTP/SFTP Server | 3-43 |
| 3.6 | System | 3-44 |
| 3.6.1 | Name and Password | 3-44 |
| 3.6.2 | Time Zone Settings..... | 3-45 |
| 3.6.3 | Firmware Upgrade..... | 3-46 |
| 3.6.4 | Backup & Restore | 3-46 |
| 3.6.5 | System Reboot | 3-47 |
| 3.6.6 | SD Card..... | 3-47 |
| 3.6.7 | Network Diagnosis..... | 3-48 |

Chapter 1 Product Introduction

Table of Contents

- 1.1 Product Overview 1-4**
 - 1.1.1 Network Design 1-5
 - 1.1.2 Features 1-5
 - 1.1.3 Front Panel Ports and LEDs 1-6
 - 1.1.4 Top Panel 1-6
 - 1.1.5 Bottom Panel 1-7
 - 1.1.6 Dimension 1-8
- 1.2 Package Checklist 1-8**

1 FCC Interference Statement

This equipment has been tested and found to comply with the limits for a class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates radio frequency signal and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CE Declaration of Conformity

DX-3001H9-V is herewith confirmed to comply with the requirements set out in the Council Directive on the Approximation of the Laws of the Member States relating to Electromagnetic Compatibility of Radio and Telecom device (1995/5/EC). For the evaluation regarding the Directives, the following standards were applied:

Test Items :

---EMC

EN 301 908-1 V7.1.1(2015-03)

EN 301 511 V12.1.1(2015-06)

---Radio

EN 301 489-1 V1.9.2 (2011-09)

EN 301 489-7 V1.3.1 (2005-11)

EN 301 489-24 V1.5.1 (2010-10)

---MPE

EN50385: 2002

---Safety

EN60950-1: 2006/A11:2009/A1:2010/A12:2011/A2:2013

EN 55022 Class A Warning:

Class A ITE is a category of all other ITE which satisfies the class A ITE limits but not the class B ITE limits.

The following warning shall be included in the instructions for use:



Notice

- This is a class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

EN 55032 Class A Warning:

Class A ITE is a category of all other ITE which satisfies the class A ITE limits but not the class B ITE limits.

The following warning shall be included in the instructions for use:

Warning: This equipment is compliant with Class A of EN 55032. In residential environment this equipment may cause radio interference.

1.1 Product Overview


DX-3001H9-V is an industrial VPN router, it has 2 SIM card slots and supports multiple mobile networks like WCDMA, UMTS, HSUPA, GSM, GPRS, and EDGE. When one cellular network fails to work, the device will automatically switch to the other cellular network. Besides the two cellular network connections, the WAN port can be another connection to Internet. Priorities of the connection to Internet over WAN and 2 cellular networks are configurable. As there is only one 3G module in the device, the two cellular networks cannot be active at the same time.

Router support standard VPN protocols include PPTP, L2TP, OPENVPN, IPSec and GRE. With interfaces like Ethernet ports, RS232 and RS485, multiple peripheral devices can be connected to the device.

The product can be widely used on the M2M fields, such as industrial automation, smart power grids, finance, environment protection, intelligent building, intelligent transportation, video surveillance, intelligent self-service and so on.




1.1.1 Network Design




1.1.2 Features

- Support HSPA+/HSUPA/HSDPA/UMTS: 800/850/900/AWS1700/1900/2100 MHz
- Support GSM/GPRS/EDGE: 850/900/1800/1900 MHz
- Support CHAP / PAP authentication
- Support APN access
- Support automatic redial when connection is broken
- WAN port access mode(static IP , DHCP client)
- Dual SIM card slots, support auto-switching between the cellular operators
- Provides dual serial ports (RS232 and RS485) and 4 LAN port to meet the needs of different devices connected
- Support PPTP/L2TP/OPENVPN/IPSec/GRE VPN
- Support LED status display
- Provides reset function
- Support NTP client, built-in independent RTC
- Support DHCP server
- Support Dynamic DNS


1.1.3 Front Panel Ports and LEDs



1.1.4 Top Panel



1.1.5 Bottom Panel




Notice

This router's reset button is on the front panel. By pressing the Reset button, users can reset the router or reset the router to factory default settings. See the instruction below:

- Reset the Router: With the router powered on, press the Reset button and release the button right away.
- Reset to Factory Defaults: With the router powered on, press and hold the Reset button for 3~6 seconds and then release the button.
 - Reset can only be done when the device is running properly.
 - With the router powered on, press and hold the Reset button until all the LEDs go out (Except the Power LED). Then release the button and wait the router to reboot to its factory default settings.

1.1.6 Dimension



Unit = mm

1.2 Package Checklist

Unpack the package carefully and check the package contents. The package should contain the following items:

- DX-3001H9-V Industrial 3G VPN Router x 1
- Quick Installation Guide x 1
- SMA Antenna (300cm) x 1

Notice

- Verify that nothing is missing from the DX-3001H9-V package by using the check list above. If any item is found missing or damaged, please contact your local sales representative for support.

Chapter 2 User Interface

Table of Contents


- 2.1 Web-based GUI Configuration2-2**
- 2.1.1 System Connection2-2
- 2.1.2 Default IP Address/Account/Password2-2
- 2.1.3 Local Network Setups2-2
- 2.1.4 Logging in.....2-5

2.1 Web-based GUI Configuration

The DX-3001 Industrial Ethernet Cloud Router provides a friendly Web Browser Configuration for users to set up and operate more intuitively.

2.1.1 System Connection

First, connect the PC used for configuration with Ethernet interface of the router directly or through the switch/hub.







2.1.2 Default IP Address/Account/Password

The default IP address of router is 192.168.1.1. The initial account and password is admin/admin

2.1.3 Local Network Setups

After the connection of the local computer and the router is done, you will need to set the network configuration for your computer.

- **Obtain an IP address automatically by using the router as a DHCP server.**
 1. Open Network Connections by clicking the Start button , and then clicking Control Panel.
 2. Under Network and Sharing Center, click View network connections.
 3. Right-click the connection that you want to change, and then click Properties.  If you're prompted for an administrator password or confirmation, type the password or provide confirmation.
 4. Click the Networking tab. Under This connection uses the following items, click either Internet Protocol Version 4 (TCP/IPv4) or Internet Protocol Version 6 (TCP/IPv6), and then click Properties.
 5. Click Obtain DNS server address automatically and then click OK to get a DNS server address automatically using DHCP.




- **Set up the IP address manually.**

(The IP address of the computer should be in the same network segment as the router's.)

Since the router's default IP address is 192.168.1.1 and the subnet mask is 255.255.255.0, the computer's IP address can be set between 192.168.1.2 to 192.168.1.254. However, you'll need to make sure there are no IP conflicts.

Here, we set the address to 192.168.1.10 and the default gateway to 192.168.1.1. For DNS, the usable DNS address can be selected or the address can also be set to 192.168.1.1.



2.1.4 Logging in

1. Open your Internet Explorer browser and input the router's LAN IP address (Default is 192.168.1.1) in the search bar and then press Enter.



2. You'll be prompted with the log-in page. Input the user name and the password (Default is admin/admin) and then press Enter to log in to the setup page.

DX-3001

User Name

Password

[LOGIN](#)

3. After login, you can see the main selection area on the left hand side and the upper area of the page. The detailed settings can be seen on the right hand side of the page.

DELTA
STATUS
NETWORK
Firewall
VPN
INTERFACE
SYSTEM
DX-3001 EXIT

Network
Device
Log

Network Status network information

STATUS > Network Status

Connection Reconnect

| Connection Type | Cellular Link1 | | |
|-----------------|----------------|--------------------|---------------|
| Operator | Others | APN | 3gnet |
| User Name | | Password | |
| MCC | 460 | MNC | 01 |
| Signal Strength | 0 | Authorization Mode | Auto |
| Dial-Up Number | *99# | Online Duration | N/A |
| IP Address | 0.0.0.0 | Network Mask | 255.255.255.0 |
| Gateway Address | 0.0.0.0 | Primary DNS | 0.0.0.0 |
| Secondary DNS | 0.0.0.0 | | |

LAN

| | | | |
|----------------|-------------|-------------|------|
| LAN IP Address | 192.168.1.1 | | |
| LAN1-Status | Down | LAN2-Status | Up |
| LAN3-Status | Down | LAN4-Status | Down |

Network Status Help

Status of the cellular network

Shows the settings in the web page of "WAN configurations"

Operator: The service provider of cellular network

Signal Strength: the signal strength of the cellular network

Connection Status: Shows if the device is online to Internet

Online Duration: The total time elapsed since the device is online to Internet

Authentication Method: The authentication method of the Internet connection.

APN: Access point name of the cellular network

Telephone Number: the phone number of the SIM card inserted into this device.

IP Address: The IP address allocate



Notice

- For security, please modify the initial password as soon as possible.

MEMO

2

Chapter 3 Functions

Table of Contents

| | | |
|------------|--------------------------------|-------------|
| 3.1 | Status | 3-3 |
| 3.1.1 | Network Status | 3-3 |
| 3.1.2 | Device | 3-4 |
| 3.1.3 | Log..... | 3-6 |
| 3.2 | Network | 3-7 |
| 3.2.1 | Connection Priority | 3-7 |
| 3.2.2 | Cellular Link1 | 3-10 |
| 3.2.3 | Cellular Link2..... | 3-12 |
| 3.2.4 | PIN Management | 3-14 |
| 3.2.5 | WAN Setting | 3-16 |
| 3.2.6 | LAN | 3-17 |
| 3.3 | Firewall | 3-19 |
| 3.3.1 | Basic | 3-19 |
| 3.3.2 | DMZ | 3-20 |
| 3.3.3 | Port Forward..... | 3-20 |
| 3.3.4 | Port Trigger | 3-22 |
| 3.3.5 | URL Filter | 3-24 |
| 3.3.6 | MAC Filter | 3-25 |
| 3.3.7 | IP Filter..... | 3-25 |
| 3.3.8 | Remote Web Manage Setting..... | 3-26 |
| 3.4 | VPN | 3-28 |
| 3.4.1 | IPSec..... | 3-28 |
| 3.4.2 | OPENVPN | 3-31 |
| 3.4.3 | PPTP..... | 3-33 |
| 3.4.4 | L2TP..... | 3-35 |
| 3.4.5 | GRE..... | 3-37 |
| 3.4.6 | Certificate | 3-39 |
| 3.4.7 | VPN Log | 3-40 |
| 3.5 | Interface | 3-40 |
| 3.5.1 | RS232 | 3-40 |
| 3.5.2 | RS485 | 3-41 |
| 3.5.3 | Profile Management | 3-42 |

| | | |
|------------|--------------------------|-------------|
| 3.5.4 | FTP/SFTP Server | 3-43 |
| 3.6 | System..... | 3-44 |
| 3.6.1 | Name and Password | 3-44 |
| 3.6.2 | Time Zone Settings | 3-45 |
| 3.6.3 | Firmware Upgrade..... | 3-46 |
| 3.6.4 | Backup & Restore..... | 3-46 |
| 3.6.5 | System Reboot | 3-47 |
| 3.6.6 | SD Card..... | 3-47 |
| 3.6.7 | Network Diagnosis..... | 3-48 |

3.1 Status

You can view summary or detailed information on the Device Information, Network Status, and Log.

3.1.1 Network Status

This page shows basic information on Network Status, LAN Status and traffic.

When router connects to internet by WAN port, the connection includes the connection type, WAN mode, IP Address Network Mask, Gateway Address, primary DNS, and Secondary DNS.

When router connects to internet by Cellular, the connection includes the Operator, Signal Strength, Connection Status, Online Duration, Authorization Mode, APN, Telephone Number, IP Address Network Mask, Gateway Address, primary DNS, and Secondary DNS.

LAN includes the LAN IP Address, and connection status of 4 LAN port. Up means connected, down means disconnected.

Traffic statistics shows network traffic information of the Cellular Link 1&2 and WAN port.

STATUS > Network Status

Connection

Reconnect

| | | | |
|-----------------|---------|--------------|---------|
| Connection Type | WAN | WAN Mode | DHCP |
| IP Address | 0.0.0.0 | Network Mask | 0.0.0.0 |
| Gateway Address | 0.0.0.0 | Primary DNS | 0.0.0.0 |
| Secondary DNS | 0.0.0.0 | | |

LAN

| | | | |
|----------------|-------------|-------------|------|
| LAN IP Address | 192.168.1.1 | | |
| LAN1-Status | Down | LAN2-Status | Up |
| LAN3-Status | Down | LAN4-Status | Down |

Traffic Statistics

| | | | |
|---------------------|---------|-------------------------|---------|
| Cellular Link1-Sent | 0 bytes | Cellular Link1-Received | 0 bytes |
| Cellular Link2-Sent | 0 bytes | Cellular Link2-Received | 0 bytes |
| WAN-Sent | 0 bytes | WAN-Received | 0 bytes |

3.1.2 Device

This page shows basic information on the Hardware/Software version and Resource Usage Information

STATUS > Device

Basic

Device Type: DX3001
 Device Name: DX3001_DA90
 S/N: DXL3001116140010

Version

Hardware Version: DX3001
 Release Date: 2016-03-14 04:28:44 PM
 Firmware Version: DX3001-0.8.1.2-2016-05-19
 Upgrade Date: 2016-05-19 02:33:39

Resource Usage

CPU Usage: 6%
 Total Memory: 121696KB
 Memory Used: 93144KB
 Memory Usage: 76%
 SD Card Status:
 SD Card Capacity: 0
 SD Card Usage: 0

Basic

| Item | Description |
|-------------|---|
| Device Type | Model type of the router |
| Device Name | Name of the router, the default is DX3001 + "_" + "the last four digits of Mac address" |
| S/N | Serial number of the router |

● Version

| Item | Description |
|-------------------------|---|
| Hardware Version | Version number of the hardware currently used on the router |
| Release Date | Hardware release date |
| Current Version | Version number of the software currently used on the router |
| Upgrade Date | Upgrade time of the software currently used on the router |

● Resource Usage

| Item | Description |
|-------------------------|--|
| CPU Usage | The CPU usage of current router |
| Total Memory | The total memory on the router |
| Memory Used | The memory currently used on the router. |
| Memory Usage | The current ratio of the router usage |
| SD Card Status | The SD card status in the router. |
| SD Card Capacity | The total storage of the SD card |
| SD Card Usage | The storage currently usage of SD card |

3.1.3 Log

This page shows logs of the router, including the System log, Warning log and the Debug log. You can use the buttons on the right hand side to refresh, clear or download the displayed logs.

STATUS > Device Logs

Log Type

Informative log Warning log Debug log

Log Content

Refresh Clear Download

| Timestamp | Content |
|-----------------|---|
| May 19 05:44:04 | syslog.info syslogd started: BusyBox v1.22.1 |
| May 19 05:44:12 | user.info WATCHDOG[1488]: watchdog enabled! |
| May 19 05:44:12 | user.info SMSTrigger: [SMSTrigger:]SMSTrigger run in /dev/ttyUSB1 115200 mode. |
| May 19 05:44:12 | user.err SMSTrigger: [SMSTrigger:]Open FIFO failed.FD value:-1 errno:2 retry : 0! |
| May 19 05:44:12 | authpriv.warn dropbear[1490]: Failed loading /etc/dropbear/dropbear_dss_host_key |
| May 19 05:44:12 | authpriv.warn dropbear[1490]: Failed loading /etc/dropbear/dropbear_ecdsa_host_key |
| May 19 05:44:12 | authpriv.info dropbear[1536]: Running in background |
| May 19 05:44:13 | user.info collection: main.c(517)-main: argc=4 |
| May 19 05:44:13 | user.info collection: main.c(518)-main: Path: /var/collection |
| May 19 05:44:13 | user.info collection: main.c(519)-main: File rotate: 20 |
| May 19 05:44:13 | user.info collection: main.c(520)-main: Interval: 5 |
| May 19 05:44:13 | user.info gre_app: [GRE_APP] gre_app start |

PREV 1 2 3 4 5 NEXT

3

3.2 Network

You can set up networks configuration, including the connection priority, Cellular network, WAN and LAN Configurations.

3.2.1 Connection Priority

This page is used for setting up the connection priority. Router provide 3 links to connect to Internet, include cellular network 1&2 and WAN, user can appoint the connect order in this page.



🏠 NETWORK > Connection Priority




☰ Connection Priority

| | |
|-------------------------|--|
| Primary Connection | <input type="text" value="WAN"/> |
| Secondary Connection | <input type="text" value="Disable"/> |
| Tertiary Connection | <input type="text" value="Disable"/> |
| Auto Detect | <input type="text" value="Ping"/> |
| Target Address 1 | <input type="text"/> |
| | <i>(must be public address, not vpn address)</i> |
| Target Address 2 | <input type="text"/> |
| | <i>(must be public address, not vpn address)</i> |
| Dial Failure To Restart | <input type="text" value="Disable"/> |
| Detect Interval | <input type="text" value="60"/> <i>(30~300s)</i> |
| WAN Backup | <input type="text" value="Disable"/> |
| WAN Check Interval | <input type="text" value="10"/> <i>(10~300s)</i> |

Save

Cancel

| Description | Default |
|---|----------|
| Primary Connection | |
| The first priority network interface connects to the Internet | WAN |
| Secondary Connection | |
| The second priority network interface connects to the Internet | Disable |
| Tertiary Connection | |
| Third priority network interface to connect to the Internet | Disable |
| Auto Detect | |
| <ul style="list-style-type: none"> Enabled: The connection priority is enabled. Switch to the Secondary Connection automatically after the third failed attempt of testing on target address 1 and 2 with PING, FTP or SFP Ping during the Primary Connection. Switch to Tertiary Connection after another third attempt failed during the Secondary Connection. Disabled: The connection priority WON'T be enabled. | Disabled |
| Target Address 1 | |
| Set the first IP of the server that program will do a ping testing.  Notice <ul style="list-style-type: none"> Make sure the target IP address allows to be pinged. Does not support Domain Name input. | N/A |
| Target Address 2 | |
| Set the second IP of the server that program will do a ping testing.  Notice <ul style="list-style-type: none"> Make sure the target IP address allows to be pinged. Does not support Domain Name input. | N/A |
| Dial Failure To Restart | |
| DX devices will be restarted if the network connection has been continuously failed for 10minures with the Primary/ Secondary/ Tertiary Connection. | Disable |
| Detect Interval | |
| Set the retry interval for PING/ FTP/ SFTP connection testing. (Range: 30 to 300 sec.) | 60s |
| WAN Backup | |
| Activated when the setting of Primary Connection is WAN. <ul style="list-style-type: none"> Enable: Even if the Secondary or Tertiary Connection is currently used for the loss of the Primary Connection. WAN will be forced to switch back to the Primary Connection after the recovery. Disable: The Secondary Connection or Tertiary Connection would still be activated after the Primary connection recovers. | Disable |
| WAN Check Interval | |
| Set the interval (30 to 300 sec.) for inspection of WAN connection status. (Range: 30 to 300 sec.) | 10s |

| | |
|-----------------------|--|
| Operation Instruction | <p>Example: Activate WAN Backup</p> <ol style="list-style-type: none"> 1. Login to DX system. 2. Follow the path: Network -> Connection 3. Set Primary Connection as "WAN" 4. Set Secondary Connection as "Celluar1" 5. Set Tertiary Connection as "Celluar2" 6. Set Ping or FTP/ SFTP for Auto Detect. Input the target IP addresses. <p> Notice</p> <ul style="list-style-type: none"> ● Make sure the target IP address allows to be pinged. ● Does not support Domain Name input. <ol style="list-style-type: none"> 7. Set WAN Backup as "Enable" 8. Set WAN Check Interval as 10 seconds (Default setting is 10s) 9. Click "Save" |
| Illustration | <p> NETWORK > Connection Priority</p> <p> Connection Priority</p> <hr/> <p>Primary Connection <input type="text" value="WAN"/></p> <p>Secondary Connection <input type="text" value="Cellular Link1"/></p> <p>Tertiary Connection <input type="text" value="Cellular Link2"/></p> <p>Auto Detect <input type="text" value="Ping"/></p> <p>Target Address 1 <input type="text" value="4.4.4.4"/> (must be public address, not vpn address)</p> <p>Target Address 2 <input type="text" value="8.8.8.8"/> (must be public address, not vpn address)</p> <p>Dial Failure To Restart <input type="text" value="Disable"/></p> <p>Detect Interval <input type="text" value="60"/> (30~300s)</p> <p>WAN Backup <input type="text" value="Enable"/></p> <p>WAN Check Interval <input type="text" value="10"/> (10~300s)</p> <p><input type="button" value="Save"/> <input type="button" value="Cancel"/></p> |

3.2.2 Cellular Link1

This page is used for setting up the Cellular Network for Link1(SIM1), including the Operator, User Name, Password, APN, Authorization Mode, Dial-Up Number, Dial-Up Mode, Redial Interval, Redial Times, Max Idle Time, Connection Check Interval, Connection Check Times, and MTU.

🏠 NETWORK > Cellular Link1

☰ Cellular Link1

| | |
|---------------------------|--|
| Operator | <input type="text" value="Auto"/> |
| User Name | <input type="text"/> |
| Password | <input type="text"/> |
| APN | <input type="text" value="3gnet"/> |
| Authorization Mode | <input type="text" value="Auto"/> |
| Dial-Up Number | <input type="text" value="*99#(UMTS/3G/3.5G)"/> |
| Dial-Up Mode | <input type="text" value="Always online"/> |
| Redial Interval | <input type="text" value="30"/> (second) |
| Redial Times | <input type="text" value="0"/> (0 means always redial) |
| Max Idle Time | <input type="text" value="0"/> (0 means always online) |
| Connection Check Interval | <input type="text" value="60"/> second (0 means not checked) |
| Connection Check Times | <input type="text" value="5"/> |
| MTU | <input type="text" value="1492"/> |

| Description | Default |
|---|---------|
| Operator | |
| Select Auto or Others for the Operator from the dropdown list. <ul style="list-style-type: none"> ● Auto: the system will detect the operator from the inserted SIM card and set up accordingly. ● Others: users can set up the operator manually. | AUTO |
| User Name | |
| This name is provided by the operator. When “Auto” is selected, the system will set the name up automatically and users cannot change the setting. | N/A |
| Password | |

| Description | Default |
|---|---------------|
| This password is provided by the operator. When "Auto" is selected, the system will set the password up automatically and users cannot change the setting. | N/A |
| APN (Access Point Name) | |
| This APN is provided by the operator. When "Auto" is selected, the system will set the APN up automatically and users cannot change the setting. | 3gnet |
| Authorization Mod | |
| Options are "Auto", "PAP" and "CHAP". | Auto |
| Dial-Up Number | |
| This number is provided by the operator. When "Auto" is selected, the system will set the number up automatically and users cannot change the setting. | *99# |
| Dial-Up Mode | |
| Options are : <ul style="list-style-type: none"> ● Always online: stay connected and once a disconnection is detected, the router will redial to connect automatically. ● On-demand connection: redial when connection to the internet is on demand. ● Manual connection: users dial to connect and when it fails to connect, it will not redial. | Always online |
| Redial Interval | |
| Set up the time to redial when the system fails to connect. This will only be executed when the option "Always online" or "On-demand connection" is selected. | 30 |
| Redial Times | |
| Set up the maximum redial time, 0 indicating infinity. This will only be executed when the option "Always online" or "On-demand connection" is selected. | 5 |
| Max Idle Time | |
| Set up the maximum idle time. When the idle time exceeds the set value, the router will disconnect and then redial, 0 indicating not to disconnect. | 180 |
| Connection Check Interval | |
| Set up the connection check interval. Check the connectivity, if the connection is lost, it will redial automatically, 0 indicating not to check the connectivity. | 60 |
| Connection Check Times | |
| Set up the connection check times, 0 indicating infinity. Once a disconnection is detected, and the option "Always online" or "On-demand connection" is selected, the router will redial according to the set value in the Redial Times. | 5 |
| MTU | |
| Maximum Transmission Unit is the largest packet that can be transmitted over packet based networks. | 1492 |

3.2.3 Cellular Link2

This page is used for setting up the Cellular Network for Link1(SIM2), including the Operator, User Name, Password, APN, Authorization Mode, Dial-Up Number, Dial-Up Mode, Redial Interval, Redial Times, Max Idle Time, Connection Check Interval, Connection Check Times, and MTU.

🏠 NETWORK > Cellular Link2

☰ Cellular Link2

| | |
|---------------------------|--|
| Operator | <input type="text" value="Auto"/> |
| User Name | <input type="text"/> |
| Password | <input type="text"/> |
| APN | <input type="text" value="3gnet"/> |
| Authorization Mode | <input type="text" value="Auto"/> |
| Dial-Up Number | <input type="text" value="*99#(UMTS/3G/3.5G)"/> |
| Dial-Up Mode | <input type="text" value="Always online"/> |
| Redial Interval | <input type="text" value="30"/> (second) |
| Redial Times | <input type="text" value="0"/> (0 means always redial) |
| Max Idle Time | <input type="text" value="0"/> (0 means always online) |
| Connection Check Interval | <input type="text" value="60"/> second (0 means not checked) |
| Connection Check Times | <input type="text" value="5"/> |
| MTU | <input type="text" value="1492"/> |

| Description | Default |
|---|---------|
| Operator | |
| Select Auto or Others for the Operator from the dropdown list. <ul style="list-style-type: none"> ● Auto: the system will detect the operator from the inserted SIM card and set up accordingly. ● Others: users can set up the operator manually. | AUTO |
| User Name | |
| This name is provided by the operator. When “Auto” is selected, the system will set the name up automatically and users cannot change the setting. | N/A |
| Password | |
| This password is provided by the operator. When “Auto” is selected, the system will set the password up automatically and users cannot change the setting. | N/A |

| Description | Default |
|--|---------------|
| APN (Access Point Name) | |
| This APN is provided by the operator. When "Auto" is selected, the system will set the APN up automatically and users cannot change the setting. | 3gnet |
| Authorization Mod | |
| Options are "Auto", "PAP" and "CHAP". | Auto |
| Dial-Up Number | |
| This number is provided by the operator. When "Auto" is selected, the system will set the number up automatically and users cannot change the setting. | *99# |
| Dial-Up Mode | |
| Options are : <ul style="list-style-type: none"> ● Always online: stay connected and once a disconnection is detected, the router will redial to connect automatically. ● On-demand connection: redial when connection to the internet is on demand. ● Manual connection: users dial to connect and when it fails to connect, it will not redial. | Always online |
| Redial Interval | |
| Set up the time to redial when the system fails to connect. This will only be executed when the option "Always online" or "On-demand connection" is selected. | 30 |
| Redial Times | |
| Set up the maximum redial time, 0 indicating infinity. This will only be executed when the option "Always online" or "On-demand connection" is selected. | 5 |
| Max Idle Time | |
| Set up the maximum idle time. When the idle time exceeds the set value, the router will disconnect and then redial, 0 indicating not to disconnect. | 180 |
| Connection Check Interval | |
| Set up the connection check interval. Check the connectivity, if the connection is lost, it will redial automatically, 0 indicating not to check the connectivity. | 60 |
| Connection Check Times | |
| Set up the connection check times, 0 indicating infinity. Once a disconnection is detected, and the option "Always online" or "On-demand connection" is selected, the router will redial according to the set value in the Redial Times. | 5 |
| MTU | |
| Maximum Transmission Unit is the largest packet that can be transmitted over packet based networks. | 1492 |

3.2.4 PIN Management

Users can unlock SIM card locked by PIN code and save the code in DX device and check the PIN status.


🏠 NETWORK > PIN Management

☰ SIM1 PIN Management


| | |
|--------------------|---|
| SIM card status | PIN locked |
| Remaining attempts | 3 |
| PIN | <input type="text"/> (4-12,number) |
| Remember my PIN | <input type="checkbox"/> (Use this PIN to verify in next reboot) |
| | <input type="button" value="Save"/> <input type="button" value="Cancel"/> |

☰ SIM2 PIN Management


SIM card status Inactive

| Description | Default |
|--|---------|
| SIM card status | |
| <ul style="list-style-type: none"> Inactive: SIM Card is inserted but communication module has not been activated. <p> Notice</p> <ul style="list-style-type: none"> DX3001 supports dual SIM with the condition that two SIM cards cannot be activated at the same time. ° No Sim: No SIM cards detected in the slot. Normal: SIM Card is inserted correctly and functions normally. PIN Locked: SIM Card is in the slot. Need the associated PIN code to function. PUK Locked: Exceed the maximum PIN code input tries. Need the correct PUK (Personal Unlocking Key) to unlock and resume normal operation. | N/A |
| Remaining attempts | |
| The allowable entry attempts is normally 3 times. When the remaining attempts is zero and the SIM card is locked, users must ask for help from operators or unlock it with PUK code. | 3 |
| PIN | |
| A personal identification number used in SIM card is a security measure to protect SIM card from being stolen. | N/A |

| Description | Default |
|---|---------|
| Remember my PIN | |
| Enable this function to remember the PIN code in the system and the code would be input automatically every time after booting. | Uncheck |

 **Notice**

- If you enter the wrong PIN three times, your SIM card will be locked. Once SIM card is blocked, you will need PUK code to unlock it or find operator's help

| | |
|-----------------------|---|
| Operation Instruction | <p>Example: Insert and unlock a PIN-locked SIM card</p> <ol style="list-style-type: none"> 1. Insert a SIM card locked by PIN codes into the SIM1 slot of the DX Shell. 2. Login to DX system. 3. Follow the path: Network -> PIN Management to access "SIM1 PIN Management". 4. Enter the correct PIN code. 5. Click "Save" and a "unlock successful" message would be displayed. |
| Illustration |  |

3.2.5 WAN Setting

🏠 NETWORK > WAN

☰ WAN Settings

| | |
|----------------------|--------------------------------------|
| WAN Mode | <input type="text" value="DHCP"/> |
| IP Allocation Method | <input type="text" value="Dynamic"/> |
| IP Address | <input type="text" value="0.0.0.0"/> |
| Network Mask | <input type="text" value="0.0.0.0"/> |
| Gateway Address | <input type="text" value="0.0.0.0"/> |
| Packet MTU | <input type="text" value="1500"/> |

(Don't change the settings unless really need to)

| | |
|--------------------------|--------------------------------------|
| Retrieve DNS Address By: | <input type="text" value="Dynamic"/> |
| Primary DNS | <input type="text" value="0.0.0.0"/> |
| Secondary DNS | <input type="text" value="0.0.0.0"/> |

3

| Description | Default |
|---|---------|
| WAN Mode | |
| Your device can connect to the internet via the WAN port with a Dynamic IP or Static IP. <ul style="list-style-type: none"> ● Static IP: Manually set up the IP address. ● Dynamic IP: DHCP (Dynamic Host Configuration Protocol) allows you to obtain an IP address automatically from your router. | DHCP |
| IP Allocation Method | |
| The IP Allocation Method is the same as the WAN Connection Mode that you have set. You can apply to different option by modifying the WAN Connection Mode. <ul style="list-style-type: none"> ● Dynamic: Dynamic Host Configuration Protocol (DHCP) allows you to obtain an IP address automatically from your router. ● Manual: Manually set up the IP address (Static). | DHCP |
| IP Address | |
| Set up an IP address for your device to connect to the internet via the WAN port. It's configurable when the mode is set to Static. | 0.0.0.0 |
| Network Mask | |
| Set up the WAN network mask. It's configurable when the mode is set to Static. | 0.0.0.0 |
| Gateway Address | |
| Set up the gateway address. It's configurable when the mode is set to Static. | 0.0.0.0 |
| MTU | |
| Maximum Transmission Unit is the largest packet that can be transmitted over packet based networks. | 1500 |
| Retrieve DNS Address By | |
| The Retrieve DNS Address Method is the same as the WAN Connection Mode that you have set. You can apply to different option by modifying the WAN Connection Mode. DNS address can be retrieved by DHCP setup or manually set. <ul style="list-style-type: none"> ● Dynamic: Dynamic Host Configuration Protocol (DHCP) allows you to obtain an IP address automatically from your router. ● Manual: Manually set up the IP address (Static). | DHCP |
| Primary DNS | |
| Set up the primary DNS. It's configurable when the mode is set to Static. | 0.0.0.0 |
| Secondary DNS | |
| Set up the secondary DNS. It's configurable when the mode is set to Static. | 0.0.0.0 |

3.2.6 LAN

This page is used for setting up the LAN, including IP Address, Network Mask, and DHCP Server.

🏠 NETWORK > LAN

☰ LAN Settings

IP Address

Network Mask

DHCP Server

Address Lease Time

First IP Address 192.168.1.

Last IP Address 192.168.1.

STP

3

| Description | Default |
|--|---------------|
| IP Address | |
| Set up an IP address for your device. | 192.168.1.1 |
| Network Mask | |
| Set up the LAN network mask. | 255.255.255.0 |
| DHCP Server | |
| Dynamic Host Configuration Protocol allows you to obtain an IP address automatically from your router. You can enable or disable this functionality. | Enable |
| Address Lease Time | |
| To set up the address lease time so that a client doesn't hold an IP address indefinitely. It allows for a mechanism to gracefully reuse DHCP addresses. Options here are 1 to 3 days. | One day |
| First IP Address | |
| To increase the number of addresses available to clients, you can change the Start Address. | 192.168.1.100 |
| Last IP Address | |
| To increase the number of addresses available to clients, you can change the End Address. | 192.168.1.200 |
| STP | |
| Enable or disable STP(spanning tree protocol) function | Enable |

**Notice**

- STP is a network protocol that builds a logical loop-free topology for Ethernet networks. The basic function of STP is to prevent bridge loops and the broadcast radiation that results from them. Enable this option will increase traffic usage

3.3 Firewall

You can set up firewall configurations, including the Basic Configurations, DMZ Configurations, Port Forward, Port Trigger, URL Filter, MAC Filter, and IP Filter.

3.3.1 Basic

This page is used for setting up the basic firewall settings, including the SPI firewall switch, WAN Ping response, LAN SSH function and WAN SSH.

[🏠 FIREWALL > Basic](#)

Basic Firewall Settings

Firewall

WAN Ping

LAN SSH

WAN SSH

| Description | Default |
|--|---------------|
| Firewall | |
| The SPI Firewall keeps track of the state of network connections travelling across it, protecting your Internet connection against Internet threats and Denial of Service (DoS). | Enable |
| WAN Ping | |
| It creates a filter that your router not to respond to Ping command and prevents other users on the internet from pinging your pc and gaining your IP address. | Not responded |
| LAN SSH | |
| Set up whether to allow LAN end to connect with the router via SSH. | Enable |
| WAN SSH | |
| Set up whether to allow WAN end to connect with the router via SSH. | Disable |

3.3.2 DMZ

This page is used for setting up the DMZ server.

[FIREWALL > DMZ](#)

DMZ

DMZ Server

DMZ Host IP Address

3

| Description | Default |
|---|---------|
| DMZ Server | |
| Demilitarized zone (DMZ) is a special segment of the local network reserved for servers accessible from the Internet, adding an additional layer of security. | Disable |
| DMZ Host IP Address | |
| Set up the IP address for the DMZ host. | N/A |

3.3.3 Port Forward

This page is used for setting up the port forward, including configuring the Network Services, Service Name, Protocol, Public Port, Server Port, and Server IP Address.

Click the "Add A Portforward Rule" to add port forwarding entries to the router.

[FIREWALL > Port Forward](#)

| ID | Service Name | Protocol | Public Port | Server Port | Server IP Address |
|----|--------------|----------|-------------|-------------|-------------------|
| | | | | | |

After clicking the "Add A Portforward Rule" , you will see the following page.

[FIREWALL > Port Forward](#)

Add A Portforward Rule

Network Services

Service Name

Protocol

Public Port (1~65534)

Server Port (1~65534)

Server IP Address 192.168.1.

| Description | Default |
|--|-------------|
| Network Services | |
| Select the common network services. Refer to the following common service list for optional values. | Customized |
| Service Name | |
| Set up the service name for port forwarding. The name is composed of letters, numbers and underline, starting with a letter or number. The maximum string length is 32 bytes. | N/A |
| Protocol | |
| Set up the protocol type for port forwarding. | TCP/UDP |
| Public Port | |
| Set up the public port for port forwarding. The port range is 1~65534. A Public port should be less than or equal to the server port. | Single Port |
| Server Port | |
| <p>Set up the server port for port forwarding. The port range is 1~65534. A server port should be greater than or equal to the public port.</p> <p>When the public port is set to a Single Port, the server port can only be set to a Single Port. When the public port is set to a Port Range, the server port can be set to a Single Port or a Port Range. And when the public port is set to a single port, all the port will be forwarded to ONE single port.</p> <p>Examples of different port forwarding settings:</p> <p>1:1</p> <p>Public Port <input type="text" value="Single Port"/> <input type="text" value="1001"/> (1~65534)</p> <p>Server Port <input type="text" value="Single Port"/> <input type="text" value="80"/> (1~65534)</p> <p>N:1</p> <p>Public Port <input type="text" value="A Port Range"/> <input type="text" value="1001"/> - <input type="text" value="1008"/> (1~65534)</p> <p>Server Port <input type="text" value="Single Port"/> <input type="text" value="80"/> (1~65534)</p> <p>N:N</p> <p>Public Port <input type="text" value="A Port Range"/> <input type="text" value="1001"/> - <input type="text" value="1008"/> (1~65534)</p> <p>Server Port <input type="text" value="A Port Range"/> <input type="text" value="1001"/> - <input type="text" value="1008"/> (1~65534)</p> | Single Port |
| Server IP Address | |
| Set up the server IP address that applies to the port mapping rule. | 192.168.1.* |

| Common Service List for Port Forwarding | | | |
|---|-------------------|---------------|-------------|
| Service name | Protocol | Starting Port | Ending Port |
| Customized | TCP, UDP, TCP/UDP | 1~65534 | 1~65534 |
| FTP | TCP | 20 | 21 |
| HTTP | TCP | 80 | 80 |
| ICUII | TCP | 23566 | 23566 |
| IP_PHONE | TCP | 6670 | 6670 |
| NetMeeting | TCP | 1720 | 1720 |
| News | TCP | 119 | 119 |
| PPTP | TCP/UDP | 1723 | 1723 |
| Telnet | TCP | 23 | 23 |
| Quakell/III | TCP/UDP | 27960 | 27960 |
| Real-Audio | TCP | 6970 | 7170 |

3.3.4 Port Trigger

This page is used for setting up the port trigger, including configuring the Service Name, Service User, Service Type, Trigger Port, Protocol Role, Begin Port, End Port, and Status.

Port triggering is port forwarding with an on/off switch for the ports that have been forwarded. Have data flow out of a trigger port or not by enabling or disabling this functionality. Set up the time for the Port Trigger Timeout and click "Save" to save the setting.

Click the "Add A Trigger Rule" to add port trigger entries to the router.

[🏠 FIREWALL > Port Trigger](#)

Port Trigger Port Trigger Timeout Minute

| ID | Service Name | Service Type | Inbound Connection | Service User | Status |
|----|--------------|--------------|--------------------|--------------|--------|
|----|--------------|--------------|--------------------|--------------|--------|

After clicking the "Add A Trigger Rule" , you will see the following page.

🏠 FIREWALL > Port Trigger

☰ Add A Trigger Rule

Service Name

Service User

Service Type

Trigger Port (1~65534)

Inbound Connection

Protocol Role

Begin Port (1~65534)

End Port (1~65534)

Status

Save

Back

| Description | Default |
|---|-------------|
| Service Name | |
| Set up the service name for port triggering. The name is composed of letters, numbers and underline, starting with a letter or number. The maximum string length is 32 bytes. | N/A |
| Service User | |
| Select the service user to apply the port triggering rule. | Any Address |
| Service Type | |
| Set up the protocol type for port triggering. | TCP |
| Triggering Port | |
| Set up the triggering port. The port range is 1~65534. | N/A |
| Protocol Role | |
| Set up the protocol type for the inbound connection. | TCP/UDP |
| Begin port | |
| Set up the starting port for the inbound connection. The port range is 1~65534. | N/A |
| End Port | |
| Set up the ending port for the inbound connection. The port range is 1~65534. | N/A |
| Status | |
| Enable/disable the port triggering functionality. | Disable |

3.3.5 URL Filter

This page is used for setting up the URL Filter, including configuring the URL Address, LAN IP Address and Status.

URL Filter is used to block particular website from the local network. Select Enable/Disable to activate/deactivate this functionality. Click the "Add An URL Address" to block the URL.

🏠 FIREWALL > URL Filter

URL Address Filter Disable ▾ Save Add An URL Address

| ID | URL Address | LAN IP Address | Status |
|----|-------------|----------------|--------|
|----|-------------|----------------|--------|

After clicking the "Add An URL Address" , you will see the following page.

🏠 FIREWALL > URL Filter

☰ Add URL

URL Address

LAN IP Address Any address ▾

Status Enabled ▾

Save Back

| Description | Default |
|--|-------------|
| URL Address | |
| Manually input the URL address that you'd like to block, for example www.baidu.com. | |
| LAN IP Address | |
| Set up the LAN IP address that you'd like to block. Options are "Any Address", "Single Address" and "Address Range". | Any Address |
| Status | |
| Enable/disable the URL Filter functionality. | Enable |

3.3.6 MAC Filter

This page is used for setting up the MAC Filter, including configuring the MAC Address, Device Name and Status.

MAC Filter is used to block particular MAC address from the local network. Select Enable/Disable to activate/deactivate this functionality. Click the "Add A MAC Address" to block the MAC Address.

[FIREWALL > MAC Filter](#)

MAC Filter Disable ▾ Save Add A MAC Address

| ID | MAC Address | Device Name | Status |
|----|-------------|-------------|--------|
|----|-------------|-------------|--------|

After clicking the "Add A MAC Address" , you will see the following page.

[FIREWALL > MAC Filter](#)

Add A MAC Address

MAC Address

Device Name

Status Enabled ▾

Save Back

| Description | Default |
|--|---------|
| MAC Address | |
| Manually input the MAC address that you'd like to block. | |
| Device Name | |
| Set up the device name corresponding to the set MAC address. | |
| Status | |
| Enable/disable the MAC Filter functionality. | Enable |

3.3.7 IP Filter

This page is used for setting up the IP Filter, including configuring the Source IP, Source Port, Destination IP, Destination Port, Protocol and Status.

IP Filter is used to block particular IP address from the local network. Select Enable/Disable to activate/deactivate this functionality. Click the "Add An IP Address" to block the IP Address.

[FIREWALL > IP Filter](#)

IP Filter Disable ▾ Save Add An IP Address

| ID | Source IP Address Range | Source Port Range | Range Of Destination IP Address | Range Of Destination Port | Protocol | Status |
|----|-------------------------|-------------------|---------------------------------|---------------------------|----------|--------|
|----|-------------------------|-------------------|---------------------------------|---------------------------|----------|--------|

After clicking the "Add An IP Address" , you will see the following page.

🏠 FIREWALL > IP Filter

☰ Add An IP Address

Source IP

Source Port

Destination IP

Destination Port

Protocol

Status

3

| Description | Default |
|---|-------------|
| Source IP | |
| Set up the source IP. | Any Address |
| Source Port | |
| Set up the source port where the datagram came from. | Any Address |
| Destination IP | |
| Set up the destination IP. | Any Address |
| Destination Port | |
| Set up the destination port where the datagram is going to. | Any Address |
| Protocol | |
| Set up the protocol type for the IP Filter. | TCP/UDP |
| Status | |
| Enable/disable the URL Filter functionality. | Enable |

3.3.8 Remote Web Manage Setting

Users can access DX webpage with a public IP address via WAN to configure remote web manage settings.

Access with <http://123.123.123.1:8080> via Web browser to setup DX configuration



Public IP address 123.123.123.1:8080



🏠 FIREWALL > Remote Web Manage Setting

☰ Remote WAN Manage

Remote WAN Manage Function ▾

Remote WAN Access Port

Save Cancel

| Description | Default |
|---|---------|
| Remote WAN Manage Function | |
| Enable or disable Remote WAN Manage Function which allows users to access the management webpage and configure various parameters/operating modes through WAN. | Disable |
| Remote WAN Access Port | |
| The default value of Remote WAN Access Ports is set as 880. Users can configure the value depending on their own needs, while the ports mostly used by other protocols are not recommended in order to prevent conflicts. ° | 8080 |

Operation Instruction

Example: Access DX webpage with a public IP address via WAN

1. Login to DX system.
2. Follow the path: NETWORK -> Connection
3. Set Primary Connection as WAN.
4. Obtain an IP address from the ISP.(e.g. 123.123.123.1)
5. Follow the path: FIREWALL -> Remote Web Manage
6. Set Remote WAN Manage Function as Enable
7. Set Remote WAN Access Port as 8080
8. Access DX Configuration webpage with <http://123.123.123.1:8080> via Web browser on your PC.

Access with <http://123.123.123.1:8080> via Web browser to setup DX configuration



Public IP address 123.123.123.1:8080



Illustration

Remote Web Manage Setting Remote WAN Manage

🏠 FIREWALL > Remote Web Manage Setting

☰ Remote WAN Manage

Remote WAN Manage Function ▾

Remote WAN Access Port

Save Cancel

3.4 VPN

You can set up the configuration of VPN in this function, device support IPSec, OPENVPN, PPTL, L2TP and GRE VPN. This function also provides certificate management and VPN log download.

3.4.1 IPSec

This page is used for set up the parameters of the IPSec VPN. Currently system support IPSec client mode only.

🏠 VPN > IPSec Setting

☰ Connection Management

NAT Traversal:

| Name | Enabled | Status | Local Interface | Local Subnet | Peer Subnet | Operation |
|------|---------|--------|-----------------|--------------|-------------|-----------|
|------|---------|--------|-----------------|--------------|-------------|-----------|

☰ IPSec Setting

Name: Enable:

IPSec Type: IPSec Role:

Local WAN Interface: Peer WAN Address:

Local Subnet: / Peer Subnet: /

Local ID: Peer ID:

☰ Phase1

IKE Encryption: IKE Integrity:

IKE DH Group: IKE Lifetime: (120-86400sec.)

☰ Phase2

ESP Encryption: ESP Integrity:

PFS: ESP Keylife: (120-86400sec.)

DH Group:

☰ Advanced

Negotiation Mode: IP Compress:

DPD Detection: Time Interval: (Sec.)

Timeout: (Sec.) DPD Action:

☰ Authentication

Use A Pre-Shared Key:

Use The X.509 Cert:

3

| Description | Default |
|--|--------------|
| Name | |
| Input the name of IPSec connection, it cannot be repeated with other connection's name. Name can be up to 20 characters long. | |
| Enable | |
| Enable or disable this connection. | False |
| IPSec Type | |
| Set up the working mode of the IPSec, currently support "Net to Net" only | Net-to-Net |
| IPSec Role | |
| Set up the role of the router in IPSec, currently support "Client" only | Client |
| Local WAN Interface | |
| Local end WAN interface, system will auto assign it base on connection status | WAN |
| Peer WAN Address | |
| IP/domain name of end opposite | |
| Local Subnet | |
| IPSec local protects subnet and subnet mask, i.e. 192.168.1.0/24 | |
| Peer Subnet | |
| IPSec opposite end protects subnet and subnet mask, i.e.192.168.7.0/24; | |
| Local ID | |
| Local end identification, IP and domain name are available | |
| Peer ID | |
| Opposite end identification, IP and domain name are available | |
| IKE Encryption | |
| IKE phase encryption mode. Options are "3DES", "DES", "AES(128bit)" and "AES(256bit)" | 3DES |
| IKE Integrity | |
| IKE phase integrity solution. Options are "MD5","SHA1" and "SHA2(256)" | MD5 |
| IKE DH Group | |
| DH exchange algorithm. Options are "Group1(768)", "Group2(1024)", "Group5(1536)", "Group14(2048)", "Group15(3072)", "Group16(4096)", "Group17(6144)" and "Group18(8192)" | Group2(1024) |
| IKE Lifetime | |
| Set IKE life time, current unit is second, range is 120~86400s | 120 |
| ESP Encryption | |
| ESP phase encryption mode. Options are "3DES", "DES", "AES(128bit)" and "AES(256bit)" | 3DES |
| ESP Integrity | |
| ESP phase integrity solution. Options are "MD5" and "SHA1" | MD5 |
| PFS | |
| Enable or disable PFS(Perfect Forward Secrecy) | Enabled |

| Description | Default |
|---|--------------|
| ESP Keylife | |
| Set up ESP life time, current unit is second, range is 120~86400s | 120 |
| DH Group | |
| DH exchange algorithm in ESP phase. Options are "Group1(768)", "Group2(1024)", "Group5(1536)", "Group14(2048)", "Group15(3072)", "Group16(4096)", "Group17(6144)" and "Group18(8192)" | Group2(1024) |
| Negotiation Mode | |
| Set up the mode of the IKE negotiation, Options are "Main" and "Aggressive" | Main |
| IP Compress | |
| Enable or disable IP Payload compression | Enabled |
| DPD Detection | |
| Enable or disable DPD detection | Enabled |
| Time Interval | |
| Set time interval of DPD detection, current unit is second | 60 |
| Timeout | |
| Set timeout of DPD detection, current unit is second | 60 |
| DPD Action | |
| Set the action when detect the connection is drop | Hold |
| Authentication | |
| Choose use share encryption option (PSK) or certificate authentication option. PSK can be up to 24 characters long; Certificate can be maintained by Certificate function | |

3.4.2 OPENVPN

This page is used for set up the parameters of the OPENVPN. Currently system support OPENVPN client mode only.

🏠 VPN > OpenVPN

Basic Settings

| | | | |
|------------------------|--------------------------------------|-------------------------|---|
| OpenVPN Mode | <input type="text" value="Client"/> | | |
| OpenVPN Server | <input type="text"/> | | |
| Port | <input type="text" value="1194"/> | Protocol | <input type="text" value="UDP"/> |
| Tunnel Device | <input type="text" value="TUN"/> | Encryption | <input type="text" value="Blowfish CBC"/> |
| Hash Algorithm | <input type="text" value="SHA1"/> | NsCertType Verification | <input type="text" value="Disable"/> |
| LZO Compression | <input type="text" value="Disable"/> | NAT | <input type="text" value="Disable"/> |
| Remote Subnet | <input type="text"/> | MTU | <input type="text" value="1500"/> |
| Remote Subnet Mask | <input type="text"/> | Tunnel UDP Fragment | <input type="text"/> |
| Connect Check Interval | <input type="text" value="60"/> | Connect Check Times | <input type="text" value="5"/> |

Authentication

| | |
|----------------------|---|
| Authentication | <input type="text" value="Pre-Shared Key"/> |
| Use A Pre-Shared Key | <input type="text"/> |
| Local IP | <input type="text"/> |
| Remote IP | <input type="text"/> |

Status

Connection Status Inactive

Save

Cancel

| Description | Default |
|--|--------------|
| OPENVPN Mode | |
| Set up the working mode of the OPENVPN, options are "Disabled" and "Client" | Disabled |
| OPENVPN Server | |
| Set up the IP/Domain name of the OPENVPEN server | |
| Port | |
| Set up the listen port of OPENVPN client | 1194 |
| Protocol | |
| Set up the protocol type, options are "UDP" and "TCP" | UDP |
| Tunnel Device | |
| Set up the interface type, options are "TUN" and "TAP" TUN – Router mode TAP – Bridge mode | TUN |
| Encryption | |
| Set up the encryption mode, options are "Blowfish CBC", "AES-128 CBC", "AES-192 CBC", "AES-256 CBC" and "AES-512 CBC" | Blowfish CBC |
| Hash Algorithm | |
| Set up hash algorithm, options are "None", "SHA1", "SHA256", "SHA512" and "MD5". | SHA1 |
| nsCertType verification | |
| Enable or disable to support ns certificate type. | Disable |
| LZO Compression | |
| Enable or disable use LZO compression for data transfer | Disabled |
| NAT | |
| Enable or disable Network Address Translation | Disabled |
| Remote Subnet | |
| Set up remote subnet. | |
| MTU | |
| Set up the Maximum Transmission Unit of the tunnel | 1500 |
| Remote Subnet Mask | |
| Set up the remote subnet mask. | |
| Tunnel UDP Fragment | |
| Set the size of UDP packet fragment. Input range is 1-65536 | |
| Connection Check Interval | |
| Set up the connection check interval. Check the connectivity, if the connection is lost, it will redial automatically, 0 indicating not to check the connectivity. | 60 |
| Connection Check Times | |
| Set up the connection check times, 0 indicating infinity. Once a disconnection is detected, the router will redial according to the set value in the Redial Times. | 5 |

| Description | Default |
|--|----------------|
| Authentication | |
| Choose use Pre-Shared key, username/password or certificate authentication option. | Pre-Shared key |
| Connection Status | |
| Display the current connection status | |

3.4.3 PPTP

This page is used for set up the parameters of the PPTP VPN. Currently system support PPTP client mode only.

[Home](#) [VPN](#) > PPTP

Basic Settings

| | |
|---------------------------|--|
| PPTP Mode | Client <input type="button" value="v"/> |
| PPTP Server | <input type="text"/> |
| User Name | <input type="text"/> |
| Password | <input type="text"/> <input type="checkbox"/> Unmask |
| Obtain IP | Auto <input type="button" value="v"/> |
| IP Address | 0.0.0.0 |
| Subnet Mask | 255.255.255.0 |
| Gateway | 0.0.0.0 |
| DNS | 0.0.0.0 |
| Authorization Mode | Auto <input type="button" value="v"/> |
| MPPE | Disabled <input type="button" value="v"/> |
| NAT | Disabled <input type="button" value="v"/> |
| MTU | 1420 (576-1420) |
| Connection Check Interval | 60 Sec(0 means not checked) |
| Connection Check Times | 5 |
| Allow Local LAN Access | Disabled <input type="button" value="v"/> |
| Connection Status | Inactive |

| Description | Default |
|--|----------|
| PPTP Mode | |
| Set up the working mode of the PPTP, options are "Disabled" and "Client" | Disabled |
| PPTP Server | |
| Set up the IP/Domain name of the PPTP server | |
| User Name | |
| Set up the username to login the PPTP server | |
| Password | |
| Set up the password to login the PPTP server | |
| Obtain IP | |
| Set up the method of obtain IP, options are "Auto" and "Manual" Auto – Obtain IP from PPTP server automatically Manual – assign IP address manual | Auto |
| IP Address | |
| PPTP Client IP address | |
| Subnet Mask | |
| PPTP Client subnet mask | |
| Gateway | |
| PPTP Client gateway address | |
| DNS | |
| PPTP Client DNS server address | |
| Authorization Mode | |
| Options are "Auto", "PAP" and "CHAP". | Auto |
| MPPE | |
| Enable or disable Microsoft Point-to-Point Encryption | Disabled |
| NAT | |
| Enable or disable Network Address Translation | Disabled |
| MTU | |
| Set up the Maximum Transmission Unit of the tunnel | 1420 |
| Connection Check Interval | |
| Set up the connection check interval. Check the connectivity, if the connection is lost, it will redial automatically, 0 indicating not to check the connectivity. | 60 |
| Connection Check Times | |
| Set up the connection check times, 0 indicating infinity. Once a disconnection is detected, the router will redial according to the set value in the Redial Times. | 5 |
| Allow Local LAN Access | |
| Setup whether allow local LAN device access PPTP server | Disabled |
| PPTP Server Subnet | |
| Setup PPTP server subnet | |

| Description | Default |
|---------------------------------------|---------|
| Connection Status | |
| Display the current connection status | |

3.4.4 L2TP

This page is used for set up the parameters of the L2TP VPN. Currently system support L2TP client mode only.

🏠 VPN > L2TP

Basic Settings

| | | |
|---------------------------|----------------------|---------------------------------|
| L2TP Mode | Client | ▼ |
| L2TP Server | <input type="text"/> | |
| User Name | <input type="text"/> | |
| Password | <input type="text"/> | <input type="checkbox"/> Unmask |
| Obtain IP | Auto | ▼ |
| IP Address | 0.0.0.0 | |
| Subnet Mask | 255.255.255.0 | |
| Gateway | 0.0.0.0 | |
| DNS | 0.0.0.0 | |
| Authorization Mode | Auto | ▼ |
| MPPE | Disabled | ▼ |
| NAT | Disabled | ▼ |
| MTU | 1460 | (576-1460) |
| Connection Check Interval | 60 | Sec(0 means not checked) |
| Connection Check Times | 5 | |
| Allow Local LAN Access | Disabled | ▼ |
| IPSec Encryption | Disabled | ▼ |

Save

Cancel

| Description | Default |
|--|----------|
| L2TP Mode | |
| Set up the working mode of the L2TP, options are "Disabled" and "Client" | Disabled |
| L2TP Server | |
| Set up the IP/Domain name of the L2TP server | |
| User Name | |
| Set up the username to login the L2TP server | |
| Password | |
| Set up the password to login the L2TP server | |
| Obtain IP | |
| Set up the method of obtain IP, options are "Auto" and "Manual" Auto – Obtain IP from PPTP server automatically Manual – assign IP address manual | Auto |
| IP Address | |
| PPTP Client IP address | |
| Subnet Mask | |
| PPTP Client subnet mask | |
| Gateway | |
| PPTP Client gateway address | |
| DNS | |
| PPTP Client DNS server address | |
| Authorization Mode | |
| Options are "Auto", "PAP" and "CHAP". | Auto |
| MPPE | |
| Enable or disable Microsoft Point-to-Point Encryption | Disabled |
| NAT | |
| Enable or disable Network Address Translation | Disabled |
| MTU | |
| Set up the Maximum Transmission Unit of the tunnel | 1460 |
| Connection Check Interval | |
| Set up the connection check interval. Check the connectivity, if the connection is lost, it will redial automatically, 0 indicating not to check the connectivity. | 60 |
| Connection Check Times | |
| Set up the connection check times, 0 indicating infinity. Once a disconnection is detected, the router will redial according to the set value in the Redial Times. | 5 |
| Allow Local LAN Access | |
| Setup whether allow local LAN device access L2TP server | Disabled |
| L2TP Server Subnet | |
| Setup L2TP server subnet | |

| Description | Default |
|---|----------|
| IPSec Encryption | |
| Set up the encryption solution of L2TP. Options are “Disabled”, “Use a Pre-Shared Key” and “Use the Certificate”. | Disabled |
| Input The PSK | |
| Input the Pre-Shared Key | |
| Select The Certificate | |
| Select the Certificate user maintain it by Certificate function | |
| IPSec Peer ID | |
| Input the peer ID of the IPSec | |
| Connection Status | |
| Display the current connection status | |

3.4.5 GRE

This page is used for set up the parameters of the GRE VPN. User can create up to 10 GRE tunnels.

🏠 VPN > GRE

Add

| Tunnel Name | Status | Tunnel Interface Src IP/Mask | Tunnel Interface Dst IP/Mask | Peer Subnet | Operation |
|-------------|--------|------------------------------|------------------------------|-------------|-----------|
|-------------|--------|------------------------------|------------------------------|-------------|-----------|

🏠 VPN > GRE

☰ Tunnel Setting


| | |
|------------------------------|--|
| Tunnel Name | <input type="text"/> |
| Enable Tunnel | Yes ▾ |
| Tunnel Interface Src IP/Mask | <input type="text"/> / <input type="text"/> |
| Tunnel Interface Dst IP/Mask | <input type="text"/> / <input type="text"/> |
| Tunnel Based Src IP | <input type="text"/> |
| Tunnel Based Dst IP | <input type="text"/> |
| Peer IP Address/Mask | <input type="text"/> / <input type="text"/> |
| Tunnel Key | <input type="text"/> (option,0-4294967296) |
| Connection Check Interval | <input type="text"/> Sec.(0 means not checked) |
| Connection Check Times | <input type="text"/> |

Save

Cancel

| Description | Default |
|--|---------|
| Tunnel Name | |
| Input the name of this tunnel, it can not be repeated with other tunnel's name. | |
| Enable Tunnel | |
| Enable or disable this tunnel. | Yes |
| Tunnel Interface Src IP/Mask | |
| The local tunnel IP address and mask | |
| Tunnel Interface Dst IP/Mask | |
| The remote tunnel IP address and mask | |
| Tunnel Based Src IP | |
| The Local WAN IP address | |
| Tunnel Based Dst IP | |
| The remote WAN IP address | |
| Peer IP Address/Mask | |
| The remote gateway local subnet | |
| Tunnel Key | |
| Input the secret key of the tunnel, number only, range is from 0 to 4294967296 | |
| Connection Check Interval | |
| Set up the connection check interval. Check the connectivity, if the connection is lost, it will redial automatically, 0 indicating not to check the connectivity. | 0 |
| Connection Check Times | |
| Set up the connection check times, 0 indicating infinity. Once a disconnection is detected, the router will redial according to the set value in the Redial Times. | 3 |

Network diagram as below:



3.4.6 Certificate

This page is used for user import the certificate which will use in IPsec or OPENVPN function.

🏠 VPN > Certificate Management

☰ Connection Management

| Group Name | CA | Public Cert | Private Cert | Expired Date | Operation |
|------------|----|-------------|--------------|--------------|-----------|
|------------|----|-------------|--------------|--------------|-----------|

Add

🏠 VPN > Certificate Management

☰ Certificate Management

Group Name

Import CA 未...件

Import Public Cert 未...件

Import Private Key 未...件

Import Peer Public Cert 未...件

Import CRL 未...件

| Description | Default |
|--|---------|
| Group Name | |
| Setup the name of cert group, it cannot be repeated with other cert group. | |
| CA | |
| Import CA certificate file | |
| Public Cert | |
| Import public certificate file | |
| Private Cert | |
| Import public certificate file | |
| Peer Public Cert | |
| Import peer end public certificate file | |

| Description | Default |
|---|---------|
| CRL | |
| Import certificate revocation list | |
| Password | |
| Input the password about the certificate file if the file with a password | |
| Expired Date | |
| Show the expired date of the cert. | |

3

3.4.7 VPN Log

This page is used for download specified VPN log. Select the VPN type and click "Download" to save the log to local.

VPN Setting VPN Log

VPN > VPN Log

VPN Log

Download the logs of VPN function to local PC. Specify logs of

IPSec

Download

3.5 Interface

3.5.1 RS232

RS232 (Recommended Standard - 232) is a telecommunication standard for binary serial communications between devices. You can set up the configurations for RS232, including Baud Rate, Data Bits, Stop Bits, Parity Bits and Flow Control.

SYSTEM > RS232 Configurations

RS232 Configurations

| | |
|----------------|------------------|
| Working Mode | Master mode |
| Baud Rate | 9600 |
| Data Bits | 8 |
| Stop Bits | 1 |
| Parity Bits | None |
| Flow Control | None |
| Modbus Mode | ModBus RTU |
| Modbus Timeout | 1000 (50~2000ms) |
| Retry Times | 1 (1~10) |

Save

Cancel

| Description | Default |
|--|------------|
| Working Mode | |
| Select the working mode for the current active serial port. <ul style="list-style-type: none"> ● Master mode: This mode is suitable for the DX-3001 to perform the read/write tasks on the open register of the Slave. ● Close: Disable this functionality. | Close |
| Baud Rate | |
| Set up the baud rate for the serial port. Options are 2400, 4800, 9600, 19200, 38400, 57600 and 115200. | 9600 |
| Data Bits | |
| Set up the data bits for the serial port. | 8 |
| Stop Bits | |
| Set up the stop bits for the serial port. Options are 1 and 2. | 1 |
| Parity Bits | |
| Set up the parity bits for the serial port. Options are None, Odd and Even. | None |
| Flow Control | |
| Set up the flow control. Options are None, XON, XOFF, RTS, and CTS. | None |
| MODBUS Mode | |
| Set up the communication mode for the device. | MODBUS RTU |
| MODBUS Timeout | |
| Set up the timeout timer from 50ms to 2000ms. If the set value is out of range, it will be automatically changed to its maximum or minimum value. | 1000ms |

3.5.2 RS485

RS-485 (Recommended Standard - 485) is a telecommunication standard for binary serial communications between devices. You can set up the configurations for RS-485, including Baud Rate, Data Bits, Stop Bits, Parity Bits, and many more.

🏠 SYSTEM > RS485 Configuration

☰ RS485 Configuration

| | |
|----------------|---|
| Working Mode | <input type="text" value="Master mode"/> |
| Baud Rate | <input type="text" value="9600"/> |
| Data Bits | <input type="text" value="8"/> |
| Stop Bits | <input type="text" value="1"/> |
| Parity Bits | <input type="text" value="None"/> |
| Modbus Mode | <input type="text" value="ModBus RTU"/> |
| Modbus Timeout | <input type="text" value="1000"/> (50~2000ms) |
| Retry Times | <input type="text" value="1"/> (1~10) |

| Description | Default |
|--|------------|
| Working Mode | |
| Select the working mode for the current active serial port. <ul style="list-style-type: none"> ● Master mode: This mode is suitable for the DX-3001 to perform the read/write tasks on the open register of the Slave. ● Close: Disable this functionality. | Close |
| Baud Rate | |
| Set up the baud rate for the serial port. Options are 2400, 4800, 9600, 19200, 38400, 57600 and 115200. | 9600 |
| Data Bits | |
| Set up the data bits for the serial port. | 8 |
| Stop Bits | |
| Set up the stop bits for the serial port. Options are 1 and 2. | 1 |
| Parity Bits | |
| Set up the parity bits for the serial port. Options are None, Odd and Even. | None |
| Flow Control | |
| Set up the flow control. Options are None, XON, XOFF, RTS, and CTS. | None |
| MODBUS Mode | |
| Set up the communication mode for the device. | MODBUS RTU |
| MODBUS Timeout | |
| Set up the timeout timer from 50ms to 2000ms. If the set value is out of range, it will be automatically changed to its maximum or minimum value. | 1000ms |

3.5.3 Profile Management

This page is used for setup the parameter about data collect.

[HOME](#) [INTERFACE](#) > Profile Setting

Profile List

选择文件 未选择...文件

Import

Cancel

| Profile ID | Profile Interface | Profile Enable | File Name | Operation |
|------------|-------------------|----------------|-----------|-----------|
|------------|-------------------|----------------|-----------|-----------|

Add

🏠 INTERFACE > Profile Setting

☰ File Setting

Profile ID:

Interface: Profile Enable:

File Name Prefix: File Name:

File Name Postfix: Separation Sign:

☰ Interface Setting

Slave ID: Interval: (s)

☰ File Content

| NO. | Item Name | Function Code | Start Addr | Count | Enable | |
|-----|-----------|---------------------------------|------------|-------|-----------------------------------|---|
| 1 | | <input type="text" value="01"/> | | | <input type="text" value="True"/> | <input type="button" value="+"/> <input type="button" value="-"/> |

Save

Cancel

3.5.4 FTP/SFTP Server

After the system collects the data and generate to file, it can be upload to specified server by FTP/SFTP. Users can config the related parameter of the FTP/SFTP here.

🏠 INTERFACE > FTP/SFTP Server Setting

☰ FTP/SFTP Server

Upload Mode:

Target Server: (IP or domain name)

Port:

File Path:

Account:

Password: Unmask

Save

Cancel

| Description | Default |
|---|----------|
| Upload Mode | |
| Set the method of the data upload to server, options are FTP and SFTP | Disabled |
| Target Server | |
| Set up the FTP/SFTP server IP/domain name | |
| Port | |
| Set up the listen port of server | |
| File Path | |
| Set up the file save path in server | / |
| Account | |
| Set up the FTP/SFTP account | |
| Password | |
| Set up the FTP/SFTP password | |

3.6 System

You can set up the system configurations, including the User and device Management, Time Configurations, Firmware Upgrade, Backup & Restore, System Reboot, SD Card, and Network Diagnosis.

3.6.1 Name and Password

This page is used for reset router name and change the administrator password. The password must be a combination of 5 to 12 characters, numbers and/or underline symbols.

🏠 SYSTEM > User Management

☰ Device Name Setting

Device Name

☰ Change Administrator Password

Old Password
New Password

The password must be a combination of 5 to 12 characters, numbers and underline marks

Confirm Password

☰ Session Timeout Setting

Session Timeout: (10-1440 min)

| Description | Default |
|---|--|
| Device Name | |
| Input the new name of this router. | DX3001 + “_” + “the last four digits of Mac” |
| Old Password | |
| Input the original password of admin. | admin |
| New Password | |
| Input the new password you'd like to use. The password length should be 5-12 digits and is composed of lowercase letters, uppercase letters (case sensitive), numerals 0-9 and underline. | N/A |
| Confirm Password | |
| Again input the password you'd like to use to double confirm there is no typo. | N/A |
| Session Timeout | |
| Session timeout is an expired time limit for a logged in user which has been inactive for a period of time. Setting range is from 10 to 1440 minutes | 30 |

3.6.2 Time Zone Settings

This page is used for set the NTP server to synchronizing router clocks over network. Use the dropdown list to select the server or manual input server IP/domain.

[SYSTEM](#) > Time Settings

The current time of device 2016-05-19 09:38:56

NTP Server: ▼

Save

Cancel

| Description | Default |
|--|---------|
| The current time of device | |
| Here shows the current time of your device. | N/A |
| NTP Server | |
| Select the operating time zone of your device: GMT-12:00 - GMT+13:00. | N/A |
| Main NTP Server | |
| Manual input the primary NTP server Domain/IP when “Others” was selected | N/A |
| Backup NTP Server | |
| Manual input the secondary NTP server Domain/IP when “Others” was selected | N/A |

3.6.3 Firmware Upgrade

This page is used for upgrading the system.

🏠 SYSTEM > Software Upgrade Settings

☰ System Upgrade

DO NOT turn off the power supply or reboot the device during the upgrade process. Please select the correct firmware package which is consistent with the device model, otherwise the device may be damaged !

(Before upgrade the firmware, please backup the settings and data. Please contact the local dealers or manufacturers when failed to upgrade the firmware)

Select Firmware 未选择任何文件

| Description | Default |
|--|---------|
| Chose file | |
| Click "Choose file" to select the new firmware file. | N/A |
| Upgrade | |
| Click "Upgrade" to upgrade firmware. The device will reboot after the upgrade is done. | N/A |

3.6.4 Backup & Restore

This page is used for backing up and restoring the configurations.

🏠 SYSTEM > Backup & Restore

☰ Backup & Restore

Device configurations can be backed up and saved to local PC

Configuration restoration will remove the current settings in the device and restore the configurations in your .cfg file

Select .Cfg File

Configurations will be reset to the factory default settings, device will be reboot after the reset

| Description | Default |
|--|---------|
| Backup | |
| Click "Backup" to save the device configurations on your computer. | N/A |
| Restore | |
| Click "Chose file" to select the backup file and then click "Restore" to restore the configurations. The device configuration will be restored to the previous version and the device will reboot after the restoring is done. | N/A |

| Description | Default |
|---|---------|
| Restore To Factory Default | |
| Click "Restore To Factory Default" to reset the configurations to the factory defaults. The device will reboot after the reset is done. | N/A |

3.6.5 System Reboot

This page is used for manually rebooting the system. Click "Restart Device" and the system will reboot.

[SYSTEM](#) > System Reboot

System Reboot

The network will be temporarily shut down during system reboot, please wait!

[Restart Device](#)

3.6.6 SD Card

This page is used for manage SD card.

[SYSTEM](#) > SD Card

SD Card Setting

Storage Limit

%

[Save](#)

Format SD Card

Format the SD card, the data will be completely removed!


[Format SD Card](#)

| Description | Default |
|--|---------|
| Storage Limit | |
| Set the storage usage limitation of the SD card. The oldest data will be overwriting when the storage usage matches the configured value | 90% |
| Format SD Card | |
| Click on the button to perform formatting SD card | N/A |

3.6.7 Network Diagnosis

This page is used for diagnosing the network status; methods are Ping Test and Route Trace.

🏠 SYSTEM > Network Diagnosis



3

| Description | Default |
|--|-----------|
| Diagnosing Method | |
| Select the Diagnosing Method; options are Ping Test and Route Trace. | Ping Test |
| Host Name/IP Address | |
| Input the Host Name or the IP Address. | N/A |
| Start | |
| Click "Start" to start the network diagnosing. While running the network diagnosing, the settings cannot be changed. | N/A |